# 0.0.0.1 Lab - Initializing and Reloading a Router and Switch

# Topology



#### **Objectives**

Part 1: Set Up Devices in the Network as Shown in the Topology

#### Part 2: Initialize the Router and Reload

Part 3: Initialize the Switch and Reload

#### Background / Scenario

Before starting a CCNA hands-on lab that makes use of either a Cisco router or switch, ensure that the devices in use have been erased and have no startup configurations present. Otherwise, the results of your lab may be unpredictable. This lab provides a detail procedure for initializing and reloading a Cisco router and a Cisco switch.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS software, Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports

# Part 1: Set Up Devices in the Network as Shown in the Topology

#### Step 1: Cable the network as shown in the topology.

Attach console cables to the devices shown in the topology diagram.

#### Step 2: Power on all the devices in the topology.

Wait for all devices to finish the software load process before moving to Part 2.

#### Part 2: Initialize the Router and Reload

#### Step 1: Connect to the router.

Console into the router and enter privileged EXEC mode using the enable command.

```
Router> enable
Router#
```

#### Step 2: Erase the startup configuration file from NVRAM.

Type the **erase startup-config** command to remove the startup configuration from nonvolatile randomaccess memory (NVRAM).

```
Router# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
Erase of nvram: complete
Router#
```

#### Step 3: Reload the router.

Issue the **reload** command to remove an old configuration from memory. When prompted to Proceed with reload, press Enter to confirm the reload. Pressing any other key will abort the reload.

```
Router# reload

Proceed with reload? [confirm]

*Nov 29 18:28:09.923: %SYS-5-RELOAD: Reload requested by console. Reload Reason:
```

Reload Command.

**Note**: You may receive a prompt to save the running configuration prior to reloading the router. Respond by typing **no** and press Enter.

System configuration has been modified. Save? [yes/no]: no

#### Step 4: Bypass the initial configuration dialog.

After the router reloads, you are prompted to enter the initial configuration dialog. Enter no and press Enter.

Would you like to enter the initial configuration dialog? [yes/no]: no

#### Step 5: Terminate the autoinstall program.

You will be prompted to terminate the autoinstall program. Respond yes and then press Enter.

```
Would you like to terminate autoinstall? [yes]: yes
Router>
```

# Part 3: Initialize the Switch and Reload

#### Step 1: Connect to the switch.

Console into the switch and enter privileged EXEC mode.

```
Switch> enable
Switch#
```

#### Step 2: Determine if there have been any virtual local-area networks (VLANs) created.

Use the show flash command to determine if any VLANs have been created on the switch.

```
Switch# show flash
```

```
Directory of flash:/
```

 2
 -rwx
 1919
 Mar 1 1993 00:06:33 +00:00
 private-config.text

 3
 -rwx
 1632
 Mar 1 1993 00:06:33 +00:00
 config.text

 4
 -rwx
 13336
 Mar 1 1993 00:06:33 +00:00
 multiple-fs

 5
 -rwx
 11607161
 Mar 1 1993 02:37:06 +00:00
 c2960-lanbasek9-mz.150-2.SE.bin

 6
 -rwx
 616
 Mar 1 1993 00:07:13 +00:00
 vlan.dat

```
32514048 bytes total (20886528 bytes free) Switch#
```

#### Step 3: Delete the VLAN file.

a. If the **vlan.dat** file was found in flash, then delete this file.

Switch# delete vlan.dat

Delete filename [vlan.dat]?

You will be prompted to verify the file name. At this point, you can change the file name or just press Enter if you have entered the name correctly.

b. When you are prompted to delete this file, press Enter to confirm the deletion. (Pressing any other key will abort the deletion.)

Delete flash:/vlan.dat? [confirm]
Switch#

#### Step 4: Erase the startup configuration file.

Use the **erase startup-config** command to erase the startup configuration file from NVRAM. When you are prompted to remove the configuration file, press Enter to confirm the erase. (Pressing any other key will abort the operation.)

```
Switch# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
Erase of nvram: complete
Switch#
```

#### Step 5: Reload the switch.

Reload the switch to remove any old configuration information from memory. When you are prompted to reload the switch, press Enter to proceed with the reload. (Pressing any other key will abort the reload.)

```
Switch# reload
Proceed with reload? [confirm]
```

**Note**: You may receive a prompt to save the running configuration prior to reloading the switch. Type **no** and press Enter.

System configuration has been modified. Save? [yes/no]: no

#### Step 6: Bypass the initial configuration dialog.

After the switch reloads, you should see a prompt to enter the initial configuration dialog. Type **no** at the prompt and press Enter.

Would you like to enter the initial configuration dialog? [yes/no]: **no** Switch>

#### Reflection

- 1. Why is it necessary to erase the startup configuration before reloading the router?
- 2. You find a couple configurations issues after saving the running configuration to the startup configuration, so you make the necessary changes to fix those issues. If you were to reload the device now, what configuration would be restored to the device after the reload?

# 0.0.0.2 Lab - Installing the IPv6 Protocol and Assigning Host Addresses with Windows XP

## Objectives

#### Part 1: Install the IPv6 Protocol on a Windows XP PC

- Install the IPv6 protocol.
- Examine IPv6 address information.

#### Part 2: Use the Network Shell (netsh) Utility

- Work inside the **netsh** utility.
- Configure a static IPv6 address on the local-area network (LAN) interface.
- Exit the **netsh** utility.
- Display IPv6 address information using netsh.
- Issue **netsh** instructions from the command prompt.

## **Background / Scenario**

The Internet Protocol Version 6 (IPv6) is not enabled by default in Windows XP. Windows XP includes IPv6 implementation, but the IPv6 protocol must be installed. XP does not provide a way to configure IPv6 static addresses from the Graphical User Interface (GUI), so all IPv6 static address assignments must be done using the Network Shell (**netsh**) utility.

In this lab, you will install the IPv6 protocol on a Windows XP PC. You will then assign a static IPv6 address to the LAN interface.

#### **Required Resources**

1 Windows XP PC

# Part 1: Install the IPv6 Protocol on a Windows XP PC

In Part 1, you will install the IPv6 protocol on a PC running Windows XP. You will also use two commands to view the IPv6 addresses assigned to the PC.

#### Step 1: Install the IPv6 protocol.

From the command prompt window, type ipv6 install to install the IPv6 protocol.



#### Step 2: Examine IPv6 Address Information.

Use the **ipconfig /all** command to view IPv6 address information.

C:\WINDOWS\system32\cmd.exe	×
Ethernet adapter Local Area Connection:	•
Connection-specific DNS Suffix . : Description VMware Accelerated AMD PCNet Adapter	
Physical Address	
funnel adapter Teredo Tunneling Pseudo-Interface:	
Connection-specific DNS Suffix .: Description	
funnel adapter Automatic Tunneling Pseudo-Interface:	
Connection-specific DNS Suffix . : Description Automatic Tunneling Pseudo-Interface	
Physical Address	
NetBIOS over Tcpip : Disabled	

# Part 2: Use the Network Shell (netsh) Utility

Network Shell (**netsh**) is a command-line utility included with Windows XP and newer Windows operating systems, such as Vista and Windows 7. It allows you to configure the IPv6 address information on your LAN. In Part 2, you will use the **netsh** utility to configure static IPv6 address information on a Windows XP PC LAN interface. You will also use the **netsh** utility to display the PC LAN interface IPv6 address information.

#### Step 1: Work inside the Network Shell utility.

a. From the command prompt window, type **netsh** and press Enter to start the **netsh** utility. The command prompt changes from **C:**> to **netsh**>.



b. At the prompt, enter a question mark (?) and press Enter to provide the list of available parameters.

netsh}?	
The following	g commands are available:
È contra	-
Commands in t	this context:
	- Goes up one context level.
?	– Displays a list of commands.
abort	— Discards changes made while in offline mode.
add	<ul> <li>Adds a configuration entry to a list of entries.</li> </ul>
alias	- Adds an alias.
bridge	- Changes to the `netsh bridge' context.
bye	- Exits the program.
commit	- Commits changes made while in offline mode.
delete 🔪	<ul> <li>Deletes a configuration entry from a list of entries.</li> </ul>
diag 🔨	- Changes to the `netsh diag' context.
ժստք	- Displays a configuration script.
exec	- Runs a script file.
exit	- Exits the program.
firewall	- Changes to the `netsh firewall' context.
help	- Displays a list of commands.
interface	<ul> <li>Changes to the interface' context.</li> </ul>
lan	- Changes to the inetsh lan' context.
nap	- Changes to the `netsh nap' context.
offline	- Sets the current mode to offline.
online	- Sets the current mode to online.
popd	<ul> <li>Pops a context from the stack.</li> </ul>
pushd	<ul> <li>Pushes current context on stack.</li> </ul>
quit	- Exits the program.
ras	- Changes to the _netsh ras' context.
routing	<ul> <li>Changes to the netsh routing' context.</li> </ul>
set	- Updates configuration settings.
show	- Displays information.
unalias	- Deletes an alias.
winsock	<ul> <li>Ghanges to the 'netsh winsock' context.</li> </ul>
The following bridge diag	g sub-contexts are available: firewall interface lan nap ras routing winsock
To view help type ?.	for a command, type the command, followed by a space, and then
netsh>	

c. Type interface ? and press Enter to provide the list of interface commands.

netsh>interfa	ce ?
The following	commands are available:
Commands in t ? add delete dump help ip ipv6 portproxy reset set show	<ul> <li>his context:</li> <li>Displays a list of commands.</li> <li>Adds a configuration entry to a table.</li> <li>Deletes a configuration entry from a table.</li> <li>Displays a configuration script.</li> <li>Displays a list of commands.</li> <li>Changes to the `netsh interface ip' context.</li> <li>Changes to the `netsh interface ipu6' context.</li> <li>Changes to the `netsh interface portproxy' context.</li> <li>Resets information.</li> <li>Displays information.</li> </ul>
The following ip ipv6 port	sub-contexts are available: proxy
To view help type ?.	for a command, type the command, followed by a space, and then
netsh>_	

**Note**: You can use the question mark (?) at any level in the **netsh** utility to list the available options. The up arrow can be used to scroll through previous **netsh** commands. The **netsh** utility also allows you to abbreviate commands, as long as the abbreviation is unique.

#### Step 2: Configure a static IPv6 address on the LAN interface.

To add a static IPv6 address to the LAN interface, issue the **interface ipv6 add address** command from inside the **netsh** utility.

netsh>interface ipv6 add address "Local Area Connection" 2001:db8:acad:a::3 Ok. netsh>

#### Step 3: Display IPv6 address information using the netsh utility.

You can display IPv6 address information using the interface ipv6 show address command.

```
netsh≻interface ipv6 show address
Querying active state...
Interface 5: Local Area Connection
Addr Type
           DAD State Valid Life
                                     Pref. Life
                                                   Address
                           infinite
Manual
           Preferred
                                         infinite 2001:db8:acad:a::3
                                         infinite fe80::250:56ff:febe:2587
Link
           Preferred
                           infinite
Interface 4: Teredo Tunneling Pseudo-Interface
                       Valid Life
Addr Type
           DAD State
                                     Pref. Life
                                                   Address
Link
           Preferred
                           infinite
                                         infinite fe80::ffff:ffff:fffd
Interface 2: Automatic Tunneling Pseudo-Interface
Addr Type
                       Valid Life
           DAD State
                                     Pref. Life
                                                   Address
Link
           Preferred
                           infinite
                                         infinite fe80::5efe:169.254.39.128
Interface 1: Loopback Pseudo-Interface
Addr Type
           DAD State
                       Valid Life
                                     Pref. Life
                                                   Address
                           infinite
infinite
                                         infinite ::1
infinite fe80::1
Loopback
           Preferred
Link
           Preferred
netsh>
```

#### Step 4: Exit the netsh utility.

Use the exit command to exit from the netsh utility.



#### Step 5: Issue netsh instructions from the command prompt.

All **netsh** instructions can be entered from the command prompt, outside the **netsh** utility, by preceding the instruction with the **netsh** command.

C:∖>netsh Querying a	interface i active state	pv6 show addre 	288	
Interface	5: Local Are	ea Connection		
Addr Type	DAD State	Valid Life	Pref. Life	Address
Manual Link	Preferred Preferred	infinite infinite	infinite infinite	2001:db8:acad:a::3 fe80::250:56ff:febe:2587
Interface	4: Teredo Tu	unneling Pseud	do-Interface	
Addr Type	DAD State	Valid Life	Pref. Life	Address
Link	Preferred	infinite	infinite	fe80::ffff:ffffd
Interface	2: Automatic	: Tunneling Pa	seudo-Interfa	ce
Addr Type	DAD State	Valid Life	Pref. Life	Address
Link	Preferred	infinite	infinite	fe80::5efe:169.254.39.128
Interface	1: Loopback	Pseudo-Interf	face	
Addr Type	DAD State	Valid Life	Pref. Life	Address
Loopback Link	Preferred Preferred	infinite infinite	infinite infinite	::1 fe80::1
c:<>				

#### Reflection

1. How would you renew your LAN interface address information from the netsh utility?

Hint: Use the question mark (?) for help in obtaining the parameter sequence.

# **1.0.1.2 Draw Your Concept of the Internet**

#### Objectives

#### Networks are made of many different components

In this activity, you will visualize how you are connected, through the Internet, to those places, people, or businesses with whom (or which) you interact on a daily basis. After reflection and sketching your home's or school's topology, you can draw conclusions about the Internet that you may not have thought of prior to this activity.

#### **Background / Scenario**

Draw and label a map of the Internet as you interpret it now. Include your home or school/university location and its respective cabling, equipment, devices, etc. Some items you may want to include:

- Devices or equipment
- Media (cabling)
- Link addresses or names
- Sources and destinations
- Internet service providers

Upon completion, save your work in a hard-copy format, it will be used for future reference at the end of this chapter. If it is an electronic document, save it to a server location provided by your instructor. Be prepared to share and explain your work in class.

For an example to get you started, please visit: http://www.kk.org/internet-mapping

#### **Required Resources**

- Internet access
- Paper and pencils or pens (if students are creating a hard copy)

#### Reflection

- 1. After reviewing your classmates drawings, were there computer devices that you could have included on your diagram? If so, which ones and why?
- 2. After reviewing your classmates' drawings, how were some of the model designs the same or different? What modifications would you make to your drawing after reviewing the other drawings?
- 3. In what way could icons on a network drawing provide a streamlined thought process and facilitate your learning? Explain your answer.

# 1.1.1.8 Lab - Researching Network Collaboration Tools

#### Objectives

#### Part 1: Use Collaboration Tools

- Identify current awareness of collaboration tools.
- Identify key reasons for using collaboration tools.

Part 2: Share Documents with Google Drive

#### Part 3: Explore Conferencing and Web Meetings

#### Part 4: Create Wiki Pages

#### **Background / Scenario**

Network collaboration tools give people the opportunity to work together efficiently and productively without the constraints of location or time zone. Collaborative tool types include document sharing, web meetings, and wikis.

In Part 1, you will identify collaboration tools that you currently use. You will also research some popular collaborative tools used today. In Part 2, you will work with Google Drive. In Part 3, you will investigate Conferencing and Web meeting tools and, in Part 4, you will work with wikis.

#### **Required Resources**

Device with Internet access

# Part 1: Use Collaboration Tools

Step 1: List some collaboration tools that you currently use today.

Step 2: List some reasons for using collaboration tools.

# Part 2: Share Documents with Google Drive

In Part 2, you will explore the document sharing functions by using Google Drive to set up document sharing. Google Drive, formally Google Docs, is a web-based office suite and data storage service that allows users to create and edit documents online while collaborating in real-time with other users. Google Drive provides 5 GB of storage with every free Google account. You can purchase additional storage, if needed.

#### Step 1: Create a Google account.

To use any of Google's services, you must first create a Google account. This account can be used with any of Google's services, including Gmail.

a. Browse to <u>www.google.com</u> and click **Sign in** (located at the top-right corner of the web page).

+You	Search	Images	Maps	Play	YouTube	News	Gmail	Documents	Calendar	More +	(	Sign in
						C	<b>C</b>	008	<u>gle</u>			
						Go	ogle Searc	ch l'm Fee	ling Lucky			

b. On the Google Accounts web page, if you already have a Google account, you can sign in now; otherwise, click **SIGN UP**.

Go	ogle		SIGN UP			
Acco	ounts					
Google h	as more to offer when you sign in to your Google Account.	Sign in	Google			
Sign in o	n the right or create an account for free.	Email				
Μ	Gmail Chat with friends and never miss an important email.	Password				
	Search, plus Your World Search the web plus your photos, posts, and stuff friends have shared with you.	Sign in 🔽 Stay signed in				
	Like Google? Make Google your homepage.	Can't access your account?				

See more benefits of a Google Account.

1

c. On the Create a new Google Account web page, fill out the form to the right. The name you enter in the **Choose your username** field becomes the account name. It is not necessary to supply your mobile phone or current email address. You must agree to the Google Terms of Service and Privacy Policy before clicking **Next step**.

GOOSIE		Sign ir
Create a new Google Accou	unt	
You You	Your Google Account is more than just Search. Talk, chat, share, schedule, store, organize, collaborate, discover, and create. Use Google products from Gmail to Google+ to YouTube, view your search history, all with one usemame and password, all backed up all the time and easy to find at (you guessed it) Google.com.	Name         First       Last         You can't leave this empty.         Choose your username         @gmail.com         You can't leave this empty.         You can't leave this empty.         Create a password
	Take it all with you. A Google Account lets you access all your stuff — Gmail, photos, and more — from any device. Search by taking pictures, or by voice. Get free turn-by-turn navigation, upload your pictures automatically, and even buy things with your phone using Google Wallet.	Confirm your password Birthday Month \$ 4 1974 Gender I am \$
Family	Share a little. Or share a lot. Share selectively with friends, family (maybe even your boss) on Google+. Start a video hangout with friends, text a group all at once, or just follow posts from people who fascinate you. Your call.	Mobile phone Your current email address Prove you're not a robot

d. The next web page allows you to add a profile photo if you would like. Click **Next Step** to complete the account creation process.

#### Step 2: Create a new document.

a. Sign in to Google using the access credentials you created in Step 1. Type http://drive.google.com in your browser and press Enter. This navigates you to Google Drive.

Google				SIGN UP
Drive Welcome to Google Drive, the net	w home for Goo	gle Docs	Sign in	Google
		Access everywhere	Email	
	۴ ۲	Store files safely	Password	
	e j	Collaborate with Google Docs	Sign in 🔽 Stay signe	rd in
		Learn more		

b. Click the **CREATE** button to display a drop-down menu that allows you to select the type of document to create. Choose **Document**.



The new document displays. Many of the functions of the Google editor work similarly to Microsoft Word.

#### Step 3: Share a Google document.

a. After the blank Google document opens, you can share it with others by clicking the **Share** button (at the top-right corner of the web page).



b. Name your new document, then click the **Save** button.

Name before sharing								
Let collaborators know what this document is about								
Untitled document								
Save	Skip							

×

c. Here on the Sharing settings web page, in the **Add people** text field, you can enter Google email names, email addresses, or groups with whom to share this document.

	os://docs.google.com/document/d/19ZaQ1f5Scnxw7	D0F9LM6aaF4oWHpDOyE
Share	e link via: 🔛 🛐 📑 Ў	
Who	has access	
â	Private - Only the people listed below can access	Change
*	John Smith (you) jsmith.netacad@gmail.com	Is owner
/	dd people:	
Ac	Enter names, email addresses, or groups	
Ac		

d. As soon as you start entering information into the Add people box, the box provides more options. The Can edit drop-down menu allows you to choose the document privileges (Can edit, Can comment, Can view) for the people you add. You can also specify how to notify these people of this document (Send a copy to myself or Paste the item itself into the email). Click Share & save.

Add people: Choose from contacts	
John Doe	Can edit •
✓ Notify people via email - Add message	
	Send a copy to myself
Share & save Cancel	email
✓ Notify people via email - Add message     Share & save   Cancel	<ul> <li>Send a copy to myself</li> <li>Paste the item itself into the email</li> </ul>

- e. Click the **Done** button. This will navigate you back to the open document.
- f. All users with share privileges can view this document at the same time. Users with edit privileges can edit this document while others view it.
- g. If the document is being viewed by someone while you are in it, you can see who they are by clicking the **other viewer(s)** drop-down menu (in the upper-right corner of the document).



#### Step 4: Close a Google document.

To close a Google document, move your cursor to the document name at the top of the screen and a left arrow will appear to the left of the name. Click that arrow to return to your Google Drive home page. The document is automatically saved.

The new document will appear at the top of your documents list under My Drive.

+John	Search	Images	Maps	Play	YouTube	News	Gmail	Drive	Calendar	More -					
Goo	ogle									~	Q		John Smith	0 +	
Drive			<u>*</u> +		i i	Ì	0	N	Nore 🔻			Sort 👻	= ::	\$	*
CREAT My Drive Shared v Starred More - Downloa	CREATE       ▲         Drive ared with me rred cent re ✓       My Drive is the home for all your files. With Google Drive for your PC, you can sync files from your computer to My Drive.         Download Google Drive for PC					ſ				Then, go fo • Explore t • Create G • See files • Get the C	r a spin he left hand oogle Docs at a glance Google Drive	navigation. and more. with the new g mobile app.	rid view.	×	
			тт	LE							OV	VNER	LAST	MODIFIED	
			☆ 🔳	Test Do	cument 1 Sh	nared					me	e	12:00	pm me	

#### Step 5: Additional Information

Google has developed apps for PCs and Smart phones. For more information about Google Drive, go to <u>http://drive.google.com</u>. YouTube is also a viable source of Google Drive tutorials.

# Part 3: Explore Conferencing and Web Meetings

Web meetings combine file and presentation sharing with voice, video, and desktop sharing. Cisco WebEx Meeting Center is one of the leading web meeting products available today.

In Part 3 of this lab, you will watch a video produced by Cisco that reviews the features contained within WebEx Meeting Center. The video is located on YouTube at the following link: <u>http://www.youtube.com/watch?v=fyaWHEF\_aWg</u>

## Part 4: Create Wiki Pages

"Wiki" is a Hawaiian-language word that means fast. In networking terms, a wiki is a web-based collaboration tool that permits almost anyone to immediately post information, files, or graphics to a common site for other users to read and modify. A wiki provides access to a home page that has a search tool to assist you in locating the articles that interest you. A wiki can be installed for the Internet community or behind a corporate firewall for employee use. The user not only reads wiki contents, but also participates by creating content within a web browser.

Although many different wiki servers are available, the following common features have been formalized into every wiki:

- Any web browser can be used to view or edit pages or create new content.
- Edit and auto links are available to edit a page and automatically link pages. Text formatting is similar to creating an email.
- A search engine is used for quick content location.
- Access control can be set by the topic creator, defining who is permitted to edit content.
- A wiki is a grouping of web pages with different collaboration groups.

In this part of the lab, you will use the Google account that you created in Part 2 and create a wiki page in Google Sites.

#### Step 1: Sign in to Google Sites.

Go to http://sites.google.com and sign in using the Google account that you created in Part 2 of this lab.



#### Step 2: Click CREATE.



Step 3: Name your new wiki site.

In the **Name your site** field, type in a name for your new wiki site. You will need to come up with a unique name for your site that has not been used by any other Google user. Google also requires that you enter the code (displayed at the bottom of the screen) to prevent automated scripts, called web robots, from creating multiple sites. After you have entered your site name, click the **CREATE** button. If someone has used your site name already, you are prompted to enter another name.



#### Step 4: Edit the look of your new wiki site.

a. Google has provided templates for you to change the look of your new wiki site. Click the **More** dropdown menu, and then click **Manage site**.

Take o	ur survey!	More 👻	Share
	Page actions		
	Revision History	g then r	
	Subscribe to page changes	f	
	Page settings	u	
	🖶 Print page	Ctrl + p	
	👕 Delete page		
	Preview page as viewer	g then p	
Sites	Page templates		
ones	Save as page template		
	Change page template	Shift + t	
	Site actions		
	Subscribe to site changes	Shift + f	
	Edit site layout New!	Shift + L	
	Manage site		
	Sign up for AdSense		
	Sharing and Permissions	Shift + S	
	Sites help		
	Report an Issue		

b. Click **Themes** at the bottom of the left sidebar.

Manage Site
< Wiki Example C1LA
Recent site activity
Pages
Attachments
Page templates
Apps Scripts
Deleted items
General
Sharing and Permissions
AdSense
Web Address
Site layout
Colors and Fonts
Themes

c. Select a theme that appeals to you and click **SAVE**.

+John Search Images	Maps Play	YouTube News	Gmail Drive Ca	lendar More -	
Google	Search my sit	es			<b>Ψ Q</b>
Manage Site	SAVE	Preview Cance	I		
< Wiki Example C1LA	Select a theme	to use or build your o	wn custom theme		
Recent site activity					-
Pages			1		
Attachments	-				
Page templates	Iceberg Q	Open Sky <b>Q</b>	Rounders Q	Slate Q	Simple Q
Apps Scripts					
Deleted items					
General		Γ	_		
Permissions					
AdCanaa	Legal Pad Q	Blank Slate Q	Micro Blueprint C	Micro Lite Q	Micro Sport Q

- 10		2.10	10-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-			1.99	and the second			10.00			
+John	Search	Images	Maps	Play	YouTube	News	Gmail	Drive	Calenda	r More	2		
G	oogle		Search	my sit	es						*	٩	l,
Ma	nage Site	e	SAVE		Preview	Cancel							
< Wiki	Example C1		Select	a theme	to use or bu	uild your o	wn custon	n theme			_		
Rece	nt site activity	y	-	_			1			_			
Page	s							Ŵ	=				
Attac	hments												
Page	templates		Iceberg	Q	Open	Sky Q	Ro	unders Q		Slate <b>Q</b>		Simple Q	
Apps	Scripts												
Delet	ed items							_					-
Gene	ral				r								
Shari Perm	ng and issions					1	-		-			6	
AdCa			Legal F	ad Q	Blank	Slate Q	Mi	cro Bluepr	int Q	Micro Lite C	2	Micro Sport	Q

d. After you have saved your theme selection, click your site name under Manage Site.

#### Step 5: Update the Home page.

a. The Home page is the first page that everyone sees when they come to your wiki site. You can edit the content of this page by clicking the edit button. From here, you can add text, pictures, or anything else to show on this page.

Home Undated 8 minutes and	
Take our surver Mon	🗧 👻 Share
Name	
Kaemap Home	
Recent Site Activity   Report Aluze   Entit Page   Remove Access   Format By Google Sites	

b. Click **Save** after you make your changes. This takes you out of page edit mode.

	John Smith 🗸
Home	draft saved at 917 AM Save Cancel
Insert <u>F</u> ormat <u>T</u> at	ble Layout
🖛 🕾 Normal	- 10 pt - B I U <u>A</u> - M- co ⊨ ⊟ ⊡ ⊡ ≡ ≡ ≡ ∃ I <sub>X</sub> «mu⊳
Home Sitemap	Home
	Welcome to our Wiki Site!
	Please feel free to go to the Wiki pages on the left and enter content.
	Recent Site Activity   Report Abuse   Print Page   Remove Access   Powered By Google Sites

#### Step 6: Create a wiki page.

a. To create a new page that you and your visitors can use to make posts, click the new page icon.



b. In the **Name your page** field, enter a page name. In the example below, the name Routers is used as the topic for this page.

Sites	CREATE Cancel
	Create a page in Site: Wiki Example C1LA
	Name your page: Routers Your page URL: /site/wikievampleeffarfouters change URL

c. Click the **Web Page** drop-down menu and select **Announcements**. Google uses this term to indicate a wiki page.

Create a page in Site: Wiki Example C1LA

	Routers		
Y	'our page URL: /site/wikiexa	amplec1la/ <mark>route</mark>	ers change URI
S	Select a template to use (Le	arn more)	
ſ	Web Page		
1	Announcements	$\supset$	
T	File Cabinet		

d. Click **CREATE** to create your new wiki page.

Sites	CREATE Cancel
	Create a page in Site: Wiki Example C1LA
	Name your page:
	Routers
	Your page URL: /site/wikiexamplec1la/routers change URL
	Select a template to use (Learn more)
	Announcements 💠
	Select a location:

e. Your new wiki page, called Routers, displays and has a **New post** menu option that allows information to be added to the page. (Notice that the left sidebar has a new link to allow your site visitors access to this page.)

Routers	John Smith ~ Take our survey!
Home Routers Sitemap	Routers
	New post Subscribe to posts
	Recent Site Activity : Report Abuse   Print Page   Remove Accessa   Pavened By Google Sites

#### Step 7: Share your web site.

A wiki site is not really a wiki site unless other people can contribute. There are a number of ways to share your new site. In this example, we will show you how to share your site to designated people who have Gmail accounts.

a. On your wiki site, click Share.

Routers	Take our survey!
Home Routers Sitemap	Routers
	New post         Subscribe to posts           There are currently no posts. Create one now by clicking the "New post" button.
	Recent Site Activity   Report Abuse   Print Page   Remove Access   Powered By Google Sites

b. Add a name, email address, or group who you grant access to this site.

John Smith (you) jsmith.netacad@gmail.com Is owner	John Smith (you) jsmith.netacad@gmail.com Is owner	9	Public on the web - Anyone on the Internet can find and <b>view</b>	Change
	Add people:		John Smith (you) jsmith.netacad@gmail.com	Is owner
	Add people:			
	Add people:			
	Add people:			

c. As soon as you start entering information into the **Add people** box, the box provides more options. The **Can edit** drop-down menu allows you to choose the document privileges (Can edit, Can comment, Can view) for the people you add. You can also specify how to notify these people of this document (**Send a copy to myself** or **Paste the item itself into the email**). Click **Share & save**.

Add people: Cl janedoe@gmai	noose from conta I.com	acts Can edit ▼	
✓ Notify people Share & save	via email - Add Cancel	message	
Share & save	Cancel	Send a copy to myself	

d. Click Share & save to save your sharing settings.



e. The **Manage Site** page displays the people who have access to your site. Click your site name to return to your home page.

Manage Site		Enable page-level permissions
Wiki Example C1LA Recent site activity	Link to share https://sites.google.com/site/wikiexamplec1la/	
Pages Attachments	Share link via: 🔛 👫 手 🎽	
Page templates Apps Scripts	Who has access Public on the web - Anyone on the Internet Change	
Deleted items	John Smith (you) jsmith.netacad@gmail.com     Is owner	
Sharing and Permissions AdSense	Lane Doe janedoe@gmail.com Can edit ▼	×

#### Step 8: Provide the URL of your site.

You can provide your URL to your new site by adding your site name to the end of the Google site URL, as shown here: http://sites.google.com/site/(sitename).

#### Step 9: Find additional information.

You can find a quick overview of how a wiki works at http://www.youtube.com/watch?v=-dnL00TdmLY.

Other examples of wikis and their web sites include:

- Wikipedia <u>http://www.wikipedia.org/</u>
- Atlassian Confluence (a popular business wiki) http://www.atlassian.com/software/confluence/
- Wikispaces (another free wiki) <u>http://www.wikispaces.com/</u>

#### Reflection

- 1. Can you think of other collaboration tools used in the business world today?
- 2. What collaboration tools do you see as useful to a network administrator?

# **1.2.3.3 Lab - Researching Converged Network Services**

#### **Objectives**

Part 1: Survey Your Understanding of Convergence

- Part 2: Research ISPs Offering Converged Services
- Part 3: Research Local ISPs Offering Converged Services
- Part 4: Select Best Local ISP Converged Service

#### Part 5: Research Local Company or Public Institution Using Convergence Technologies

#### **Background / Scenario**

Convergence in the context of networking is a term used to describe the process of combining voice, video, and data communications over a common network infrastructure. Converged networks have existed for some time, but were only feasible in large enterprise organizations because of the network infrastructure requirements and complex management required to make them work seamlessly. Technology advances have made convergence readily available to large, medium, and small businesses, as well as for the home consumer.

In Part 1, you will describe your current understanding of convergence and any experience you have with it.

In Part 2, you will research which providers have this service, regardless of geographical location, using the predefined form included in the lab.

In Part 3, you will research which local ISPs in your area offer converged services for end-user consumers, using the predefined form included in the lab.

In Part 4, you will select the ISP you like best for home use and list the reasons why.

In Part 5, you will find a local company or public institution using convergence technologies in their business, using the predefined form included in the lab.

#### **Required Resources**

Device with Internet access

# Part 1: Survey Your Understanding on Convergence

#### Step 1: Describe convergence as you understand it and give examples of its use in the home.

Write a definition of convergence and list some examples.

# Part 2: Research ISPs Offering Converged Services

In Part 2, you research and find two or three ISPs who offer converged services for the home, regardless of geographical location.

#### Step 1: Research various ISPs that offer converged services.

List some of the ISPs that you found in your search.

#### Step 2: Fill in the following form for the ISPs selected.

Internet Service Provider	Product Name of Converged Service

# Part 3: Researching Local ISPs Offering Converged Services

In Part 3, you research and find two or three local ISPs who offer converged services for the home in your geographic area.

#### Step 1: Research various ISPs that offer converged services.

List some of the ISPs that you found in your search.

#### Step 2: Fill in the following form for the ISPs selected.

Internet Service Provider	Product Name of Converged Service	Cost per Month	Download Speed

# Part 4: Select Best Local ISP Converged Service Offering

Select your top choice from the list of local ISPs that you selected and give reasons why you chose that particular one.

# Part 5: Research Local Company or Public Institution Using Convergence Technologies

In Part 5, you research and locate a company in your area that currently uses convergence technologies in their business.

#### Step 1: Research and find a local company using convergence.

In the following table, list the company, industry, and convergence technologies used.

Name of Company	Industry	Convergence Technologies

# Reflection

1. What are some of the advantages of using convergence technologies?

2. What are some of the disadvantages of using convergence technologies?

# 1.3.1.3 Lab - Mapping the Internet

#### Objectives

- Part 1: Test Network Connectivity Using Ping
- Part 2: Trace a Route to a Remote Server Using Windows Tracert
- Part 3: Trace a Route to a Remote Server Using Web-Based and Software Tools

#### Part 4: Compare Traceroute Results

#### Background

Route tracing computer software is a utility that lists the networks data has to traverse from the user's originating end device to a distant destination network.

This network tool is typically executed at the command line as:

tracert <destination network name or end device address>

(Microsoft Windows systems)

or

traceroute <destination network name or end device address>

(Unix and similar systems)

Route tracing utilities allow a user to determine the path or routes as well as the delay across an IP network. Several tools exist to perform this function.

The **traceroute** (or **tracert**) tool is often used for network troubleshooting. By showing a list of routers traversed, it allows the user to identify the path taken to reach a particular destination on the network or across internetworks. Each router represents a point where one network connects to another network and through which the data packet was forwarded. The number of routers is known as the number of "hops" the data traveled from source to destination.

The displayed list can help identify data flow problems when trying to access a service such as a website. It can also be useful when performing tasks such as downloading data. If there are multiple websites (mirrors) available for the same data file, one can trace each mirror to get a good idea of which mirror would be the fastest to use.

Two trace routes between the same source and destination conducted some time apart may produce different results. This is due to the "meshed" nature of the interconnected networks that comprise the Internet and the Internet Protocols ability to select different pathways over which to send packets.

Command-line-based route tracing tools are usually embedded with the operating system of the end device.

Other tools, such as VisualRoute<sup>™</sup>, are proprietary programs that provide extra information. VisualRoute uses available online information to graphically display the route.

This lab assumes the installation of VisualRoute. If the computer you are using does not have VisualRoute installed, you can download the program using the following link:

#### http://www.visualroute.com/download.html

If you have any trouble downloading or installing VisualRoute, ask your instructor for assistance. Ensure that you download the Lite Edition.

and the second second second	Windows XP\2003\Vista\7	4.0Mb	Download
VisualRoute Lite Edition	Mac OS X (dmg) 10.3+, universal binary	2.0Mb	Download

#### Scenario

Using an Internet connection, you will use three route tracing utilities to examine the Internet pathway to destination networks. This activity should be performed on a computer that has Internet access and access to the command line. First, you will use the Windows embedded tracert utility. Second, you will use a web-based traceroute tool (<u>http://www.subnetonline.com/pages/network-tools/online-traceroute.php</u>). Finally, you will use the VisualRoute traceroute program.

#### **Required Resources**

1 PC (Windows 7, Vista, or XP with Internet access)

# Part 1: Test Network Connectivity Using Ping

#### Step 1: Determine whether the remote server is reachable.

To trace the route to a distant network, the PC used must have a working connection to the Internet.

- a. The first tool we will use is ping. Ping is a tool used to test whether a host is reachable. Packets of information are sent to the remote host with instructions to reply. Your local PC measures whether a response is received to each packet, and how long it takes for those packets to cross the network. The name ping comes from active sonar technology in which a pulse of sound is sent underwater and bounced off of terrain or other ships.
- b. From your PC, click the **Windows Start** icon, type **cmd** in the **Search programs and files** box, and then press Enter.



c. At the command-line prompt, type **ping www.cisco.com**.

# C:\>ping www.cisco.com Pinging e144.dscb.akamaiedge.net [23.1.48.170] with 32 bytes of data: Reply from 23.1.48.170: bytes=32 time=56ms TTL=57 Reply from 23.1.48.170: bytes=32 time=55ms TTL=57 Reply from 23.1.48.170: bytes=32 time=54ms TTL=57 Ping statistics for 23.1.48.170: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 54ms, Maximum = 56ms, Average = 54ms

- d. The first output line displays the Fully Qualified Domain Name (FQDN) e144.dscb.akamaiedge.net. This is followed by the IP address 23.1.48.170. Cisco hosts the same web content on different servers throughout the world (known as mirrors). Therefore, depending upon where you are geographically, the FQDN and the IP address will be different.
- e. From this portion of the output:

```
Ping statistics for 23.1.48.170:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 54ms, Maximum = 56ms, Average = 54ms
```

Four pings were sent and a reply was received from each ping. Because each ping was responded to, there was 0% packet loss. On average, it took 54 ms (54 milliseconds) for the packets to cross the network. A millisecond is 1/1,000<sup>th</sup> of a second.

Streaming video and online games are two applications that suffer when there is packet loss, or a slow network connection. A more accurate determination of an Internet connection speed can be determined by sending 100 pings, instead of the default 4. Here is how to do that:

#### C:\>ping -n 100 www.cisco.com

And here is what the output from that looks like:

```
Ping statistics for 23.45.0.170:
Packets: Sent = 100, Received = 100, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 46ms, Maximum = 53ms, Average = 49ms
```

f. Now ping Regional Internet Registry (RIR) websites located in different parts of the world:

For Africa: C:\> ping www.afrinic.net

#### C:\>ping www.afrinic.net

```
Pinging www.afrinic.net [196.216.2.136] with 32 bytes of data:
Reply from 196.216.2.136: bytes=32 time=314ms TTL=111
Reply from 196.216.2.136: bytes=32 time=312ms TTL=111
Reply from 196.216.2.136: bytes=32 time=313ms TTL=111
Reply from 196.216.2.136: bytes=32 time=313ms TTL=111
Ping statistics for 196.216.2.136:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 312ms, Maximum = 314ms, Average = 313ms
```

For Australia: C:\> ping www.apnic.net

#### C:\>ping www.apnic.net

Pinging www.apnic.net [202.12.29.194] with 32 bytes of data: Reply from 202.12.29.194: bytes=32 time=286ms TTL=49 Ping statistics for 202.12.29.194: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 286ms, Maximum = 287ms, Average = 286ms

For Europe:

C:\> ping www.ripe.net

C:\>ping www.ripe.net Pinging www.ripe.net [193.0.6.139] with 32 bytes of data: Request timed out. Request timed out. Request timed out. Request timed out. Ping statistics for 193.0.6.139: Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

For South America: C:\> ping lacnic.net

C:\>ping www.lacnic.net

Pinging www.lacnic.net [200.3.14.147] with 32 bytes of data: Reply from 200.3.14.147: bytes=32 time=158ms TTL=51 Reply from 200.3.14.147: bytes=32 time=158ms TTL=51 Reply from 200.3.14.147: bytes=32 time=158ms TTL=51 Reply from 200.3.14.147: bytes=32 time=157ms TTL=51 Ping statistics for 200.3.14.147: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 157ms, Maximum = 158ms, Average = 157ms

All these pings were run from a computer located in the U.S. What happens to the average ping time in milliseconds when data is traveling within the same continent (North America) as compared to data from North America traveling to different continents?

What is interesting about the pings that were sent to the European website?

# Part 2: Trace a Route to a Remote Server Using Tracert

#### Step 1: Determine what route across the Internet traffic takes to the remote server.

Now that basic reachability has been verified by using the ping tool, it is helpful to look more closely at each network segment that is crossed. To do this, the **tracert** tool will be used.

a. At the command-line prompt, type tracert www.cisco.com.

C∶∖>t	race	rt wu	W.ci	SCO.0	com		
Traci	ng ro	oute	to e	144.0	dscb.a	akam	aiedge.net [23.1.144.170]
over	a max	xımur	пот .	su no	ops:		
1	<1	ms	<1	ms	<1	ms	dslrouter.westell.com [192.168.1.1]
2	38	ms	38	ms	37	ms	10.18.20.1
3	37	ms	37	ms	37	ms	G3-0-9-2204.ALBYNY-LCR-02.verizon-gni.net [130.8
1.196	. 190	]					
4	43	ms	43	ms	42	ms	so-5-1-1-0.NY325-BB-RTR2.verizon-gni.net [130.81
.22.4	6]						
5	43	ms	43	ms	65	ms	0.so-4-0-2.XT2.NYC4.ALTER.NET [152.63.1.57]
6	45	ms	45	ms	45	ms	0.so-3-2-0.XL4.EWR6.ALTER.NET [152.63.17.109]
7	46	ms	48	ms	46	ms	TenGigE0-5-0-0.GW8.EWR6.ALTER.NET [152.63.21.14]
8	45	ms	45	ms	45	ms	a23-1-144-170.deploy.akamaitechnologies.com [23.
1.144	.170	]					
Trace	com	olete	e.				

- b. Save the tracert output in a text file as follows:
  - 1) Right-click the title bar of the Command Prompt window and choose Edit > Select All.
  - 2) Right-click the title bar of the Command Prompt window again and choose **Edit** > **Copy**.
  - 3) Open the Windows Notepad program: Windows Start icon > All Programs > Accessories > Notepad.
  - 4) To paste the output into Notepad, choose Edit > Paste.
  - 5) Choose File > Save As and save the Notepad file to your desktop as tracert1.txt.
- c. Run tracert for each destination website and save the output in sequentially numbered files.
  - C:\> tracert www.afrinic.net
  - C:\> tracert www.lacnic.net
- d. Interpreting tracert outputs.

Routes traced can go through many hops and a number of different Internet Service Providers (ISPs), depending on the size of your ISP and the location of the source and destination hosts. Each "hop" represents a router. A router is a specialized type of computer used to direct traffic across the Internet. Imagine taking an automobile trip across several countries using many highways. At different points in the trip you come to a fork in the road in which you have the option to select from several different highways. Now further imagine that there is a device at each fork in the road that directs you to take the correct highway to your final destination. That is what a router does for packets on a network.

Because computers talk in numbers, rather than words, routers are uniquely identified using IP addresses (numbers with the format x.x.x.x). The **tracert** tool shows you what path through the network a packet of information takes to reach its final destination. The **tracert** tool also gives you an idea of how fast traffic is going on each segment of the network. Three packets are sent to each router in the path, and the return time is measured in milliseconds. Now use this information to analyze the **tracert** results to www.cisco.com. Below is the entire traceroute:

C:\>t	racert wu	ww.cisco.c	om	
Traci	ng route	to e144.d	scb.akam	aiedge.net [23.1.144.170]
over	a maximur	n of 30 ho	ps:	
1	<1 ms	<1 ms	<1 ms	dslrouter.westell.com [192.168.1.1]
2	38 ms	38 ms	37 ms	10.18.20.1
3	37 ms	37 ms	37 ms	G3-0-9-2204.ALBYNY-LCR-02.verizon-gni.net [130.8
1.196	.190]			
4	43 ms	43 ms	42 ms	so-5-1-1-0.NY325-BB-RTR2.verizon-gni.net [130.81
.22.4	61			
5	43 ms	43 ms	65 ms	0.so-4-0-2.XT2.NYC4.ALTER.NET [152.63.1.57]
6	45 ms	45 ms	45 ms	0.so-3-2-0.XL4.EWR6.ALTER.NET [152.63.17.109]
7	46 ms	48 ms	46 ms	TenGigE0-5-0-0.GW8.EWR6.ALTER.NET [152.63.21.14]
8	45 ms	45 ms	45 ms	a23-1-144-170.deploy.akamaitechnologies.com [23.
1.144	.170]			
Trace	complete	e.		

Below is the breakdown:



In the example output shown above, the tracert packets travel from the source PC to the local router default gateway (hop 1: 192.168.1.1) to the ISPs Point of Presence (POP) router (hop 2: 10.18.20.1). Every ISP has numerous POP routers. These POP routers are at the edge of the ISP's network and are the means by which customers connect to the Internet. The packets travel along the Verizon network for two hops and then jump to a router that belongs to alter.net. This could mean that the packets have traveled to another ISP. This is significant because sometimes there is packet loss in the transition between ISPs, or sometimes one ISP is slower than another. How could we determine if alter.net is another ISP or the same ISP?
e. There is an Internet tool known as whois. The whois tool allows us to determine who owns a domain name. A web-based whois tool is found at <a href="http://whois.domaintools.com/">http://whois.domaintools.com/</a>. This domain is also owned by Verizon according to the web-based whois tool.

```
Registrant:

Verizon Business Global LLC

Verizon Business Global LLC

One Verizon Way

Basking Ridge NJ 07920

US

domainlegalcontact@verizon.com +1.7033513164 Fax: +1.7033513669
```

Domain Name: alter.net

To summarize, Internet traffic starts at a home PC and travels through the home router (hop 1). It then connects to the ISP and travels through its network (hops 2-7) until it arrives at the remote server (hop 8). This is a relatively unusual example in which there is only one ISP involved from start to finish. It is typical to have two or more ISP involved as displayed in the following examples.

f. Now examine an example that involves Internet traffic crossing multiple ISPs. Below is the tracert for www.afrinic.net:

```
C:\>tracert www.afrinic.net
Tracing route to www.afrinic.net [196.216.2.136]
over a maximum of 30 hops:
       1 ms
 1
                <1 ms
                         <1 ms dslrouter.westell.com [192.168.1.1]
                                10.18.20.1
       39 ms
                38 ms
                         37 ms
 2
      40 ms
                         39 ms
                                G4-0-0-2204.ALBYNY-LCR-02.verizon-gni.net [130.8
                38 ms
 3
 .197.182]
      44 ms
                         43 ms so-5-1-1-0.NY325-BB-RTR2.verizon-gni.net [130.81
                43 ms
 4
 22.461
 5
      43 ms
                43 ms
                         42 ms 0.so-4-0-0.XT2.NYC4.ALTER.NET [152.63.9.249]
                                0.ae4.BR3.NYC4.ALTER.NET [152.63.16.185]
 6
       43 ms
                71 ms
                         43 ms
                                te-7-3-0.edge2.NewYork2.level3.net [4.68.111.137
  7
       47 ms
                47 ms
                         47 ms
      43 ms
                         43 ms vlan51.ebr1.NewYork2.Level3.net [4.69.138.222]
 8
                55 ms
 9
      52 ms
                51 ms
                         51 ms ae-3-3.ebr2.Washington1.Level3.net [4.69.132.89]
 10
      130 ms
               132 ms
                        132 ms ae-42-42.ebr2.Paris1.Level3.net [4.69.137.53]
      139 ms
               145 ms
                        140 ms ae-46-46.ebr1.Frankfurt1.Level3.net [4.69.143.13
11
7]
12
                        152 ms_ae-91-91.csw4.Frankfurt1.Level3.net [4.69.140.14
      148 ms
               140 ms
13
     144 ms
               144 ms
                        146 ms ae-92-92.ebr2.Frankfurt1.Level3.net [4.69.140.29
14
                        150 ms ae-23-23.ebr2.London1.Level3.net [4.69.148.193]
     151 ms
               150 ms
 15
     150 ms
               150 ms
                        150 ms ae-58-223.csw2.London1.Level3.net [4.69.153.138]
16
                        156 ms_ae-227-3603.edge3.London1.Level3.net [4.69.166.1
     156 ms
               156 ms
541
17
               159 ms
                        160 ms 195.50.124.34
      157 ms
18
      353 ms
               340 ms
                        341 ms
                                168.209.201.74
19
      333 ms
               333 ms
                        332 ms
                                csw4-pk1-gi1-1.ip.isnet.net [196.26.0.101]
                                196.37.155.180
20
      331 ms
               331 ms
                        331 ms
21
                        318 ms
                                fa1-0-1.ar02.jnb.afrinic.net [196.216.3.132]
      318 ms
               316 ms
22
     332 ms
               334 ms
                        332 ms 196.216.2.136
Trace complete.
```

What happens at hop 7? Is level3.net the same ISP as hops 2-6, or a different ISP? Use the whois tool to answer this question.

What happens in hop 10 to the amount of time it takes for a packet to travel between Washington D.C. and Paris, as compared with the earlier hops 1-9?

What happens in hop 18? Do a whois lookup on 168.209.201.74 using the whois tool. Who owns this network?

g. Type tracert www.lacnic.net.

```
C:\>tracert www.lacnic.net
Tracing route to www.lacnic.net [200.3.14.147]
over a maximum of 30 hops:
 1
       <1 ms
                <1 ms
                         <1 ms
                                dslrouter.westell.com [192.168.1.1]
 2
       38 ms
                38 ms
                         37 ms
                                10.18.20.1
       38 ms
                38 ms
                         39 ms
                                G3-0-9-2204.ALBYNY-LCR-02.verizon-gni.net [130.8
 3
.196.190]
       42 ms
                         42 ms so-5-1-1-0.NY325-BB-RTR2.verizon-gni.net [130.81
 4
                43 ms
22.461
       82 ms
                47 ms
                         47 ms 0.ae2.BR3.NYC4.ALTER.NET [152.63.16.49]
 5
                47 ms
                         56 ms 204.255.168.194
 6
      46 ms
      157 ms
               158 ms
                        157 ms ge-1-1-0.100.gw1.gc.registro.br [159.63.48.38]
 7
 8
      156 ms
               157 ms
                        157 ms xe-5-0-1-0.core1.gc.registro.br [200.160.0.174]
 9
      161 ms
               161 ms
                        161 ms xe-4-0-0-0.core2.nu.registro.br [200.160.0.164]
10
      158 ms
               157 ms
                        157 ms
                                ae0-0.ar3.nu.registro.br [200.160.0.249]
                                gw02.lacnic.registro.br [200.160.0.213]
11
      176 ms
               176 ms
                        170 ms
12
      158 ms
               158 ms
                        158 ms
                                200.3.12.36
13
      157 ms
               158 ms
                        157 ms
                                200.3.14.147
Trace complete.
```

What happens in hop 7?

# Part 3: Trace a Route to a Remote Server Using Web-Based and SoftwareTools

#### Step 1: Use a web-based traceroute tool.

a. Using <u>http://www.subnetonline.com/pages/network-tools/online-tracepath.php</u> to trace the route to the following websites:

www.cisco.com

www.afrinic.net

Capture and save the output in Notepad.

How is the traceroute different when going to <u>www.cisco.com</u> from the command prompt (see Part 1) rather than from the online website? (Your results may vary depending upon where you are located geographically, and which ISP is providing connectivity to your school.)

Compare the tracert from Part 1 that goes to Africa with the tracert that goes to Africa from the web interface. What difference do you notice?

Some of the traceroutes have the abbreviation asymm in them. Any guesses as to what this means? What is its significance?

#### Step 2: Use VisualRoute Lite Edition

VisualRoute is a proprietary traceroute program that can display the tracing path results graphically.

a. Please download the VisualRoute Lite Edition from the following link if it is not already installed:

http://www.visualroute.com/download.html

If you have any trouble downloading or installing VisualRoute, ask your instructor for assistance. Ensure that you download the Lite Edition.

- b. Using VisualRoute 2010 Lite Edition, trace the routes to <u>www.cisco.com</u>.
- c. Record the IP addresses in the path in Notepad.

VisualRo	ute 2010 - Lite Edition				X
File Edit O	ptions Maps Tools Help				
Test to www.	.cisco.com				race
Start Vie	ews: 🥃 🚯 <u>vs</u> 🖽 🌫 🕲 🗝				
Traceroute	e to www.cisco.com				0 区
Target Informati	ion		Route Informatio	n	
То	www.cisco.com (23.1.144.170)		Analysis	In general this route offers a good throughput.	*
Location	Cambridge, MA, USA	-		with hops responding on average within 39ms.	=
Network	Not available in free edition		RTT	42 2ms / 97ms	-
RTT	53.0ms / 50ms / 57ms		avg,max	42.2.110 / 0/1110	
avg,min,max		Ŧ	Packet Loss	0.0% / 0%	*
				1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 -	
DTT me	e to www.cisco.com				6
INTERIS .				T	
90			_		
80			_		
70					
				152 63 21 14	
60-				152.63 17.109	
				152.63.9.249	4.170
50-					
1.000	1	30.81.15	1.1 130.81.22.4	60°	
40-	10.18.20.1 130.81.196.188		@**	1	
100	₫ <b>()</b> ġ				
20	1				
000	/				
20	/				
4.0	1				
10	/				
192.16	38117 19216811				
0-					

# Part 4: Compare Traceroute Results

Compare the traceroute results to <u>www.cisco.com</u> from Parts 2 and 3.

#### Step 1: List the path to www.cisco.com using tracert.

Step 2: List the path to <u>www.cisco.com</u> using the web-based tool on subnetonline.com.

Step 3: List the path to <u>www.cisco.com</u> using VisualRoute Lite edition.

Did all the traceroute utilities use the same paths to www.cisco.com? Why or Why not?

#### Reflection

Having now viewed traceroute through three different tools (tracert, web interface, and VisualRoute), are there any insights that using VisualRoute provided that the other two tools did not?

# 1.4.4.3 Lab - Researching IT and Networking Job Opportunities

### **Objectives**

#### Part 1: Research Job Opportunities

- Identify the current networking jobs that are in demand.
- Explain the value of Cisco certifications in the job market.

#### Part 2: Reflect on Research

- Identify current hiring trends in IT/networking.
- Identify future networking career certifications and skills.
- Identify additional networking career paths.

#### **Background / Scenario**

Jobs in Information Technology (IT) and computer networking continue to grow. Most employers require some form of industry standard certification, degree, or other qualifications from their potential employees, especially those with limited experience. The Cisco CCNA certification is a known and established entry level networking certification that is respected in the industry. There are additional levels and kinds of Cisco certifications that one can attain, and each certification may enhance employment opportunities as well as salary range.

In this lab, you will do some targeted job searching on the web, to find what types of IT and computer networking jobs are available; what kinds of skills and certifications you will need; and the salary ranges associated with the various job titles.

#### **Required Resources**

• Device with Internet access

# Part 1: Research Job Opportunities

In Part 1, you will use a web browser to visit the popular job listing web sites monster.com and salary.com.

#### Step 1: Open a web browser and go to a job listing website.

In the URL address bar type in <u>http://monster.com</u> and press Enter.

Note: For job listings outside of the US, use the following link to search for your country:

http://www.monster.com/geo/siteselection/

#### Step 2: Search for networking related jobs.

a. Type the word *Network* in the Job title box. Notice that the website offers context sensitive suggestions based on the keywords provided. Either click on, or finish typing the words, *Network Administrator* and click the **SEARCH** button (see image below).



b. Notice the search results:

<u>Home Resume</u> Jobs <u>Career Tools</u> <u>Adv</u>	<u>vice Communities</u>		<u>Join Us</u> o
monster Network Administrator	Any Skills or K	eywords in	Any Loo
f Sign in with facebook	Find your inside cont	nections	(
358 Network Administrator jobs matched	your search		
,//	Advanced Search	Sort by relevance -	

<b>♦</b> ⇒ 🕑	Jobsearch.monster.com/search/Network-Administrator_5					
	Sr. Network Systems Administrator - LAN/WAN systems, SaaS, Junip CyberCoders - \$80,000 - \$110,000 Today	Manhattan, NY	See who you know			
	LAN Administrator - TCP/IP, VPN, Network Security CyberCoders • \$40,000 - \$50,000 Today	Appleton, WI	See who you know			
	Network Administrator - Windows, Linux, Cisco, Exchange, VMWare CyberCoders • \$75,000 - \$90,000 Today	Philadelphia, PA	See who you know			
	Retail Manager Love's Travel Stops & Country St Featured Job	Wamsutter, WY				
	Earn The Degree That's Right For You! Advance your career by going back to school. Find out what administrative program is best for you. Featured Opportunity	Campus or Online Programs				
	Network Administrator - Windows environment - Start-up Company CyberCoders • \$70,000 - \$85,000 Today	Waltham, MA	See who you know			
	Texas - Network Administrator - Telecom Administrator CyberCoders - \$60,000 - \$100,000	Beilmead, TX	See who you			

- c. Now focus your search by adding terms to the keywords field box. Try terms like Cisco CCNA, CCNP, CCNA Security, CCNA Voice, etc.
- d. Now try refining your search by adding in different geographical locations. Did you find jobs in the locations you entered?
- e. Try searching a different website. Go to <u>http://salary.com</u> and click the **Job Search** menu bar button.
   **Note**: For salary listings outside of the US, use the following link to search for your country: <u>http://www.payscale.com/rccountries.aspx</u>



f. Now add a search term like *Information Technology* to the job title field box and click **Submit**.

you're more	than just a salary	Enter a job title	- P P	the second	the local data in the local and the
Calment			Lin	ter a city or p	ostal code
Salary	Job Search	Education	Career Develop	pment	Work &
rch Job Openii	igs Sea	Title:			
Evaluation Too		rmation Technology			
Alert Emails	En	ter a city or postal code			
	Search 15 Twe rch Job Openir Evaluation Too Alert Emails	Search 15 Tweet 1 2+1 6 rch Job Openings Sea Evaluation Tool Alert Emails	Search 15 Tweet {1 2+1 6 in share 2 rch Job Openings Evaluation Tool Alert Emails Search Job Openings Job Title: Information Technology Location: Enter a city or postal code	Search          I5       Tweet {1       Image: Constraint of the search of	Search   15   Tweet {1   2   Information Technology   Location:   Enter a city or postal code

g. In the image below, note the large number of matching search results. There are also easy to use tools for refining your search, in the column to the left.



h. Spend some time searching for jobs and looking through the search results. Take note of what skills are required for different job titles and the range of starting salaries.

# Part 2: Reflect on Research

In Part 2, you answer questions based on your research findings.

- a. What job titles did you search for?
- b. What skills or certifications were required?
- c. Did you find any jobs that you previously did not know existed? If so, what were they?

d. Did you find any jobs that you are interested in? If so, which ones and what skills or certifications do they require?

# **1.5.1.1 Draw Your Concept of the Internet Now**

# Objectives

#### Identify the common components of a network.

In this activity, you will illustrate how concepts from Chapter 1 are applied to show how network devices connect to and throughout the Internet. After reflecting on your home or small-business topology, you will become familiar with using the device icons and knowledge needed to visualize network connectivity through the remaining network courses.

### **Background / Scenario**

In this activity, you will use the knowledge you have acquired throughout Chapter 1, and the modeling activity document that you prepared at the beginning of this chapter. You may also refer to the other activities completed in this chapter, including Packet Tracer activities.

Draw a map of the Internet as you see it now. Use the icons presented in the chapter for media, end devices, and intermediary devices.

In your revised drawing, you may want to include some of the following:

- WANs
- LANs
- Cloud computing
- Internet Service Providers (tiers)

Save your drawing in hard-copy format. If it is an electronic document, save it to a server location provided by your instructor. Be prepared to share and explain your revised work in class.

#### **Required Resources**

- Beginning of chapter modeling activity drawing
- Packet Tracer (may be optional if students sketch their own drawing)
- Paper and pencils or pens

#### Reflection

1. After completing Chapter 1, are you more aware of the devices, cabling, and physical components of a smallto-medium size network? Explain your answer.

# **Modeling Activity Graphic Representation**

# 2.0.1.2 It Is Just an Operating System!

# Objectives

#### Describe the command structure of Cisco IOS software

In this activity, you will recognize that text commands used in command line interfaces are intentionally chosen from spoken language. Text commands are often abbreviated, or otherwise simplified in their syntax, to keep the resulting command set concise. They may be grouped into context modes that simplify their usage. Configuring a device using written commands is similar to giving out short orders verbally. The commands are executed by the operating system and the actual process is performed by the device.

#### Background/Scenario

Imagine that you are employed as an engineer for a car manufacturing company. The company is currently working on a new car model. This model will have selected functions that can be controlled by the driver giving specific voice commands.

You must design the set of commands used by this voice-activated control system.

The functions of the car that can be controlled by voice commands are:

- Lights
- Wipers
- Radio
- Telephone set
- Air conditioning
- Ignition

Your task is to devise a simple set of spoken commands that will be used to control these systems and identify how they are going to be executed.

#### **Required Resources**

Paper and pencils or pens, or computer

#### Reflection

1. How can devising a set of voice commands assist in operating a vehicle? How could these same commands be used on a computer or network operating system?

# 2.1.4.9 Lab - Establishing a Console Session with Tera Term

# Topology



### **Objectives**

#### Part 1: Access a Cisco Switch through the Serial Console Port

- Connect to a Cisco switch using a serial console cable.
- Establish a console session using a terminal emulator, such as Tera Term.

#### Part 2: Display and Configure Basic Device Settings

- Use **show** commands to display device settings.
- Configure the clock on the switch.

#### Part 3: (Optional) Access a Cisco Router Using a Mini-USB Console Cable

Note: Users on Netlab or other remote access equipment should complete only Part 2.

#### **Background / Scenario**

Various models of Cisco routers and switches are used in networks of all types. These devices are managed using a local console connection or a remote connection. Nearly all Cisco devices have a serial console port to which you can connect. Some newer models, such as the 1941 Integrated Services Router (ISR) G2 used in this lab, also have a USB console port.

In this lab, you will learn how to access a Cisco device via a direct local connection to the console port, using a terminal emulation program, Tera Term. You will also learn how to configure the serial port settings for the Tera Term console connection. After you have established a console connection with the Cisco device, you can display or configure device settings. You will only display settings and configure the clock with this lab.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 ISRs with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of the lab for the correct interface identifiers.

**Note**: Make sure that the switch and router have been erased and have no startup configuration. If you are unsure, contact your instructor.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS software, release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Rollover (DB-9 to RJ-45) console cable to configure the switch or router via the RJ-45 console port
- Mini-USB cable to configure the router via the USB console port

# Part 1: Access a Cisco Switch through the Serial Console Port

You will connect a PC to a Cisco switch using a rollover console cable. This connection will allow you to access the command line interface (CLI) and display settings or configure the switch.

#### Step 1: Connect a Cisco switch and computer using a rollover console cable.

- a. Connect the rollover console cable to the RJ-45 console port of the switch.
- b. Connect the other cable end to the serial COM port on the computer.

**Note**: Serial COM ports are no longer available on most computers today. A USB-to-DB9 adapter can be used with the rollover console cable for console connection between the computer and a Cisco device. These USB-to-DB9 adapters can be purchased at any computer electronics store.

**Note**: If using a USB-to-DB9 adapter to connect to the COM port, you may be required to install a driver for the adapter provided by the manufacturer on your computer. To determine the COM port used by the adapter, please see Part 3 Step 4. The correct COM port number is required to connect to the Cisco IOS device using a terminal emulator in Step 2.



c. Power up the Cisco switch and computer if these devices are not already on.

#### Step 2: Configure Tera Term to establish a console session with the switch.

Tera Term is a terminal emulation program. This program allows you to access the terminal output of the switch. It also allows you to configure the switch.

a. Start Tera Term by clicking the **Windows Start** button located in the task bar. Locate **Tera Term** under **All Programs**.

**Note**: If the program is not installed on the system, Tera Term can be downloaded from the following link by selecting **Tera Term**:

http://logmett.com/index.php?/download/free-downloads.html

b. In the New Connection dialog box, click the **Serial** radio button. Verify that the correct COM port is selected and click **OK** to continue.

📜 Tera Term - [disconnected] ¥T		
File Edit Setup	connection	
© тср <u>и</u> р	Hos <u>t</u> : myhost.example.com ✓ History Service: C Telnet TCP port#: 22 © SSH SSH version: SSH2 ▼ C Other Protocol: UNSPEC ▼	
© <u>Serial</u>	Po <u>r</u> t: COM1: Communications Port (COM1) <b>v</b> OK Cancel <u>H</u> elp	T

c. From the Tera Term **Setup** menu, choose the **Serial port...** to verify the serial settings. The default parameters for the console port are 9600 baud, 8 data bits, no parity, 1 stop bit, and no flow control. The Tera Term default settings match the console port settings for communications with the Cisco IOS switch.

💯 COM1:9600baud - Te	ra Term VT			
File Edit Setup Contro	Tera Term: Serial port s	etup	×	
	Port:	СОМ1 -	ок	<b></b>
	Baud rate:	9600 💌		
	Data:	8 bit 💌	Cancel	
	Parity:	none 💌		
	Stop:	1 bit 💌	Help	
	Flow control:	none 💌		
	Transmit dela	y c/char 0 ms	ec/line	

d. When you can see the terminal output, you are ready to configure a Cisco switch. The following console example displays the terminal output of the switch while it is loading.



# Part 2: Display and Configure Basic Device Settings

In this section, you are introduced to the user and privileged executive modes. You will determine the Internetwork Operating System (IOS) version, display the clock settings, and configure the clock on the switch.

#### Step 1: Display the switch IOS image version.

a. After the switch has completed its startup process, the following message displays. Enter **n** to continue.

Would you like to enter the initial configuration dialog? [yes/no]:  ${f n}$ 

**Note**: If you do not see the above message, please contact your instructor to reset your switch to the initial configuration.

b. While you are in the user EXEC mode, display the IOS version for your switch.

```
Switch> show version
Cisco IOS Software, C2960 Software (C2960-LANBASEK9-M), Version 15.0(2)SE, RELEASE
SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2012 by Cisco Systems, Inc.
Compiled Sat 28-Jul-12 00:29 by prod_rel_team
ROM: Bootstrap program is C2960 boot loader
BOOTLDR: C2960 Boot Loader (C2960-HBOOT-M) Version 12.2(53r)SEY3, RELEASE SOFTWARE
(fc1)
Switch uptime is 2 minutes
System returned to ROM by power-on
System image file is "flash://c2960-lanbasek9-mz.150-2.SE.bin"
<output omitted>
Which IOS image version is currently in use by your switch?
```

#### Step 2: Configure the clock.

As you learn more about networking, you will see that configuring the correct time on a Cisco switch can be helpful when you are troubleshooting problems. The following steps manually configure the internal clock of the switch.

a. Display the current clock settings.

Switch> show clock \*00:30:05.261 UTC Mon Mar 1 1993

b. The clock setting is changed in the privileged EXEC mode. Enter the privileged EXEC mode by typing **enable** at the user EXEC mode prompt.

Switch> enable

c. Configure the clock setting. The question mark (?) provides help and allows you to determine the expected input for configuring the current time, date, and year. Press Enter to complete the clock configuration.

```
Switch# clock set ?
   hh:mm:ss Current Time
Switch# clock set 15:08:00 ?
   <1-31> Day of the month
   MONTH Month of the year
Switch# clock set 15:08:00 Oct 26 ?
   <1993-2035> Year
Switch# clock set 15:08:00 Oct 26 2012
Switch#
*Oct 26 15:08:00.000: %SYS-6-CLOCKUPDATE: System clock has been updated from 00:31:43
UTC Mon Mar 1 1993 to 15:08:00 UTC Fri Oct 26 2012, configured from console by
   console.
```

d. Enter the show clock command to verify that the clock setting was updated.

Switch# show clock 15:08:07.205 UTC Fri Oct 26 2012

# Part 3: (Optional) Access a Cisco Router Using a Mini-USB Console Cable

If you are using a Cisco 1941 router or other Cisco IOS devices with a mini-USB console port, you can access the device console port using a mini-USB cable connected to the USB port on your computer.

**Note**: The mini-USB console cable is the same type of mini-USB cables that are used with other electronics devices, such as USB hard drives, USB printers, or USB hubs. These mini-USB cables can be purchased through Cisco Systems, Inc. or other third-party vendors. Please verify that you are using a mini-USB cable, not a micro-USB cable, to connect to the mini-USB console port on a Cisco IOS device.



**Note**: You must use either the USB port or the RJ-45 port, and not both simultaneously. When the USB port is used, it takes priority over the RJ-45 console port used in Part 1.

#### Step 1: Set up the physical connection with a mini-USB cable.

- a. Connect the mini-USB cable to the mini-USB console port of the router.
- b. Connect the other cable end to a USB port on the computer.
- c. Power up the Cisco router and computer, if these devices are not already on.



- 1) USB 5-pin mini Type-B console port
- 2) USB 5-pin mini Type-B to USB Type-A Console Cable
- 3) USB Type-A connector

#### Step 2: Verify that the USB console is ready.

If you are using a Microsoft Windows-based PC and the USB console port LED indicator (labeled EN) does not turn green, please install the Cisco USB console driver.

For a Microsoft Windows-based PC connecting to a Cisco IOS device with a USB cable, a USB driver must be installed prior to use. The driver can be found on <u>www.cisco.com</u> with the related Cisco IOS device. The USB driver can be downloaded from the following link:

http://www.cisco.com/cisco/software/release.html?mdfid=282774238&flowid=714&softwareid=282855122&rel ease=3.1&relind=AVAILABLE&rellifecycle=&reltype=latest

Note: You must have a valid Cisco Connection Online (CCO) account to download this file.

**Note**: This link is related to the Cisco 1941 router; however, the USB console driver is not Cisco IOS devicemodel specific. This USB console driver only works with Cisco routers and switches. The computer requires a reboot after finishing the installation of the USB driver. **Note**: After the files are extracted, the folder contains instructions for installation and removal and necessary drivers for different operating systems and architectures. Please choose the appropriate version for your system.

When the LED indicator for the USB console port has turned green, the USB console port is ready for access.

#### Step 3: (Optional) Enable the COM port for the Windows 7 PC.

If you are using a Microsoft Windows 7 PC, you may need to perform the following steps to enable the COM port:

- a. Click the Windows Start icon to access the Control Panel.
- b. Open the Device Manager.
- c. Click the **Ports (COM & LPT)** tree link to expand it. The **Cisco Virtual Comm Port00** icon displays with a yellow exclamation point attached.



- d. To resolve the issue, right-click the **Cisco Virtual Comm Port00** icon and choose **Update Driver Software**.
- e. Choose Browse my computer for driver software.

🖡 Update Driver Software - Cisco Virtual Comm Port00	×
🕜 📱 Update Driver Software - Cisco Virtual Comm Port00	
How do you want to search for driver software?	
Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software for yo device, unless you've disabled this feature in your device installation settings.	ur
Browse my computer for driver software Locate and install driver software manually.	
	Cancel

f. Choose Let me pick from a list of device drivers on my computer and click Next.

🏮 Up	date Driver Software - Cisco Virtual Comm Port00	×
0	Update Driver Software - Cisco Virtual Comm Port00	
	Browse for driver software on your computer	
	Search for driver software in this location:	
	C:\Users\user1\Downloads\CDM20802WHQLCertified\i386	
	I Include subfolders	
	Let me pick from a list of device drivers on my computer This list will show installed driver software compatible with the device, and all driver software in the same category as the device.	
	Next Cance	

g. Choose the Cisco Serial driver and click Next.

🔋 Update Driver Software - Cisco Virtual Comm Port00					
Θ	Update Driver Software - Cisco Virtual Comm Port00				
	Select the device driver you want to install for this hardware.				
	Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.				
	I✓ Show <u>c</u> ompatible hardware	7			
	Cisco Serial				
	This driver is digitally signed. <u>Have Disk</u> <u>Tell me why driver signing is important</u>	]			
	<u>N</u> ext Cance				

h. The device driver is installed successfully. Take note of the port number assigned at the top of the window. In this sample, COM 6 is used for communication with the router. Click **Close**.



#### Step 4: (Optional) Determine the COM port number.

a. If you need to determine the COM port number, open the Control Panel and select the Device Manager. Search for the Ports (COM & LPT) heading, expand it, and determine the COM port number currently in use. In this example, Cisco Serial (COM 6) was selected for connection to the router because a Cisco USB console driver is in use. If you use a rollover console cable, or an adapter from a different manufacturer, the naming convention reflects this information.



b. Open Tera Term. Click the Serial radio button and choose Port COM6: Cisco Serial (COM 6). This port should now be available for communication with the router. Click OK.

💯 Tera	Term - [disconnecte	a] vī	<u>- 0 ×</u>
File Edu	Tera Term: New conr	ection	
	© TCP/IP	Host: myhost.example.com	P port#: 22 sion: SSH2   cool: UNSPEC
	• Serial	Port: COM6: Cisco Serial (COM6)	м6) <b>т</b> !p
			▼

#### Reflection

- 1. How do you prevent unauthorized personnel from accessing your Cisco device through the console port?
- 2. What are the advantages and disadvantages of using the serial console connection as compared to the USB console connection to a Cisco router or switch?

#### **Router Interface Summary Table**

Router Interface Summary						
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2		
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)		
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 2.3.3.4 Lab - Building a Simple Network

# Topology



# Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
S1	VLAN 1	N/A	N/A	N/A
S2	VLAN 1	N/A	N/A	N/A
PC-A	NIC	192.168.1.10	255.255.255.0	N/A
PC-B	NIC	192.168.1.11	255.255.255.0	N/A

# **Objectives**

#### Part 1: Set Up the Network Topology (Ethernet only)

- Identify cables and ports for use in the network.
- Cable a physical lab topology.

#### Part 2: Configure PC Hosts

- Enter static IP address information on the LAN interface of the hosts.
- Verify that PCs can communicate using the **ping** utility.

#### Part 3: Configure and Verify Basic Switch Settings

- Configure each switch with hostname, local passwords, and login banner.
- Save the running configurations.
- Display the running switch configuration.
- Display the IOS version for the running switch.
- Display the status of the interfaces.

# **Background / Scenario**

Networks are constructed of three major components: hosts, switches, and routers. In this lab, you will build a simple network with two hosts and two switches. You will also configure basic settings including hostname,

local passwords, and login banner. Use **show** commands to display the running configuration, IOS version, and interface status. Use the **copy** command to save device configurations.

You will apply IP addressing for this lab to the PCs to enable communication between these two devices. Use the **ping** utility to verify connectivity.

**Note**: The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs.

**Note**: Make sure that the switches have been erased and have no startup configurations. Refer to Appendix A for the procedure to initialize and reload a switch.

#### **Required Resources**

- 2 Switches (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

# Part 1: Set Up the Network Topology (Ethernet only)

In Part 1, you will cable the devices together according to the network topology.

#### Step 1: Power on the devices.

Power on all devices in the topology. The switches do not have a power switch; they will power on as soon as you plug in the power cord.

#### Step 2: Connect the two switches.

Connect one end of an Ethernet cable to F0/1 on S1 and the other end of the cable to F0/1 on S2. You should see the lights for F0/1 on both switches turn amber and then green. This indicates that the switches have been connected correctly.

#### Step 3: Connect the PCs to their respective switches.

- a. Connect one end of the second Ethernet cable to the NIC port on PC-A. Connect the other end of the cable to F0/6 on S1. After connecting the PC to the switch, you should see the light for F0/6 turn amber and then green, indicating that PC-A has been connected correctly.
- b. Connect one end of the last Ethernet cable to the NIC port on PC-B. Connect the other end of the cable to F0/18 on S2. After connecting the PC to the switch, you should see the light for F0/18 turn amber and then green, indicating that the PC-B has been connected correctly.

#### Step 4: Visually inspect network connections.

After cabling the network devices, take a moment to carefully verify the connections to minimize the time required to troubleshoot network connectivity issues later.

# Part 2: Configure PC Hosts

#### Step 1: Configure static IP address information on the PCs.

a. Click the Windows Start icon and then select Control Panel.

Calculator	Music
Paint >	Computer
XPS Viewer	Control Panel
Windows Fax and Scan	Devices and Printers
Cisco Configuration Professional	Default Programs
Magnifier	Help and Support
All Programs	
Search programs and files	Shut down 🕨
A 8	
N PC A Windows 7 MAP 6	

b. In the Network and Internet section, click the View network status and tasks link.

**Note**: If the Control Panel displays a list of icons, click the drop-down option next to the **View by**: and change this option to display by **Category**.



c. In the left pane of the Network and Sharing Center window, click the **Change adapter settings** link.



d. The Network Connections window displays the available interfaces on the PC. Right-click the Local Area Connection interface and select Properties.

😋 🗢 😰 « Netw 🕨	Netw	ork Connections 🕨 👻	✓ Search Network	Connections	× •
Organize 🔻 Disable this	netw	ork device Diagnose this c	onnection »	₩ <b>-</b> ▼	0
Local Area Connec Unidentified netwo Intel(R) PRO/1000	tion	Local A Disable Status Diagnose Bridge Connections Create Shortcut Delete Rename	rea Connection 2	or 6	

e. Select the Internet Protocol Version 4 (TCP/IPv4) option and then click Properties.

📮 Local Area Connection Properties				
Networking				
Connect using:				
Intel(R) PRO/1000 MT Network Connection				
Configure				
I his connection uses the following items:				
Client for Microsoft Networks				
🗹 📑 Deterministic Network Enhancer				
🗹 🛃 QoS Packet Scheduler				
File and Printer Sharing for Microsoft Networks				
Internet Protocol Version 6 (TCP / IPv6)				
Internet Protocol Version 4 (TCP/IPv4)				
🗹 🚣 Link-Layer Topology Discoursy Mapper 1/0 Driver				
🗹 🛶 Link-Layer Topology Discovery Responder				
Install Uninstall Properties				
Description				
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.				
OK Cancel				

Note: You can also double-click Internet Protocol Version 4 (TCP/IPv4) to display the Properties window.

f. Click the **Use the following IP address** radio button to manually enter an IP address, subnet mask, and default gateway.

Internet Protocol Version 4 (TCP/IPv4) Properties						
General						
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.						
Obtain an IP address automatically						
O Use the following IP address:						
IP address: 192 . 168 . 1 . 10						
Subnet mask: 255 . 255 . 255 . 0						
Default gateway:						
Obtain DNS server address automatically						
O Use the following DNS server addresses:						
Preferred DNS server:						
Alternate DNS server:						
Validate settings upon exit						
OK Cancel						

**Note**: In the above example, the IP address and subnet mask have been entered for PC-A. The default gateway has not been entered, because there is no router attached to the network. Refer to the Addressing Table on page 1 for PC-B's IP address information.

- g. After all the IP information has been entered, click **OK**. Click **OK** on the Local Area Connection Properties window to assign the IP address to the LAN adapter.
- h. Repeat the previous steps to enter the IP address information for PC-B.

#### Step 2: Verify PC settings and connectivity.

Use the command prompt (cmd.exe) window to verify the PC settings and connectivity.

a. From PC-A, click the **Windows Start** icon, type **cmd** in the **Search programs and files** box, and then press Enter.



b. The cmd.exe window is where you can enter commands directly to the PC and view the results of those commands. Verify your PC settings by using the **ipconfig /all** command. This command displays the PC hostname and the IPv4 address information.



c. Type ping 192.168.1.11 and press Enter.



Were the ping results successful?

If not, troubleshoot as necessary.

**Note**: If you did not get a reply from PC-B, try to ping PC-B again. If you still do not get a reply from PC-B, try to ping PC-A from PC-B. If you are unable to get a reply from the remote PC, then have your instructor help you troubleshoot the problem.

# Part 3: Configure and Verify Basic Switch Settings

#### Step 1: Console into the switch.

Using Tera Term, establish a console connection to the switch from PC-A.

#### Step 2: Enter privileged EXEC mode.

You can access all switch commands in privileged EXEC mode. The privileged EXEC command set includes those commands contained in user EXEC mode, as well as the **configure** command through which access to the remaining command modes are gained. Enter privileged EXEC mode by entering the **enable** command.

```
Switch> enable
Switch#
```

The prompt changed from Switch> to Switch# which indicates privileged EXEC mode.

#### Step 3: Enter configuration mode.

Use the configuration terminal command to enter configuration mode.

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
```

The prompt changed to reflect global configuration mode.

#### Step 4: Give the switch a name.

Use the **hostname** command to change the switch name to **S1**.

```
Switch(config) # hostname S1
S1(config) #
```

#### Step 5: Prevent unwanted DNS lookups.

To prevent the switch from attempting to translate incorrectly entered commands as though they were hostnames, disable the Domain Name System (DNS) lookup.

```
S1(config) # no ip domain-lookup
S1(config) #
```

#### Step 6: Enter local passwords.

To prevent unauthorized access to the switch, passwords must be configured.

```
S1(config)# enable secret class
S1(config)# line con 0
S1(config-line)# password cisco
S1(config-line)# login
S1(config-line)# exit
S1(config)#
```

#### Step 7: Enter a login MOTD banner.

A login banner, known as the message of the day (MOTD) banner, should be configured to warn anyone accessing the switch that unauthorized access will not be tolerated.

The **banner motd** command requires the use of delimiters to identify the content of the banner message. The delimiting character can be any character as long as it does not occur in the message. For this reason, symbols, such as the **#**, are often used.

```
S1(config)# banner motd #
Enter TEXT message. End with the character '#'.
Unauthorized access is strictly prohibited and prosecuted to the full extent
of the law. #
S1(config)# exit
S1#
```

#### Step 8: Save the configuration.

Use the **copy** command to save the running configuration to the startup file on non-volatile random access memory (NVRAM).

```
S1# copy running-config startup-config
Destination filename [startup-config]? [Enter]
Building configuration...
[OK]
S1#
```

#### Step 9: Display the current configuration.

The **show running-config** command displays the entire running configuration, one page at a time. Use the spacebar to advance paging. The commands configured in Steps 1 – 8 are highlighted below.

```
S1# show running-config
Building configuration ...
Current configuration : 1409 bytes
1
! Last configuration change at 03:49:17 UTC Mon Mar 1 1993
1
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname S1
1
boot-start-marker
boot-end-marker
!
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
Т
no aaa new-model
system mtu routing 1500
!
1
no ip domain-lookup
```

```
T
<output omitted>
1
banner motd ^C
Unauthorized access is strictly prohibited and prosecuted to the full extent of the
law. ^C
Т
line con 0
 password cisco
login
line vty 0 4
login
line vty 5 15
login
!
end
S1#
```

#### Step 10: Display the IOS version and other useful switch information.

Use the **show version** command to display the IOS version that the switch is running, along with other useful information. Again, you will need to use the spacebar to advance through the displayed information.

```
S1# show version
Cisco IOS Software, C2960 Software (C2960-LANBASEK9-M), Version 15.0(2)SE, RELEASE
SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2012 by Cisco Systems, Inc.
Compiled Sat 28-Jul-12 00:29 by prod rel team
ROM: Bootstrap program is C2960 boot loader
BOOTLDR: C2960 Boot Loader (C2960-HBOOT-M) Version 12.2(53r)SEY3, RELEASE SOFTWARE
(fc1)
S1 uptime is 1 hour, 38 minutes
System returned to ROM by power-on
System image file is "flash:/c2960-lanbasek9-mz.150-2.SE.bin"
This product contains cryptographic features and is subject to United
States and local country laws governing import, export, transfer and
use. Delivery of Cisco cryptographic products does not imply
third-party authority to import, export, distribute or use encryption.
Importers, exporters, distributors and users are responsible for
compliance with U.S. and local country laws. By using this product you
agree to comply with applicable laws and regulations. If you are unable
```

to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: http://www.cisco.com/wwl/export/crypto/tool/stqrg.html

```
If you require further assistance please contact us by sending email to export@cisco.com.
```

cisco WS-C2960-24TT-L (PowerPC405) processor (revision R0) with 65536K bytes of memory. Processor board ID FCQ1628Y5LE Last reset from power-on 1 Virtual Ethernet interface 24 FastEthernet interfaces 2 Gigabit Ethernet interfaces The password-recovery mechanism is enabled.

64K bytes of flash-simulated no	on-volatile configuration memory.
Base ethernet MAC Address	: 0C:D9:96:E2:3D:00
Motherboard assembly number	: 73-12600-06
Power supply part number	: 341-0097-03
Motherboard serial number	: FCQ16270N5G
Power supply serial number	: DCA1616884D
Model revision number	: R0
Motherboard revision number	: A0
Model number	: WS-C2960-24TT-L
System serial number	: FCQ1628Y5LE
Top Assembly Part Number	: 800-32797-02
Top Assembly Revision Number	: A0
Version ID	: V11
CLEI Code Number	: COM3L00BRF
Hardware Board Revision Number	: 0x0A

Switc	h Ports	Model	SW Version	SW Image
*	1 26	<mark>WS-C2960-24TT-L</mark>	<mark>15.0(2)SE</mark>	C2960-LANBASEK9-M

```
Configuration register is 0xF S1#
```

#### Step 11: Display the status of the connected interfaces on the switch.

To check the status of the connected interfaces, use the **show ip interface brief** command. Press the spacebar to advance to the end of the list.

S1# show ip interface	e brief			
Interface	IP-Address	OK? Method	Status	Protocol
Vlan1	unassigned	YES unset	up	up
FastEthernet0/1	unassigned	YES unset	up	up
FastEthernet0/2	unassigned	YES unset	down	down
FastEthernet0/3	unassigned	YES unset	down	down

FastEthernet0/4	unassigned	YES unset	down	down
FastEthernet0/5	unassigned	YES unset	down	down
FastEthernet0/6	unassigned	YES unset	up	up
FastEthernet0/7	unassigned	YES unset	down	down
FastEthernet0/8	unassigned	YES unset	down	down
FastEthernet0/9	unassigned	YES unset	down	down
FastEthernet0/10	unassigned	YES unset	down	down
FastEthernet0/11	unassigned	YES unset	down	down
FastEthernet0/12	unassigned	YES unset	down	down
FastEthernet0/13	unassigned	YES unset	down	down
FastEthernet0/14	unassigned	YES unset	down	down
FastEthernet0/15	unassigned	YES unset	down	down
FastEthernet0/16	unassigned	YES unset	down	down
FastEthernet0/17	unassigned	YES unset	down	down
FastEthernet0/18	unassigned	YES unset	down	down
FastEthernet0/19	unassigned	YES unset	down	down
FastEthernet0/20	unassigned	YES unset	down	down
FastEthernet0/21	unassigned	YES unset	down	down
FastEthernet0/22	unassigned	YES unset	down	down
FastEthernet0/23	unassigned	YES unset	down	down
FastEthernet0/24	unassigned	YES unset	down	down
GigabitEthernet0/1	unassigned	YES unset	down	down
GigabitEthernet0/2	unassigned	YES unset	down	down
S1#				

# Step 12: Repeat Steps 1 to 12 to configure switch S2.

The only difference for this step is to change the hostname to S2.

# Step 13: Record the interface status for the following interfaces.

	S1		S2	
Interface	Status	Protocol	Status	Protocol
F0/1				
F0/6				
F0/18				
VLAN 1				

Why are some FastEthernet ports on the switches are up and others are down?
### Reflection

What could prevent a ping from being sent between the PCs?

Note: It may be necessary to disable the PC firewall to ping between PCs.

### Appendix A: Initializing and Reloading a Switch

#### Step 1: Connect to the switch.

Console into the switch and enter privileged EXEC mode.

```
Switch> enable
Switch#
```

#### Step 2: Determine if there have been any virtual local-area networks (VLANs) created.

Use the **show flash** command to determine if any VLANs have been created on the switch.

```
Switch# show flash
```

```
Directory of flash:/
```

2	-rwx	1919	Mar 1	1993	00:06:33 +	+00:00	private-config.text
3	-rwx	1632	Mar 1	1993	00:06:33 +	+00:00	config.text
4	-rwx	13336	Mar 1	1993	00:06:33 +	+00:00	multiple-fs
5	-rwx	11607161	Mar 1	1993	02:37:06 +	+00:00	c2960-lanbasek9-mz.150-2.SE.bin
6	-rwx	616	Mar 1	1993	00:07:13 +	+00:00	vlan.dat

```
32514048 bytes total (20886528 bytes free)
Switch#
```

#### Step 3: Delete the VLAN file.

a. If the vlan.dat file was found in flash, then delete this file.

Switch# delete vlan.dat

Delete filename [vlan.dat]?

You will be prompted to verify the file name. At this point, you can change the file name or just press Enter if you have entered the name correctly.

b. When you are prompted to delete this file, press Enter to confirm the deletion. (Pressing any other key will abort the deletion.)

```
Delete flash:/vlan.dat? [confirm]
Switch#
```

#### Step 4: Erase the startup configuration file.

Use the **erase startup-config** command to erase the startup configuration file from NVRAM. When you are prompted to remove the configuration file, press Enter to confirm the erase. (Pressing any other key will abort the operation.)

```
Switch# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
```

```
Erase of nvram: complete Switch#
```

#### Step 5: Reload the switch.

Reload the switch to remove any old configuration information from memory. When you are prompted to reload the switch, press Enter to proceed with the reload. (Pressing any other key will abort the reload.)

Switch# **reload** Proceed with reload? [confirm]

**Note**: You may receive a prompt to save the running configuration prior to reloading the switch. Type **no** and press Enter.

System configuration has been modified. Save? [yes/no]: no

#### Step 6: Bypass the initial configuration dialog.

After the switch reloads, you should see a prompt to enter the initial configuration dialog. Type **no** at the prompt and press Enter.

Would you like to enter the initial configuration dialog? [yes/no]: **no** Switch>

# 2.3.3.5 Lab - Configuring a Switch Management Address

# Topology



# Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
S1	VLAN 1	192.168.1.2	255.255.255.0	N/A
PC-A	NIC	192.168.1.10	255.255.255.0	N/A

# **Objectives**

### Part 1: Configure a Basic Network Device

- Cable the network as shown in the topology.
- Configure basic switch settings including hostname, management address, and Telnet access.
- Configure an IP address on the PC.

#### Part 2: Verify and Test Network Connectivity

- Display device configuration.
- Test end-to-end connectivity with ping.
- Test remote management capability with Telnet.
- Save the switch running configuration file.

# **Background / Scenario**

Cisco switches have a special interface, known as a switch virtual interface (SVI). The SVI can be configured with an IP address, commonly referred to as the management address that is used for remote access to the switch to display or configure settings.

In this lab, you will build a simple network using Ethernet LAN cabling and access a Cisco switch using the console and remote access methods. You will configure basic switch settings and IP addressing, and demonstrate the use of a management IP address for remote switch management. The topology consists of one switch and one host using only Ethernet and console ports.

**Note**: The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the available commands and output produced might vary from what is shown in the labs.

**Note**: Make sure that the switch has been erased and has no startup configuration. If you are unsure, contact your instructor.

# **Required Resources**

• 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)

- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- · Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

# Part 1: Configure a Basic Network Device

In Part 1, you will set up the network and configure basic settings, such as hostnames, interface IP addresses, and passwords.

#### Step 1: Cable the network.

- a. Cable the network as shown in the topology.
- b. Establish a console connection to the switch from PC-A.

#### Step 2: Configure basic switch settings.

In this step, you will configure basic switch settings, such as hostname and configuring an IP address for the SVI. Assigning an IP address on the switch is only the first step. As the network administrator, you must specify how the switch will be managed. Telnet and Secure Shell (SSH) are two of the most common management methods; however, Telnet is a very insecure protocol. All information flowing between the two devices is sent in plain text. Passwords and other sensitive information can be easily looked at if captured by a packet sniffer.

a. Assuming the switch had no configuration file stored in nonvolatile random-access memory (NVRAM), you will be at the user EXEC mode prompt on the switch with a prompt of Switch>. Enter privileged EXEC mode.

```
Switch> enable
Switch#
```

- b. Verify a clean configuration file with the show running-config privileged EXEC command. If a configuration file was previously saved, it will have to be removed. Depending on the switch model and IOS version, your configuration may look slightly different. However, there should be no configured passwords or IP address set. If your switch does not have a default configuration, ask your instructor for help.
- c. Enter global configuration mode and assign the switch hostname.

Switch# configure terminal
Switch(config)# hostname S1
S1(config)#

d. Configure the switch password access.

S1(config)# enable secret class
S1(config)#

e. Prevent unwanted Domain Name System (DNS) lookups.

S1(config)# no ip domain-lookup
S1(config)#

- f. Configure a login message-of-the-day (MOTD) banner.
  - S1(config) # banner motd #

```
Enter Text message. End with the character `#'.
Unauthorized access is strictly prohibited. #
```

g. Verify your access setting by moving between modes.

```
S1(config)# exit
S1#
S1#
exit
Unauthorized access is strictly prohibited.
S1>
```

What shortcut keys are used to go directly from global configuration mode to privileged EXEC mode?

h. Return to privileged EXEC mode from user EXEC mode.

```
S1> enable
Password: class
S1#
```

Note: Password will not show up on screen when entering.

i. Enter global configuration mode to set the SVI IP address to allow remote switch management.

```
S1# config t
S1#(config)# interface vlan 1
S1(config-if)# ip address 192.168.1.2 255.255.255.0
S1(config-if)# no shut
S1(config-if)# exit
S1(config)#
```

 Restrict console port access. The default configuration is to allow all console connections with no password needed.

```
S1(config)# line con 0
S1(config-line)# password cisco
S1(config-line)# login
S1(config-line)# exit
S1(config)#
```

k. Configure the virtual terminal (VTY) line for the switch to allow Telnet access. If you do not configure a VTY password, you will not be able to Telnet to the switch.

```
S1(config)# line vty 0 4
S1(config-line)# password cisco
S1(config-line)# login
S1(config-line)# end
S1#
*Mar 1 00:06:11.590: %SYS-5-CONFIG_I: Configured from console by console
```

#### Step 3: Configure an IP address on PC-A.

- a. Assign the IP address and subnet mask to the PC, as shown in the Addressing Table on page 1. The procedure for assigning an IP address on a PC running Windows 7 is described below:
  - 1) Click the Windows Start icon > Control Panel.
  - 2) Click View By: > Category.
  - 3) Choose View network status and tasks > Change adapter settings.
  - 4) Right-click Local Area Network Connection and select Properties.
  - 5) Choose Internet Protocol Version 4 (TCP/IPv4), click Properties > OK.
  - 6) Click the Use the following IP address radio button and enter the IP address and subnet mask.

# Part 2: Verify and Test Network Connectivity

You will now verify and document the switch configuration, test end-to-end connectivity between PC-A and S1, and test the remote management capability of the switch.

#### Step 1: Display the S1 device configuration.

S1# show run

a. Return to your console connection using Tera Term on PC-A to display and verify your switch configuration by issuing the **show run** command. A sample configuration is shown below. The settings you configured are highlighted in yellow. The other configuration settings are IOS defaults.

```
Building configuration ...
Current configuration : 1508 bytes
Т
! Last configuration change at 00:06:11 UTC Mon Mar 1 1993
T
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname S1
T
boot-start-marker
boot-end-marker
1
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
T
no aaa new-model
system mtu routing 1500
!
!
no ip domain-lookup
spanning-tree mode pvst
```

```
spanning-tree extend system-id
!
vlan internal allocation policy ascending
1
!
interface FastEthernet0/1
!
interface FastEthernet0/2
<output omitted>
interface FastEthernet0/24
!
interface GigabitEthernet0/1
!
interface GigabitEthernet0/2
1
interface Vlan1
ip address 192.168.1.2 255.255.255.0
1
ip http server
ip http secure-server
!
banner motd ^C
Unauthorized access is strictly prohibited. ^C
!
line con O
password cisco
login
line vty 0 4
password cisco
 login
line vty 5 15
 login
!
end
```

b. Verify the status of your SVI management interface. Your VLAN 1 interface should be up/up and have an IP address assigned. Notice that switch port F0/6 is also up because PC-A is connected to it. Because all switch ports are initially in VLAN 1, by default, you can communicate with the switch using the IP address you configured for VLAN 1.

-				
Interface	IP-Address	OK? Method	Status	Protocol
Vlan1	192.168.1.2	YES manual	up	up
FastEthernet0/1	unassigned	YES unset	down	down
FastEthernet0/2	unassigned	YES unset	down	down
FastEthernet0/3	unassigned	YES unset	down	down
FastEthernet0/4	unassigned	YES unset	down	down
FastEthernet0/5	unassigned	YES unset	down	down
FastEthernet0/6	unassigned	YES unset	up	up

#### S1# show ip interface brief

FastEthernet0/7	unassigned	YES unset	down	down
FastEthernet0/8	unassigned	YES unset	down	down
FastEthernet0/9	unassigned	YES unset	down	down
FastEthernet0/10	unassigned	YES unset	down	down
FastEthernet0/11	unassigned	YES unset	down	down
FastEthernet0/12	unassigned	YES unset	down	down
FastEthernet0/13	unassigned	YES unset	down	down
FastEthernet0/14	unassigned	YES unset	down	down
FastEthernet0/15	unassigned	YES unset	down	down
FastEthernet0/16	unassigned	YES unset	down	down
FastEthernet0/17	unassigned	YES unset	down	down
FastEthernet0/18	unassigned	YES unset	down	down
FastEthernet0/19	unassigned	YES unset	down	down
FastEthernet0/20	unassigned	YES unset	down	down
FastEthernet0/21	unassigned	YES unset	down	down
FastEthernet0/22	unassigned	YES unset	down	down
FastEthernet0/23	unassigned	YES unset	down	down
FastEthernet0/24	unassigned	YES unset	down	down
GigabitEthernet0/1	unassigned	YES unset	down	down
GigabitEthernet0/2	unassigned	YES unset	down	down

#### Step 2: Test end-to-end connectivity.

Open a command prompt window (cmd.exe) on PC-A by clicking the **Windows Start** icon and enter **cmd** into the **Search for programs and files** field. Verify the IP address of PC-A by using the **ipconfig /all** command. This command displays the PC hostname and the IPv4 address information. Ping PC-A's own address and the management address of S1.

a. Ping your own PC-A address first.

C:\Users\NetAcad> ping 192.168.1.10

Your output should be similar to the following screen:

```
C:\Windows\system32\cmd.exe
Microsoft Windows [Uersion 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.
C:\Users\NetAcad>ping 192.168.1.10
Pinging 192.168.1.10 with 32 bytes of data:
Reply from 192.168.1.10: bytes=32 time(1ms TIL=128
Ping statistics for 192.168.1.10:
Packets: Sent = 4, Received = 4, Lost = Ø (0% loss),
Approximate round trip times in milli-seconds:
Minimum = Øms, Maximum = Øms, Average = Øms
C:\Users\NetAcad>_
```

b. Ping the SVI management address of S1.

C:\Users\NetAcad> ping 192.168.1.2

Your output should be similar to the following screen. If ping results are not successful, troubleshoot the basic device configurations. You should check both the physical cabling and IP addressing, if necessary.

C:\Users\NetAcad> C:\Users\NetAcad>ping 192.168.1.2 Pinging 192.168.1.2 with 32 bytes of data: Request timed out. Reply from 192.168.1.2: bytes=32 time=2ms TTL=255 Reply from 192.168.1.2: bytes=32 time<2ms TTL=255 Reply from 192.168.1.2: bytes=32 time<1ms TTL=255 Ping statistics for 192.168.1.2: Packets: Sent = 4, Received = 3, Lost = 1 (25% loss), Approximate round trip times in milli-seconds: Minimum = 0ms, Maximum = 2ms, Average = 1ms C:\Users\NetAcad>\_

#### Step 3: Test and verify remote management of S1.

You will now use Telnet to remotely access the switch S1 using the SVI management address. In this lab, PC-A and S1 reside side by side. In a production network, the switch could be in a wiring closet on the top floor while your management PC is located on the ground floor. Telnet is not a secure protocol. However, you will use it in this lab to test remote access. All information sent by Telnet, including passwords and commands, is sent across the session in plain text. In subsequent labs, you will use Secure Shell (SSH) to remotely access network devices.

**Note**: Windows 7 does not natively support Telnet. The administrator must enable this protocol. To install the Telnet client, open a command prompt window and type **pkgmgr** /iu:"TelnetClient".

```
C:\Users\NetAcad> pkgmgr /iu:"TelnetClient"
```

a. With the command prompt window still open on PC-A, issue a Telnet command to connect to S1 via the SVI management address. The password is **cisco**.

C:\Users\NetAcad> telnet 192.168.1.2

Your output should be similar to the following screen:



b. After entering the **cisco** password, you will be at the user EXEC mode prompt. Type **enable** at the prompt. Enter the **class** password to enter privileged EXEC mode and issue a **show run** command.

#### Step 4: Save the configuration file.

a. From your Telnet session, issue the copy run start command at the prompt.

```
S1# copy run start
Destination filename [startup-config]? [Enter]
Building configuration ..
S1#
```

b. Exit the Telnet session by typing quit. You will be returned to the Windows 7 command prompt.

### Reflection

Why must you use a console connection to initially configure the switch? Why not connect to the switch via Telnet or SSH?

# 2.4.1.1 Tutor me!

# Objectives

#### Configure initial settings on a network device using the Cisco IOS software.

In this activity, you will use and reinforce your knowledge of the Cisco Internetwork Operating System (IOS) command-line interface (CLI) by explaining it to other students. You will look for different ways to explain the meaning of individual commands. You will also find the optimal grouping of commands to be used when configuring a device to minimize the necessary count of mode changes.

# Background/Scenario

#### (Students will work in pairs. Packet Tracer is required to be used with this activity.)

Assume that a new colleague has asked you for an orientation to the Cisco IOS CLI. This colleague has never worked with Cisco devices before.

You explain the basic CLI commands and structure, because you want your colleague to understand that the CLI is a simple, yet powerful, command language that can be easily understood and navigated.

Use Packet Tracer and one of the activities available in this chapter as a simple network model (for example, Lab Activity 2.3.3.5 LAB – Configuring a Switch Management Address). Focus on these areas:

- While the commands are technical, do they resemble any statements from plain English?
- How is the set of commands organized into subgroups or modes? How does an administrator know which mode he or she is currently using?
- What are the individual commands to configure the basic settings of a Cisco device? How would you explain this command in laymen's terms? Use parallels to real life whenever appropriate.

Suggest how to group different commands together according to their modes so that a minimum number of moves between modes will be needed.

# **Required Resources**

- Packet Tracer
- Any simple network model activity available from Chapter 2

# Reflection

1. After completing Chapter 2, do you feel as though you have a concrete understanding of what the Cisco IOS does and how it operates? What were some of the difficulties you encountered when explaining the basic CLI commands and structure to your colleague? If you were the "new colleague," what would be some of the difficulties that you would have learning the basic CLI commands and structure?

2. Answer the following questions, and discuss your answers with the entire class:

a) While the commands are technical, do they resemble any statements from plain English?

How is the set of commands organized into subgroups or modes? How does an administrator know which mode he or she is currently using?								
What are explain th	the individua	l commands t in laymen's te	o configure erms? Use p	the basic sett arallels to rea	ings of a Cisc al life wheneve	o device? How w er appropriate.	ould	


# 3.0.1.2 Let's just talk about this...

# **Objectives**

# Explain the role of protocols and standards organizations in facilitating interoperability in network communications.

In this activity, you will determine ways to communicate when standards are not present or agreed upon. You will also resolve a communication issue by establishing standards for communication.

# Background/Scenario

You have just purchased a new automobile for your personal use. After driving the car for a week or so, you find that it is not properly functioning.

After discussing the problem with several of your peers, you decide to take it to a highly recommended automotive repair facility. It is the only repair facility located in close proximity to you.

When you arrive at the repair facility, you find that all of the mechanics speak another language. You are having difficulty explaining the automobile's performance problems, but the repairs really need to be done. You are not sure you can drive it back home to research other options.

You must find a way to work with the repair facility to ensure your automobile is properly repaired.

How will you communicate with the mechanics in this firm? Design a communications model to ensure that the car is properly repaired.

### Reflection

1. What steps did you identify as important to communicating your repair request? Justify your answer.

# 3.2.3.6 Lab - Researching Networking Standards

# **Objectives**

### Part 1: Research Networking Standards Organizations

- Gather information about the major networking standards organizations by going on a web surfing treasure hunt.
- Identify important characteristics of some of the organizations.

#### Part 2: Reflect on Internet and Computer Networking Experiences

• Reflect on how the various networking standards organizations enhance our experience of the Internet and computer networking.

# **Background / Scenario**

Using web search engines like Google, research the non-profit organizations that are responsible for establishing international standards for the Internet and the development of Internet technologies.

# **Required Resources**

Device with Internet access

# Part 1: Research Networking Standards Organizations

In Part 1, you will identify some of the major standards organizations and important characteristics, such as the number of years in existence, the size of their membership, the important historical figures, some of the responsibilities and duties, organizational oversight role, and the location of the organization's headquarters.

Use a web browser or websites for various organizations to research information about the following organizations and the people who have been instrumental in maintaining them.

You can find answers to the questions below by searching the following organizational acronyms and terms: ISO, ITU, ICANN, IANA, IEEE, EIA, TIA, ISOC, IAB, IETF, W3C, RFC, and Wi-Fi Alliance.

- 1. Who is Jonathan B. Postel and what is he known for?
- 2. Which two related organizations are responsible for managing the top-level domain name space and the root Domain Name System (DNS) name servers on the Internet?
- 3. Vinton Cerf has been called one of main fathers of the Internet. What Internet organizations did he chair or help found? What Internet technologies did he help to develop?
- 4. What organization is responsible for publishing Request for Comments (RFC)?

#### Lab - Researching Networking Standards

- 5. What do RFC 349 and RFC 1700 have in common?
- 6. What RFC number is the ARPAWOCKY? What is it?
- 7. Who founded the World Wide Web Consortium (W3C)?
- 8. Name 10 World Wide Web (WWW) standards that the W3C develops and maintains?
- 9. Where is the Institute of Electrical and Electronics Engineers (IEEE) headquarters located and what is the significance of its logo?
- 10. What is the IEEE standard for the Wi-Fi Protected Access 2 (WPA2) security protocol?
- 11. Is the Wi-Fi Alliance a non-profit standards organization? What is their goal?
- 12. Who is Hamadoun Touré?
- 13. What is the International Telecommunication Union (ITU) and where is it headquartered?
- 14. Name the three ITU sectors?
- 15. What does the RS in RS-232 stand for and which organization introduced it?

16. What is SpaceWire?

17. What is the mission of the ISOC and where are its headquarters located?

18.	What	organizations	does	the	IAB	oversee?
-----	------	---------------	------	-----	-----	----------

- 19. What organization oversees the IAB?
- 20. When was the ISO founded and where are its headquarters located?

# Part 2: Reflect on Internet and Computer Networking Experiences

Take a moment to think about the Internet today in relation to the organizations and technologies you have just researched. Then answer the following questions.

- 1. How do the Internet standards allow for greater commerce? What potential problems could we have if we did not have the IEEE?
- 2. What potential problems could we have if we did not have the W3C?
- 3. What can we learn from the example of the Wi-Fi Alliance with regard to the necessity of networking standards?

# 3.2.4.7 Lab - Researching RFCs

# **Objectives**

### Part 1: RFC Editor

- Navigate to the RFC Editor.
- Search for RFCs using keywords.
- Find RFCs by status.
- Search for humorous RFCs.

### Part 2: Publishing RFCs

# **Background / Scenario**

Request for Comments (RFCs) were created by Steve Crocker to help record notes on development of Advanced Research Projects Agency Network (ARPANET) in 1969 and eventually evolved into an official collection of memorandum that describes topics that are mainly related to the Internet and the TCP/IP protocol suite. Today the RFCs are managed by the IETF. There are currently over 6,000 RFCs, and the complete list is available at <a href="http://www.ietf.org/download/rfc-index.txt">http://www.ietf.org/download/rfc-index.txt</a>.

In this lab, you will learn how an RFC is published today by IETF. Additionally, you will also identify a few wellknown RFCs that are used in your network. You can also find a few non-technical RFCs that can provide information or engineering humor.

# **Required Resources**

Device with Internet access

# Part 1: RFC Editor

RFCs started as a collection of memorandum on the development of the first Internet (ARPANET). In this collection, only a few RFCs are considered as Internet standards. Most of the RFCs describe experimental protocols. Some of the RFCs are only informational. The main purpose of RFCs is to stimulate comment and discussion.

# Step 1: Navigate to the RFC Editor.

All the published RFCs are available for access at <u>http://www.rfc-editor.org</u>. The RFC Editor is an RFC repository maintained by the IETF.

At the top banner of this page, you can click any of the links, and these links direct you to the different searches, databases, and information. A link to **IETF HOME** is also included within this blue banner.

After an RFC is located, you have access to the full text of the document.

#### Step 2: Search for RFCs using keywords.

a. Open a browser and navigate to <u>http://www.rfc-editor.org</u>. On the RFC Editor Homepage, you can search and retrieve RFCs and other information related to the Internet.



include the meta-data, links to the RFC text itself,

Most recent RFCs published

b. In the **Finding and Retrieving RFCs, etc.** pane, these links can help you search for RFCs using different methods. The **Search for an RFC and its meta-data** link displays a list of RFCs after inputting your search parameters, such as number, author, title, or keyword. The word, **pop**, is used in the following example.

Perform Another Search :				
pop SEARCH Search for : All Fields ▼ Results Per Page: 25 ▼ RFC File: ● ASCII+ ● All PDF	Search : • All • RFC • STD • BCP • FYI         Match : • Prefix • Entire Word         Show Abstract: • On • Off         Show Keywords: • On • Off         Result Order : • Descending • Ascending         RFC Contents Via: • FTP • HTTP			

o Based on your search of [*pop*] in the All Fields field **31** matches were found - Below you will find matching items <u>1 through 25</u>

Number	Title	Author or Ed.	Date	Format	More Info (Obs&Upd)	Status
<u>STD0053</u> <u>RFC1939</u>	Post Office Protocol - Version 3	J. Myers, M. Rose	May 1996	ASCII	Obsoletes <u>RFC1725</u> , Updated by <u>RFC1957</u> , <u>RFC2449</u> , <u>RFC6186</u>	STD
<u>RFC6511</u>	Non-Penultimate Hop Popping Behavior and Out-of-Band Mapping for RSVP-TE Label Switched Paths	Z. Ali, G. Swallow, R. Aggarwal	February 2012	ASCII		PROPOSED STANDARD
<u>RFC6186</u>	Use of SRV Records for Locating Email Submission/Access Services	C. Daboo	March 2011	ASCII	Updates <u>RFC1939,</u> <u>RFC3501</u>	PROPOSED STANDARD
<u>RFC6105</u>	IPv6 Router Advertisement Guard	E. Levy-Abegnoli, G. Van de Velde, C. Popoviciu, J. Mohacsi	February 2011	ASCII		INFORMATIONAL

Look for **Post Office Protocol – Version 3** in the list. The associated RFC number is **RFC 1939**. This RFC is also an Internet standard, as indicated by the STD number in the **Number** column.

After an RFC is published and assigned a number, it cannot be changed and the RFC number is never used again for a newer RFC. For example, in the **More Info** column, RFC 1939 has made the previous RFC 1725 obsolete. The information in RFC 1725 has not been modified, but it has been replaced with the information from RFC 1939. RFC 1939 has been updated by RFC 1957, RFC 2449, and RFC 6186, as indicated in the **More Info** column. If you click any of these links, the full text of the RFC displays.

Refer to the **Status** column and locate the **Proposed Standard** status. They may be technically sound, but require further testing and validation.

Refer to the **Status** column and locate the **Informational** status. Informational RFCs can be anything from technical to humorous. For example, RFC 0035 (Network Meeting) provides an insight into the development of a network protocol in the early days of the Internet.

#### Step 3: Find RFCs by status.

To find a list of RFCs that are either Internet Standards (STD) or by their status, perform the following tasks:

- a. Navigate back to the RFC Editor Homepage.
- b. Click the Official Internet Protocol Standard RFCs link in the left column. You will find a list of official standard RFCs followed by other RFC status lists. Each RFC link leads to the full RFC text.

# **Official Internet Protocol Standards**

This page shows the current definitions of STD and BCP numbers. It also lists those standards-track and BEST CURRENT PRACTICE RFCs that have not been obsoleted, as well as current EXPERIMENTAL and HISTORIC RFCs.

RFC numbers more recent than Nov 2007 are starred.

Results are as of Nov-15-2012					
Standards Ordered by STD #	Standards Ordered by RFC #				
Draft Standards					
Proposed Standards					
Best Current Practice by BCP #	Best Current Practice by RFC #				
Experimental RFCs					
Historic RFCs					

#### Go to RFC Editor home page Return to Finding&Retrieving Page

< STANDARDS Ordered by STD > Back to Top						
Mnemonic	Title	RFC#	STD#			
	[Reserved for Assigned Numbers. See <u>RFC 1700</u> and <u>RFC 3232</u> .]	xxx	2			
	Requirements for Internet Hosts - Communication Layers	1122	3			
	Requirements for Internet Hosts - Application and Support	1123	3			

#### Step 4: Search for humorous RFCs.

Engineering humor can also be found in the RFCs, such as RFC 1300 (Remembrances of Things Past). An Internet search engine can be used to find information on RFCs.

a. Search the Internet for "engineering humor rfc" to see more examples of whimsical RFCs. What did you find?

b.	Search for RFC 2795. What is the subject of this RFC?
	What company does the author of this RFC work for?

# Part 2: Publishing RFCs

The late Dr. Jonathan Postel maintained and managed the archiving of RFCs for 28 years (RFC 2468). Today, RFCs are a collection of documents published and managed by IETF. IETF is a large, open, international community of network designers, operators, vendors, and researchers related to the Internet and the Internet protocol suite.

Anyone can submit a proposal to the RFC Editor for possible publication. The proposal is initially published as an Internet-Draft (I-D). After review by the community and if it is approved by an RFC Editor, it will enter the same publishing process as IETF submission. For more details regarding independent submission, see <a href="http://www.rfc-editor.org/indsubs.html">http://www.rfc-editor.org/indsubs.html</a>.

For proposals that may become Internet Standard or Best Current Practice and some Experimental or Informational RFCs, these submissions are published as Internet-Drafts. The Internet-Drafts are made available for informal review and comments. The Internet-Drafts have no formal status, and they are subject to change or removal at any time. They can be found at <a href="http://www.rfc-editor.org/">http://www.rfc-editor.org/</a>.

- a. Navigate to http://www.rfc-editor.org.
- b. Click **I-D SEARCH** at the top of the Homepage, and then click **SEARCH**. This will display a list of the current Internet-Drafts.



o Based on your search of [] in the *All Fields* field **2149** matches were found - Below you will find matching items *1 through 25* 

Name	Title	Author	Source	Date									
draft-ietf-6lowpan- btle-11	Transmission of IPv6 Packets over BLUETOOTH Low Energy	Johanna Nieminen, Teemu Savolainen, Markus Isomaki, Basavaraj Patil, Zach Shelby, Carles Gomez	6lowpan	12-Oct-12									
<u>draft-ietf-6man-</u> udpzero-07	Applicability Statement for the use of IPv6 UDP Datagrams with Zero Checksums	Gorry Fairhurst, Magnus Westerlund	6man	22-Oct-12									

The list of results provides links to the full text of the I-Ds and other useful information. The **Source** column lists the Working Group with IETF that is responsible for the draft. As an example, **6man** is a Working Group that submitted multiple drafts. To find out more information about this Working Group, click **IETF HOME** at the top of the results page.

c. After arriving at the IETF Homepage, click **WG Charters** in the left column, listed under Working Groups.

The Active IETF Working Groups page displays. The IETF Working Group's (WG) primary function is to develop IETF specifications and guidelines. Many of these specifications and guidelines are intended to become standards or recommendations. By scrolling the page, you see a list of Active Working Groups in different development areas for technology related to networking. The **6man** Working Group can be found listed in the Internet Area. This working group is responsible for maintenance and advancement of the IPv6 protocol specifications and addressing architecture.

d. Click **6man** to view the complete list of current proposals and other information for this Working Group.

After the I-D has received significant community review and is considered useful, stable, and wellunderstood by the community, it should become a Proposed Standard. The full text of the Proposed Standard can be found by searching in the <u>RFC-Editor</u>. The Proposed Standard may become an Internet Standard after significant implementation and successful operational experience.

Note: Only a few RFCs published by IETF will become Internet standards.

### Reflection

- 1. Why are RFCs important for Internet standards and history?
- 2. What are the advantages of RFCs as a collaborative effort?

# 3.3.3.4 Lab - Using Wireshark to View Network Traffic

# Topology



# **Objectives**

Part 1: (Optional) Download and Install Wireshark

# Part 2: Capture and Analyze Local ICMP Data in Wireshark

- Start and stop data capture of ping traffic to local hosts.
- Locate the IP and MAC address information in captured PDUs.

# Part 3: Capture and Analyze Remote ICMP Data in Wireshark

- Start and stop data capture of ping traffic to remote hosts.
- Locate the IP and MAC address information in captured PDUs.
- Explain why MAC addresses for remote hosts are different than the MAC addresses of local hosts.

# **Background / Scenario**

Wireshark is a software protocol analyzer, or "packet sniffer" application, used for network troubleshooting, analysis, software and protocol development, and education. As data streams travel back and forth over the network, the sniffer "captures" each protocol data unit (PDU) and can decode and analyze its content according to the appropriate RFC or other specifications.

Wireshark is a useful tool for anyone working with networks and can be used with most labs in the CCNA courses for data analysis and troubleshooting. This lab provides instructions for downloading and installing Wireshark, although it may already be installed. In this lab, you will use Wireshark to capture ICMP data packet IP addresses and Ethernet frame MAC addresses.

#### **Required Resources**

- 1 PC (Windows 7, Vista, or XP with Internet access)
- Additional PC(s) on a local-area network (LAN) will be used to reply to ping requests.

# Part 1: (Optional) Download and Install Wireshark

Wireshark has become the industry standard packet-sniffer program used by network engineers. This open source software is available for many different operating systems, including Windows, Mac, and Linux. In Part 1 of this lab, you will download and install the Wireshark software program on your PC.

**Note**: If Wireshark is already installed on your PC, you can skip Part 1 and go directly to Part 2. If Wireshark is not installed on your PC, check with your instructor about your academy's software download policy.

#### Step 1: Download Wireshark.

- a. Wireshark can be downloaded from <u>www.wireshark.org</u>.
- b. Click Download Wireshark.



c. Choose the software version you need based on your PC's architecture and operating system. For instance, if you have a 64-bit PC running Windows, choose **Windows Installer (64-bit)**.



After making a selection, the download should start. The location of the downloaded file depends on the browser and operating system that you use. For Windows users, the default location is the **Downloads** folder.

#### Step 2: Install Wireshark.

- a. The downloaded file is named **Wireshark-win64-x.x.x.exe**, where **x** represents the version number. Double-click the file to start the installation process.
- Respond to any security messages that may display on your screen. If you already have a copy of Wireshark on your PC, you will be prompted to uninstall the old version before installing the new version. It is recommended that you remove the old version of Wireshark prior to installing another version. Click Yes to uninstall the previous version of Wireshark.



c. If this is the first time to install Wireshark, or after you have completed the uninstall process, you will navigate to the Wireshark Setup wizard. Click **Next**.



d. Continue advancing through the installation process. Click **I Agree** when the License Agreement window displays.

🔀 Wireshark 1.8.3 (64-bit) Setup	
License Agreement Please review the license terms before installing Wireshark 1.8.3 (64-bit).	
Press Page Down to see the rest of the agreement.	
This text consists of three parts: Part I: Some remarks regarding the license given in Part II: The actual license that covers Wireshark. Part III: Other applicable licenses. When in doubt: Part II/III is the legally binding part, Part I is just there to make it easier for people that are not familiar with the GPLv2.	
If you accept the terms of the agreement, click I Agree to continue. You mus agreement to install Wireshark 1.8.3 (64-bit).	₹ t accept the
Kulisort Install System V2.46     Kack     I Agree	Cancel

e. Keep the default settings on the Choose Components window and click Next.



f. Choose your desired shortcut options and click Next.

Wireshark 1.8.3 (64-bit) Setup	
Select Additional Tasks Which additional tasks should be done?	
Create Shortcuts	apc, atc, bfr, tr1, trace, trc, wpc, wpz,
Nullsoft Install System v2,46 <b></b>	Next > Cancel

g. You can change the installation location of Wireshark, but unless you have limited disk space, it is recommended that you keep the default location.

🕢 Wireshark 1.8.3 (64-bit) Setup	- • •
Choose Install Location Choose the folder in which to install Wireshark 1.8.3 (64-bit).	
Choose a directory in which to install Wireshark.	
Destination Folder	
C: \Program Files\Wireshark	Browse
Space required: 102.4MB Space available: 81.5GB	
Nullsoft Install System v2,46	Next > Cancel
	Currer

- h. To capture live network data, WinPcap must be installed on your PC. If WinPcap is already installed on your PC, the Install check box will be unchecked. If your installed version of WinPcap is older than the version that comes with Wireshark, it is recommend that you allow the newer version to be installed by clicking the **Install WinPcap x.x.x** (version number) check box.
- i. Finish the WinPcap Setup Wizard if installing WinPcap.

🕢 Wireshark 1.8.3 (64-bit) Setup	- • ×
Install WinPcap? WinPcap is required to capture live network data. Should WinPcap be installed	i? 🚺
Currently installed WinPcap version WinPcap 4.1.2	
Install Install WinPcap 4.1.2 If selected, the currently installed WinPcap 4.1.2 will be uninstalled first	t.
What is WinPcap?	
Nullsoft Install System v2.46 — Sack Install	Cancel

j. Wireshark starts installing its files and a separate window displays with the status of the installation. Click **Next** when the installation is complete.

🕜 Wireshark 1.8.3 (64-bit) Setup	
Installation Complete Setup was completed successfully.	
Completed	
Extract: mergecap.html Output folder: C:\Program Files\Wireshark Extract: capinfos.exe Extract: capinfos.html Output folder: C:\Program Files\Wireshark Extract: rawshark.exe Extract: rawshark.html Output folder: C:\Program Files\Wireshark Extract: user-guide.chm Completed	
Nullsoft Install System v2.46 — — — — — — — — — — — — — — — — — — —	k Next > Cancel

k. Click **Finish** to complete the Wireshark install process.



# Part 2: Capture and Analyze Local ICMP Data in Wireshark

In Part 2 of this lab, you will ping another PC on the LAN and capture ICMP requests and replies in Wireshark. You will also look inside the frames captured for specific information. This analysis should help to clarify how packet headers are used to transport data to their destination.

#### Step 1: Retrieve your PC's interface addresses.

For this lab, you will need to retrieve your PC's IP address and its network interface card (NIC) physical address, also called the MAC address.

- a. Open a command window, type **ipconfig /all**, and then press Enter.
- b. Note your PC interface's IP address and MAC (physical) address.



c. Ask a team member for their PC's IP address and provide your PC's IP address to them. Do not provide them with your MAC address at this time.

#### Step 2: Start Wireshark and begin capturing data.

- a. On your PC, click the Windows **Start** button to see Wireshark listed as one of the programs on the pop-up menu. Double-click **Wireshark**.
- b. After Wireshark starts, click Interface List.



Note: Clicking the first interface icon in the row of icons also opens the Interface List.

c. On the Wireshark: Capture Interfaces window, click the check box next to the interface connected to your LAN.

📶 Wireshark: Ca	pture Interfaces				- • •
	Description	IP	Packets	Packets/s	
	Intel(R) PRO/1000 MT Network Connection		19	0	<u>D</u> etails
	Intel(R) 82577LM Gigabit Network Connection	192.168.1.11	47	0	Details
<u>H</u> elp		<u>S</u> tart	Stop	<u>O</u> ptions	<u>C</u> lose

**Note**: If multiple interfaces are listed and you are unsure which interface to check, click the **Details** button, and then click the **802.3 (Ethernet)** tab. Verify that the MAC address matches what you noted in Step 1b. Close the Interface Details window after verifying the correct interface.

📶 Wireshark: Interface Details	
Characteristics Statistics 802.3 (Ethernet	302,11 (WLAN) Task Offload
Characteristics Permanent station address	00:50:56:BE:76:8C
Statistics	00:50:56:BE:76:8C

d. After you have checked the correct interface, click **Start** to start the data capture.

	Wiresharl	k: Cap	ture Interfaces				- • •
			Description	IP	Packets	Packets/s	
		<b>*</b>	Intel(R) PRO/1000 MT Network Connection		19	0	<u>D</u> etails
		<b>1</b>	Intel(R) 82577LM Gigabit Network Connection	192.168.1.11	47	0	<u>D</u> etails
1							
	<u>H</u> elp			Start	Stop	<u>O</u> ptions	<u>C</u> lose

Information will start scrolling down the top section in Wireshark. The data lines will appear in different colors based on protocol.

🗖 Cap	turing from Intel(R) 82577LM Gigabit Network Conn	nection: \Device\NPF_{6179E093-A447-4	-81DF-5E22D08A6F63} [Wireshark 1.8.3 (SVN Rev 45256 from /trunk-1.8)]	
<u>File</u>	<u>E</u> dit <u>V</u> iew <u>G</u> o <u>C</u> apture <u>A</u> nalyze <u>S</u> tatistics	Telephony <u>T</u> ools Internals <u>H</u> elp		
	<b>IN AIN NO X</b> 24 A 1 A			
Filter		<ul> <li>Expression</li> </ul>	ar Apply Save	
No.	Time Source	Destination Pro	ol Length Info	*
	21 2.451962000 cisco_7a:ec:84	Spanning-tree-(for-br:ST	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	Port = 0x8001
	22 3.497376000 10.20.164.21	173.194.79.125 TC	91 [TCP segment of a reassembled PDU]	
	23 3.567094000 173.194.79.125	10.20.164.21 TC	60 xmpp-client > 53588 [ACK] Seq=1 Ack=38 win=1002	Len=0
	24 4.451700000 cisco_7a:ec:84	Spanning-tree-(for-br:SI	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	<pre>Port = 0x8001</pre>
	25 6.451326000 cisco_7a:ec:84	Spanning-tree-(for-br:ST	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	<pre>Port = 0x8001</pre>
	26 8.451225000 cisco_7a:ec:84	Spanning-tree-(for-br:ST	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	) Port = 0x8001
	27 10.27736800(10.20.164.21	173.36.12.72 то	55 53964 > 10846 [ACK] Seq=1 Ack=1 Win=63974 Len=1	
	28 10.35963200(173.36.12.72	10.20.164.21 то	66 10846 > 53964 [ACK] Seq=1 Ack=2 Win=513 Len=0 SL	.E=1 SRE=2
	29 10.45232500(cisco_7a:ec:84	Spanning-tree-(for-br:S1	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	) Port = 0x8001
	30 10.94920600(10.20.164.21	171.68.57.53 NE	92 Name query NB UNIDC3<20>	
	31 10.99746700(171.68.57.53	10.20.164.21 NE	98 Name query response, Requested name does not exi	st
	32 10.99758500(10.20.164.21	173.37.115.191 NE	92 Name query NB UNIDC3<20>	
	33 11.08046600(173.37.115.191	10.20.164.21 NE	98 Name query response, Requested name does not exi	st
	34 11.09043000(10.20.164.21	10.20.164.31 NE	92 Name query NB UNIDC3<20>	
	35 11.84043400(10.20.164.21	10.20.164.31 NE	92 Name query NB UNIDC3<20>	
	36 12.45071000(cisco_7a:ec:84	Spanning-tree-(for-br:ST	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	<pre>Port = 0x8001</pre>
	37 12.59048100(10.20.164.21	10.20.164.31 NE	92 Name query NB UNIDC3<20>	
	38 13.34153600(10.20.164.21	171.68.57.53 NE	92 Name query NB UNIDC3<20>	
	39 13.41142100(171.68.57.53	10.20.164.21 NE	98 Name query response, Requested name does not exit	st
	40 13.41151700(10.20.164.21	173.37.115.191 NE	92 Name query NB UNIDC3<20>	
	41 13.49295400(173.37.115.191	10.20.164.21 NE	98 Name query response, Requested name does not exit	st
	42 13. 50250600(10. 20. 164. 21	10.20.164.31 NE	92 Name query NB UNIDC3<20>	
	43 14.25256700(10.20.164.21	10.20.164.31 NE	92 Name query NB UNIDC3<20>	
	44 14.45045300(Cisco_7a:ec:84	Spanning-tree-(for-br:SI	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0	<pre>Port = 0x8001</pre>
_	45 14.69467200(10.20.164.21	192.168.87.9 SF	OC 86 Attribute Request, V1 Transaction ID - 49289	•
۰			III	P. International Provide American Provid
🕀 Fra	ame 1: 66 bytes on wire (528 bits),	66 bytes captured (528 bi	) on interface 0	
🕑 Eth	nernet II, Src: Dell_24:2a:60 (5c:2	26:0a:24:2a:60), Dst: Cisco	a:ec:84 (30:f7:0d:7a:ec:84)	
🗉 Int	ernet Protocol Version 4, Src: 10.	20.164.21 (10.20.164.21),	t: 204.236.230.45 (204.236.230.45)	
🗉 Tra	ansmission Control Protocol, Src Po	ort: 54996 (54996), Dst Por	https (443), Seq: 0, Len: 0	
0000	20 57 04 7 84 5- 26 0- 24 2-	60 08 00 45 00 0 - \c	14 <sup>1</sup> -	
0000	30 T/ UG /a ec 84 5c 26 0a 24 2a	14 a4 15 cc ec 40x8	)"E.	<u>^</u>
0020	e6 2d d6 d4 01 bb dc b2 af 4e 00	00 00 00 80 02	4	=
0030	20 00 8a 09 00 00 02 04 04 ec 01	03 03 02 01 01		
0040	04 02			+
	Intel(R) 825771 M Gigabit Network Connection: \Dev	rice\NPE (6179E093-0447-4EC8-81DE	ckets: 45 Displayed: 45 Marked: 0	file: Default
	intering 02577 EWF organic Network Connection: (Dev	100/14/1_(01/30033-A447*4EC8*81DF	ekeis 45 bispiayeu 45 Markeu V	inc. Deraute

e. This information can scroll by very quickly depending on what communication is taking place between your PC and the LAN. We can apply a filter to make it easier to view and work with the data that is being captured by Wireshark. For this lab, we are only interested in displaying ICMP (ping) PDUs. Type **icmp** in the Filter box at the top of Wireshark and press Enter or click on the **Apply** button to view only ICMP (ping) PDUs.



f. This filter causes all data in the top window to disappear, but you are still capturing the traffic on the interface. Bring up the command prompt window that you opened earlier and ping the IP address that you received from your team member. Notice that you start seeing data appear in the top window of Wireshark again.

🗖 Ca	pturing from Intel(F	R) PRO/1000 MT Net	work Connection [Wireshark 1.6.1	(SVN Rev 38096	from /trunk-1.6)]				• 🕱 .						
<u>F</u> ile	<u>E</u> dit <u>V</u> iew <u>G</u> o	<u>Capture</u> <u>A</u> nalyze	Statistics Telephony Tools	Internals <u>H</u> elp											
		<b>B Z</b> × 2			0,0,0, 🖭	¥ 🗹 🍋	*								
Filter:	Filter: icmp Expression Clear Apply														
No.	Time	Source	Destination	Protocol Le	ength Info										
	11 15.118840	192.168.1.11	192.168.1.12	ICMP	74 Echo (ping)	request	id=0x0001,	seq=21/5376,	tt]=12						
	14 15.119602	192.168.1.12	192.168.1.11	ICMP	74 Echo (ping)	reply	id=0x0001,	seq=21/5376,	tt]=12						
	16 16.127853	192.168.1.11	192.168.1.12	ICMP	74 Echo (ping)	request	id=0x0001,	seq=22/5632,	tt]=12						
	17 16.128679	192.168.1.12	192.168.1.11	ICMP	74 Echo (ping)	reply	id=0x0001,	seq=22/5632,	tt]=12						
	18 17.141897	192.168.1.11	192.168.1.12	ICMP	/4 Echo (ping)	request	1d=0x0001,	seq=23/5888,	tt  =12						
	19 17.145943	192.168.1.12	192.168.1.11	ICMP	74 Echo (ping)	reply	1d=0x0001,	seq=23/5888,	tt  =12						
	21 18.140246	192.168.1.11	192.168.1.12	ICMP	74 Echo (ping)	request	1d=0x0001,	seq=24/6144,	ttl=1/						
	22 10.140/94	192.100.1.12	152.100.1.11	TCHE	/ Leno (pring)	терту	10-000001,	504-24/0144,							
			(												
			C:\Windows\syste	em32\cmd.exe					• 🕺						
					a										
			lunnel adapter	Local Area	Connection* 11:										
			Media State		: Med	lia disco	onnected								
			Connection-	specific DNS	S Suffix . :	- J- T	-14 D4-								
🕀 Er.	ame 11:74 by	/tes on wire (	592 hit Physical Ad	dress.		00-00-00	1-00-00-00-E	) Incertace							
I Et	hernet II. Sr	c: Vmware be:	76:8c ( DHCP Enable	d	No										
I In	ternet Protoc	ol Version 4.	Src: 19 Hutoconfigu	ration Enabl	led : Yes				4						
🕀 In	ternet Contro	ol Message Pro	tocol C:\>												
		-	C:\>ping 192.1	68.1.12					=						
			Pinging 192.16	8.1.12 with	32 bytes of data	.=									
0000	00 50 56 be	f6 db 00 50	56 be 7 Reply from 192	.168.1.12: ]	bytes=32 time=1ms	TTL=128	3								
0010	00 3c 01 ac	00 00 80 01	b5 ad c Reply from 192	168 1 12: 1	Dytes=32 time <ims< td=""><td>TTL=128</td><td>}</td><td></td><td></td></ims<>	TTL=128	}								
0020	1020 01 0c 08 00 4d 46 00 01 00 15 G Reply from 192.168 1.12: bytes=32 time=4ms IIL=128														
0030	01 0C 08 00	40 46 00 01	of 70 7 Reply from 192	.168.1.12: )	bytes=32 time=4ms bytes=32 time<1ms	TTL=128	3								
0040	01 0C 08 00 67 68 69 6a 77 61 62 63	40 46 00 01 6b 6c 6d 6e 64 65 66 67	67 70 7 68 69 Pipe statistic	.168.1.12: )	bytes=32 time=4ms bytes=32 time<1ms 68 1 12:	ŤŤĹ=Ĩ28	} 								
0040	01 0c 08 00 67 68 69 6a 77 61 62 63	4d 46 00 01 6b 6c 6d 6e 64 65 66 67	60 15 6 Reply from 192 6f 70 7 68 69 Ping statistic Packets: S	.168.1.12: ) s for 192.16 ent = 4, Rec	bytes=32 time=4ms bytes=32 time<1ms 68.1.12: ceived = 4, Lost	TTL=128	loss),								

**Note**: If your team member's PC does not reply to your pings, this may be because their PC firewall is blocking these requests. Please see Appendix A: Allowing ICMP Traffic Through a Firewall for information on how to allow ICMP traffic through the firewall using Windows 7.

g. Stop capturing data by clicking the Stop Capture icon.



#### Step 3: Examine the captured data.

In Step 3, examine the data that was generated by the ping requests of your team member's PC. Wireshark data is displayed in three sections: 1) The top section displays the list of PDU frames captured with a summary of the IP packet information listed, 2) the middle section lists PDU information for the frame selected in the top part of the screen and separates a captured PDU frame by its protocol layers, and 3) the bottom section displays the raw data of each layer. The raw data is displayed in both hexadecimal and decimal form.

🗖 Cap	oturing fron	n Intel(R	) PRO/1	000 M	T Netv	vork C	onne	ction	[Wir	esha	rk 1.6	5.1 (SV	/N Rev 380	)96 fr	rom /trunk-1	1.6)]						• <b>×</b>
<u>F</u> ile	<u>E</u> dit <u>V</u> iew	<u>G</u> o	<u>C</u> apture	<u>A</u> na	alyze	<u>S</u> tati	stics	Telep	hony	Ī	ools	<u>I</u> nter	mals <u>H</u> el	lp								
e i	ni 🐏 🎴	<b>i</b>		8 %	2	₽	Q	\$			7	₽		]  (	Ð. Q. 19.	. <b>**</b> *	è	i 🗹 🍕	X			
Filter:	icmp											•	Expression	(	Clear Appl	у						
No.	Time		Source				D	estina	tion				Protocol	Len	ngth Info							_
	11 15.11	8840	192.1	68.1	11			92.1	68.1	12			ICMP		74 Echo	(p1	ing)	request	E 1	id=0x0001,	seq=21/5376,	ttl=1.
	14 15.11	.9602	192.1	.68.1	12		1	92.1	68.1	11	L		ICMP		74 Echo	(pi	ing)	reply	i	id=0x0001,	seq=21/5376,	tt]=12
	16 16.12	27853	192.1	.68.1	.11		1	92.1	68.1	17	2		ICMP		74 Echo	(pi	ng)	request	t i	d=0x0001,	seq=22/5632,	tt]=12
	17 16.12	8679	192.1	.68.1	12		1	92.1	68.1		L		ICMP		74 Echo	(pi	ng)	reply	i	d=0x0001,	seq=22/5632,	tt]=12
	18 17.14	1897	192.1	.68.1	11		1	92.1	68.1	12	2		ICMP		74 Echo	(pi	ng)	request	t i	id=0x0001,	seq=23/5888,	tt]=12
	19 17.14	5943	192.1	.68.1	12		1	92.1	68.1	11	L		ICMP		74 Echo	(pi	ng)	reply	1	d=0x0001,	seq=23/5888,	tt]=12
	21 18.14	0246	192.1	.68.1	11		1	92.1	68.1	12	2		ICMP		74 Echo	(pi	ng)	request	t i	id=0x0001,	seq=24/6144,	tt]=12
	22 18.14	0794	192.1	.68.1	12		1	92.1	68.1	11	L		ICMP		74 Echo	(pi	ng)	reply	i	id=0x0001,	seq=24/6144,	tt]=12
	amo 11.	74 by	tos o	n wir	ra (1	502	hite	) 7	4 b	rt or		optur	ad (50	2 h	i+c)							
Eth	hernet I	I, Sr	c: Int	telCo	or_34	4:92 Src	:1c	(58: 2 16	94:6 8 1	5b:	34:9	)2:10	EU (J) E), DST	: I	ntel_Of:	91:4	8 (0	0:11:11	L:0f	:91:48)		
I Int	ternet C	ontro	1 Mes	sade	Prot	toco	i	2.10	0.1.		(1)			,,	050. 152			(152.	100			
				9-																Mid	dle Section	
0000 0010 0020 0030 0040	00 50 00 3c 01 0c 67 68 77 61	56 be 01 ac 08 00 69 6a 62 63	f6 db 00 00 4d 46 6b 6c 64 65	00 80 500 6d 6d	50 01 01 6e 67	56 b b5 a 00 b 6f a 68 d	De 70 ad c0 L5 61 70 71 59	6 8c 0 a8 1 62 1 72	08 01 63 73	00 0b 64 74	45 c0 65 75	00 a8 66 76	.PV . <mf ghijk wabcde</mf 	P  Imn efg	V.vE abcdet opqrstu hi	F V				Bot	tom Seciton	* 
O Inte	el(R) PRO/1	000 MT	Network	c Conn	nection	n:	Packe	ts: 199	) Disp	laye	d: 8 N	/larked	<del>l</del> : 0							Profile: Defa	ault	.H

a. Click the first ICMP request PDU frames in the top section of Wireshark. Notice that the Source column has your PC's IP address, and the Destination contains the IP address of the teammate's PC you pinged.

Intel(R) PRO/1000 MT Network Connection [Wireshark 1.6.1 (SVN Rev 38096 from /trunk-1.6)]									
<u>F</u> ile	<u>E</u> dit <u>V</u> iew <u>G</u> o	<u>C</u> apture <u>A</u> nalyze	<u>Statistics</u> Telephony <u>T</u> ools	Internals <u>H</u> elp	р				Source
		🖹 🖥 🗶 🔁	占   🔍 🗢 🗼 🐴	<u>↓</u>   E Ę		🖭   🎽 🗵	] 畅 💥   🧱		Jource
Filte	r: icmp			Expression.	Clear Apply				
No.	Time	Source	Destination	Protocol	Length Info				
	5 2.801784	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping) req	uest id=0x0001,	seq=25/6400,	tt]=12
	8 2.802679	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping) rep	ly id=0x0001,	seq=25/6400,	tt]=12
	10 3.816895	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping) req	uest id=0x0001,	seq=26/6656,	tt]=12
	11 3.817540	192.168.1.12	192. <u>168.1</u> .11	ICMP	74 Echo	(ping) rep	<u>ly</u> id=0x0001,	seq=26/6656,	tt]=12
	13 4.831343	(192.168.1.11	192.168.1.12	ICMP	74 Echo	(pinc) req	uest id=0x0001,	seq=27/6912,	tt]=12
	14 4.832006	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping) rep	ly id=0x0001,	seq=27/6912,	tt]=12
	15 5.844858	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping) req	uest id=0x0001,	seq=28/7168,	tt]=12
	16 5.845488	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping) rep	ly id=0x0001,	seq=28/7168,	tt]=12

b. With this PDU frame still selected in the top section, navigate to the middle section. Click the plus sign to the left of the Ethernet II row to view the Destination and Source MAC addresses.

Intel(R) PRO/1000 MT Network Connection [Wireshark 1.6.1 (SVN Rev 38096 from /trunk-1.6)]										
<u>File Edit View Go Capture Analyze Statistics Telephony Iools Internals H</u> elp										
		i i 🖻 🖬 🗙 🔁 d	l 🔍 🗢 🔿 👍	<u>1</u>	€ € @	m   👹	( 🗹 🖪	¥		
Filte	r: icmp			Expression	Clear Apply					
No.	Time	Source	Destination	Protocol I	ength Info					
	5 2.801784	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping)	request	id=0x0001,	seq=25/6400,	tt]=12
	8 2.802679	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping)	reply	id=0x0001,	seq=25/6400,	tt]=12
	10 3.816895	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping)	request	id=0x0001,	seq=26/6656,	tt]=12
	11 3.817540	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping)	reply	id=0x0001,	seq=26/6656,	tt]=12
	13 4.831343	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping)	request	id=0x0001,	seq=27/6912,	tt]=12
	14 4.832006	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping)	reply	id=0x0001,	seq=27/6912,	tt]=12
	15 5.844858	192.168.1.11	192.168.1.12	ICMP	74 Echo	(ping)	request	id=0x0001,	seq=28/7168,	tt]=12
	16 5.845488	192.168.1.12	192.168.1.11	ICMP	74 Echo	(ping)	reply	id=0x0001,	seq=28/7168,	tt]=12
B Frame 13: 74 bytes on wire (592 bits), 74 bytes captured (592 bits)										
<pre>Ethernet II, Src: IntelCor_34:92:1c (58:94:6b:34:92:1c), Dst: Intel_0f:91:48 (00:11:11:0f:91:48)</pre>										
<pre>     B Destination: Intel_0f:91:48 (00:11:11:0f:91:48)     B Source: IntelCor_34:92:1c (58:94:6b:34:92:1c)     Type: IP (0x0800) </pre>										
Internet Protocol version 4, Src: 192.168.1.11 (192.168.1.11), Dst: 192.168.1.12 (192.168.1.12)										
Internet Control Message Protocol										

Does the Source MAC address match your PC's interface?

Does the Destination MAC address in Wireshark match the MAC address that of your team member's?

How is the MAC address of the pinged PC obtained by your PC?

**Note**: In the preceding example of a captured ICMP request, ICMP data is encapsulated inside an IPv4 packet PDU (IPv4 header) which is then encapsulated in an Ethernet II frame PDU (Ethernet II header) for transmission on the LAN.

# Part 3: Capture and Analyze Remote ICMP Data in Wireshark

In Part 3, you will ping remote hosts (hosts not on the LAN) and examine the generated data from those pings. You will then determine what is different about this data from the data examined in Part 2.

#### Step 1: Start capturing data on interface.

a. Click the Interface List icon to bring up the list PC interfaces again.


b. Make sure the check box next to the LAN interface is checked, and then click Start.

wireshark capture interfaces		
Description IP Packets	Packets/s	
Intel(R) PRO/1000 MT Network Connection 19	0	<u>D</u> etails
Intel(R) 82577LM Gigabit Network Connection 192.168.1.11 47	0	<u>D</u> etails
<u>H</u> elp <u>Start</u> Stop	<u>O</u> ptions	<u>C</u> lose

c. A window prompts to save the previously captured data before starting another capture. It is not necessary to save this data. Click **Continue without Saving**.

📶 Wireshark	
	Save capture file before starting a new capture?
	If you start a new capture without saving, your current capture
	data will
	be discarded.
<u>S</u> ave	Continue <u>w</u> ithout Saving <u>C</u> ancel

- d. With the capture active, ping the following three website URLs:
  - 1) www.yahoo.com
  - 2) www.cisco.com
  - 3) www.google.com

```
C:\Vindows\system32\cmd.exe
C:\ping www.yahoo.com
Pinging www.yahoo.com
(72.30.38.140) with 32 bytes of data:
Reply from 72.30.38.140: bytes=32 time(ins TIL=255
Ping statistics for 72.30.38.140:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Mininum = 0ms, Maximum = 1ms, Average = 0ms
C:\ping www.cisco.com
Pinging www.cisco.com
Pinging www.cisco.com
Pinging www.cisco.com
Pinging uww.cisco.com
Pinging uww.google.com
P
```

**Note**: When you ping the URLs listed, notice that the Domain Name Server (DNS) translates the URL to an IP address. Note the IP address received for each URL.

e. You can stop capturing data by clicking the Stop Capture icon.

Capturing from Intel(R) PRO/1000 MT Network Connection					
<u>File Edit View Go Capture Analyze St</u>	atistics Telep				
	] 🔍 🍬				
Filter: icmp					
No. Time Source	Destinat				

### Step 2: Examining and analyzing the data from the remote hosts.

a. Review the captured data in Wireshark, examine the IP and MAC addresses of the three locations that you pinged. List the destination IP and MAC addresses for all three locations in the space provided.

1 <sup>er</sup> Location:	IP:	_ MAC:	_:	_:	_:	_:	:
2 <sup>nd</sup> Location:	IP:	_ MAC:	_:	:	_:	:	_:
3 <sup>rd</sup> Location:	IP:	_ MAC:	_:	_:	_:	_:	_:



c. How does this information differ from the local ping information you received in Part 2?

### Reflection

Why does Wireshark show the actual MAC address of the local hosts, but not the actual MAC address for the remote hosts?

### Appendix A: Allowing ICMP Traffic Through a Firewall

If the members of your team are unable to ping your PC, the firewall may be blocking those requests. This appendix describes how to create a rule in the firewall to allow ping requests. It also describes how to disable the new ICMP rule after you have completed the lab.

#### Step 1: Create a new inbound rule allowing ICMP traffic through the firewall.

a. From the Control Panel, click the System and Security option.



b. From the System and Security window, click **Windows Firewall**.



c. In the left pane of the Windows Firewall window, click Advanced settings.



d. On the Advanced Security window, choose the **Inbound Rules** option on the left sidebar and then click **New Rule...** on the right sidebar.

Windows Firewall with Advanced	Security							x
File Action View Help	13							
🗢 🤿 🖄 🖬 🗟 🖬								
Windows Firewall with Advance	Inbound Rules					A	ctions	
Inbound Rules	Name	Group	Profile	Enabled	Action	I	nbound Rules	•
Connection Security Rules	🔇 Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow		💈 New Rule 💙	
Monitoring	🕑 Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow =		7 Filter by Profile	Þ
	🕑 Java(TM) Platform SE binary		Private	Yes	Allow		Z Filter by Chete	
	🔇 Java(TM) Platform SE binary		Private	Yes	Allow	יווי	Fliter by State	
	🕑 winradius.exe		Private	Yes	Allow	15	Filter by Group	•
	🕑 winradius.exe		Private	Yes	Allow		View	•
	🕢 winradius.exe		Private	Yes	Allow		Pofrach	
	🕑 winradius.exe		Private	Yes	Allow		a Kerresh	
	BranchCache Content Retrieval (HTTP-In)	BranchCache - Content Retr	All	No	Allow		Export List	
	BranchCache Hosted Cache Server (HTT	BranchCache - Hosted Cach	All	No	Allow	10	Help	
	RranchCache Beer Discoveny (WSD-In)	RranchCache - Deer Discove	АШ	No	Allow	117		

e. This launches the New Inbound Rule wizard. On the Rule Type screen, click the **Custom** radio button and click **Next** 



f. In the left pane, click the **Protocol and Ports** option and using the Protocol type drop-down menu, select **ICMPv4**, and then click **Next**.

🔐 New Inbound Rule Wizard		<b>×</b>
Protocol and Ports		
Specify the protocols and ports to	which this rule applies.	
Steps:		
Rule Type	To which ports and protocols does this rule apply?	
Program		
Protocol and Ports	Protocol type: Any	
Scope	Protocol number: Any Custom	
Action		
Profile	Local port: IGMP TCP	
• Name	UDP IPv6 IPv6-Route	
	Hemote port: IPv6-Frag GRE ICMPv6 IPv6-NoNot IPv6-Oots	
	Internet Control Message (ICMP) settings: L2TP	
	Learn more about protocol and ports	
	< Back	Next > Cancel

g. In the left pane, click the Name option and in the Name field, type Allow ICMP Requests. Click Finish.

💣 New Inbound Rule Wizard		×
Name		
Specify the name and description	i of this rule.	
Steps:		
a Rule Type		
Program		
Protocol and Ports		
Scope	Allow ICMP Requests	
Action		
Profile	Description (optional):	
Name		
	< Back Finish Cance	
		·

This new rule should allow your team members to receive ping replies from your PC.

### Step 2: Disabling or deleting the new ICMP rule.

After the lab is complete, you may want to disable or even delete the new rule you created in Step 1. Using the **Disable Rule** option allows you to enable the rule again at a later date. Deleting the rule permanently deletes it from the list of Inbound Rules.

a. On the Advanced Security window, in the left pane, click **Inbound Rules** and then locate the rule you created in Step 1.

I Windows Firewall with Advanced	d Security							×
File Action View Help								
🗢 🄿 🔰 🖬 🔒 👔 🖬								
Windows Firewall with Advance	Inbound Rules						Actions	
Cuthound Rules	Name	Group	Profile	Enabled	Action	-	Inbound Rules	•
Connection Security Rules	Allow ICMP Requests		All	Yes	Allow		🐹 New Rule	
Monitoring	Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow	Ξ	Filter by Profile	•
	🔇 Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow		Tiltes hu State	
	🕜 Java(TM) Platform SE binary		Private	Yes	Allow		Y Filter by State	
	🔇 Java(TM) Platform SE binary		Private	Yes	Allow		Filter by Group	
	🐼 winradius.exe		Private	Yes	Allow		View	•
	🔇 winradius.exe		Private	Yes	Allow		Refrech	
	🕑 winradius.exe		Private	Yes	Allow		Nerrean	
	🐼 winradius.exe		Private	Yes	Allow		Export List	
	BranchCache Content Retrieval (HTTP-In)	BranchCache - Content Retr	All	No	Allow		🛛 Help	
	BranchCache Hosted Cache Server (HTT	BranchCache - Hosted Cach	All	No	Allow			
	BranchCache Peer Discovery (WSD-In)	BranchCache - Peer Discove	All	No	Allow		Allow ICMP Requests	•
	Connect to a Network Projector (TCP-In)	Connect to a Network Proje	Domain	No	Allow		🔹 Disable Rule	
	Connect to a Network Projector (TCP-In)	Connect to a Network Proje	Private	No	Allow		🔏 Cut	
	Connect to a Network Projector (WSD Ev	Connect to a Network Proje	Private	No	Allow		Conv.	
	Onnect to a Network Projector (WSD Ev	Connect to a Network Proje	Domain	No	Allow		Сору	
	Onnect to a Network Projector (WSD Ev	Connect to a Network Proje	Domain	No	Allow		🗙 Delete	
	Connect to a Network Projector (WSD Ev	Connect to a Network Proje	Drivate	No	Allow		Properties	

b. To disable the rule, click the **Disable Rule** option. When you choose this option, you will see this option change to **Enable Rule**. You can toggle back and forth between Disable Rule and Enable Rule; the status of the rule also shows in the Enabled column of the Inbound Rules list.

Windows Firewall with Advanced	I Security						
File Action View Help							
🗢 🄿 🙍 🖬 🗟 🖬							
🔗 Windows Firewall with Advance	Inbound Rules						Actions
🔣 Inbound Rules	Name	Group	Profile	Enabled	Action	*	Inbound Rules 🔺
Outbound Rules	Allow ICMP Requests	•	All C	Yes	Allow		🚉 New Rule
Monitoring	Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow	Ξ	Filter by Profile
V 100	🔇 Java(TM) 2 Platform Standard Edition bin		Private	Yes	Allow		
	🕑 Java(TM) Platform SE binary		Private	Yes	Allow		
	🕑 Java(TM) Platform SE binary		Private	Yes	Allow		▼ Filter by Group
	🕑 winradius.exe		Private	Yes	Allow		View 🕨
	🕑 winradius.exe		Private	Yes	Allow		G Refresh
	🕑 winradius.exe		Private	Yes	Allow		Concept Lint
	Winradius.exe		Private	Yes	Allow		
	BranchCache Content Retrieval (HTTP-In)	BranchCache - Content Retr	All	No	Allow		🕐 Help
	BranchCache Hosted Cache Server (HTT	BranchCache - Hosted Cach	All	No	Allow		
	BranchCache Peer Discovery (WSD-In)	BranchCache - Peer Discove	All	No	Allow		Allow to the Acquests =
	Connect to a Network Projector (TCP-In)	Connect to a Network Proje	Domain	No	Allow	5	Disable Rule
	Connect to a Network Projector (TCP-In)	Connect to a Network Proje	Private	No	Allow		of Cut
	Connect to a Network Projector (WSD Ev	Connect to a Network Proje	Private	No	Allow		Сору
	Connect to a Network Projector (WSD Ev	Connect to a Network Proje	Domain	No	Allow		
	Connect to a Network Projector (WSD Ev	Connect to a Network Proje	Domain	No	Allow		A Delete

c. To permanently delete the ICMP rule, click **Delete**. If you choose this option, you must re-create the rule again to allow ICMP replies.

it iveti	All	INU	Allow		пер
I Cach	All	No	Allow	H	
iscove	All	No	Allow	Allo	w ICMP Requests
Proje	Domain	No	Allow		Disable Rule
Proje	Private	No	Allow	8	Cut
Proje	Private	No	Allow		Comu
Proje	Domain	No	Allow	99	Сору
Proje	Domain	No	Allow 🤇	×	Delete
Proie	Private	No	Allow	F	Properties

## 3.4.1.1 Guaranteed to work!

### **Objectives**

# Explain the role of protocols and standards organizations in facilitating interoperability in network communications.

In this activity, you will demonstrate how network communications can be compared to everyday activities using established procedures and standards.

### Background/Scenario

You have just completed the Chapter 3 content regarding network protocols and standards.

Assuming you resolved the beginning of this chapter's modeling activity, how would you compare the following steps taken to design a communications system to the networking models used for communications?

Steps to Communicate	Possible Answers	Associated TCP/IP Model Layer
Establish a language to communicate		
Divide the message into small steps, delivered a little at a time, to facilitate understanding of the problem		
Verify that the message has been delivered correctly to the mechanic who will perform the repairs		
Deliver the automobile and identify wait time for repairs		

### **Required Resources**

Blank "Steps to Communicate" table (above) for students to record their answers based upon their Chapter 3 content knowledge.

### Reflection

1. How does your network model in developing an automotive repair communications plan compare to a network communications interoperability plan?

### **Guaranteed to work!**

Steps to Communicate	Possible Answers	Associated TCP/IP Model Layer

## 4.0.1.2 Let me tell you what I heard at a conference...

### **Objectives**

# Describe the purpose and function of the data link layer in preparing communication for transmission on specific media.

In this activity, you will discuss how communication within a single data-link layer domain can be performed immediately by addressing the intended node directly. You will also consider the increasing difficulty of communication if multiple nodes in a single domain need to communicate.

### Background/Scenario

You and your colleague are attending a networking conference. There are many lectures and presentations held during this event, and because they overlap, each of you can attend only a limited set of sessions. Therefore, you decide to split up, each of you attending a separate set of presentations, and after the event ends, you share the slides and the knowledge each of you gained during the event.

Answer the following questions:

- How would you personally organize a conference where multiple sessions are held at the same time? Would you put all of them into a single conference room, or would you use multiple rooms? Explain your answer.
- Assume that the conference room is properly fitted with audiovisual equipment to display largesize video and amplify the speaker's voice. If a person wanted to attend a specific session, does it matter which seat the person takes, or is it sufficient for the person to sit anywhere as long as it is in an appropriate conference room?
- What are the potential consequences or benefits if the speech from one conference room somehow leaked into another?
- If questions or inquiries arise during a presentation, should an attendee simply shout out a question, or should there be some process of assuring that attendees are given an opportunity to ask questions that everyone can hear? What would happen without this process?
- Can a session run out of time without going through the entire intended content if an interesting topic elicits a larger discussion where many attendees have questions? If you did not want this to happen, what would be the best way to ensure that it does not occur?
- Imagine that the session is in a panel format, which allows more free discussion of attendees with the panelists and among themselves. If a person wants to address another person within the same room, can it be done directly? If so, how is this possible? How would a panelist invite another person to join who is not presently in the room?
- What benefit, if any, was achieved by the isolation of multiple sessions into separate conference rooms if, after the event, people could meet and share the information?

### **Required Resources**

Recording capabilities (paper, tablet, etc.) for reflective comments to be shared with the class.

### Reflection

1. How would you personally organize a conference where multiple sessions are held at the same time? Would you put all of them into a single conference room, or would you use multiple rooms? What would be the reason? Explain your answer.

2.	Assume that the conference room is properly fitted with audiovisual equipment to display large-size video and amplify the speaker's voice. If a person wanted to attend a specific session, does it matter which seat will the person takes, or is it sufficient for the person to sit anywhere as long as it is in appropriate conference room?
3.	What are the potential consequences or benefits if the speech from one conference room somehow leaked into another?
4.	If questions or inquiries arise during a presentation, should an attendee simply shout out his/her question, or should there be some process of assuring that attendees are given an opportunity to ask questions that everyone can hear? What would happen without this process?
5.	Can a session run out of time without going through the entire intended content if an interesting topic elicits a larger discussion where many attendees have questions? If you did not want this to happen, what would be the best way to ensure that it does not occur?

6. Imagine that the session is in a panel format, which allows more free discussion of attendees with the panelists and among themselves. If a person wants to address another person within the same room, can he/she do it directly? If so, how is this possible? How would a panelist invite another person to join who is not presently in the room?

7. What benefit, if any, was achieved by the isolation of multiple sessions into separate conference rooms if, after the event, people could meet and share the information?

# 4.1.2.4 Lab A - Identifying Network Devices and Cabling

### Objectives

### Part 1: Identify Network Devices

• Describe the functions and physical characteristics of the network device.

### Part 2: Identify Network Media

• Describe the functions and physical characteristics of the media.

### **Background / Scenario**

As a member of the networking support staff, you must be able to identify different networking equipment. You must also understand the function of equipment in the appropriate part of the network. In this lab, you will have access to network devices and media. You will identify the type and characteristics of the network equipment and media.

### Part 1: Identify Network Devices

Your instructor will provide various network devices for identification. Each will be tagged with an ID number.

Fill in the table below with the device tag ID number, manufacturer, device model, type (hub, switch, and router), functionality (wireless, router, switch, or combination), and other physical characteristics, such as number of interface types. The first line is filled out as a reference.

ID	Manufacturer	Model	Туре	Functionality	Physical Characteristics
1	Cisco	1941	Router	Router	<ul> <li>2 GigabitEthernet Ports</li> <li>2 EHWIC slots</li> <li>2 CompactFlash slots</li> <li>1 ISM slot</li> <li>2 Console ports: USB, RJ-45</li> </ul>
2					
3					
4					
5					
6					

### Part 2: Identify Network Media

Your instructor will provide various network media for identification. You will name the network media, identify the media type (copper, fiber optic, or wireless), and provide a short media description including what device types it connects. Use the table below to record your findings. The first line in the table has been filled out as a reference.

ID	Network Media	Туре	Description and to What It Connects
1	UTP	Copper	Connect wired NIC and Ethernet ports on network devices Cat 5 straight-through wired. Connects PCs and routers to switches and wiring panels.
2			
3			
4			
5			
6			

### Reflection

After you have identified the network equipment, where would you find more information about the equipment?

# 4.2.2.7 Lab - Building an Ethernet Crossover Cable

### Topology



### Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
PC-A	NIC	192.168.10.1	255.255.255.0	N/A
PC-B	NIC	192.168.10.2	255.255.255.0	N/A

### Objectives

### Part 1: Analyze Ethernet Cabling Standards and Pinouts

- Analyze diagrams and tables for the TIA/EIA 568-A standard Ethernet cable.
- Analyze diagrams and tables for the TIA/EIA 568-B standard Ethernet cable.

### Part 2: Build an Ethernet Crossover Cable

- Build and terminate a TIA/EIA 568-A cable end.
- Build and terminate a TIA/EIA 568-B cable end.

### Part 3: Test an Ethernet Crossover Cable

- Test an Ethernet crossover cable with a cable tester.
- Connect two PCs together using an Ethernet crossover cable.

### **Background / Scenario**

In this lab, you will build and terminate an Ethernet crossover cable and test it by connecting two PCs together and pinging between them. You will first analyze the Telecommunications Industry Association/Electronic Industries Association (TIA/EIA) 568-A and 568-B standards and how they apply to Ethernet cables. You will then construct an Ethernet crossover cable and test it. Finally, you will use the cable you just constructed to connect two PCs together and test it by pinging between them.

**Note**: With autosensing capabilities available on many devices, such as the Cisco 1941 Integrated Services Router (ISR) switch, you may see straight-through cables connecting like devices.

### **Required Resources**

- One length of cable, either Category 5 or 5e. Cable length should be 0.6 to 0.9m (2 to 3 ft.)
- 2 RJ-45 connectors
- RJ-45 crimping tool
- Wire cutter
- Wire stripper

- Ethernet cable tester (optional)
- 2 PCs (Windows 7, Vista, or XP)

### Part 1: Analyze Ethernet Cabling Standards and Pinouts

The TIA/EIA has specified unshielded twisted pair (UTP) cabling standards for use in LAN cabling environments. TIA/EIA 568-A and 568-B stipulates the commercial cabling standards for LAN installations; these are the standards most commonly used in LAN cabling for organizations and they determine which color wire is used on each pin.

With a crossover cable, the second and third pairs on the RJ-45 connector at one end of the cable are reversed at the other end, which reverses the send and receive pairs. The cable pinouts are the 568-A standard on one end and the 568-B standard on the other end. Crossover cables are normally used to connect hubs to hubs or switches to switches, but they can also be used to directly connect two hosts to create a simple network.

**Note**: With modern networking devices, a straight-through cable can often be used even when connecting like devices because of their autosensing feature. With autosensing, the interfaces detect whether the send and receive circuit pairs are correctly connected. If they are not, the interfaces reverse one end of the connection. Autosensing also alters the speed of the interfaces to match the slowest one. For example, if connecting a Gigabit Ethernet (1000 Mb/s) router interface to a Fast Ethernet (100 Mb/s) switch interface, the connection uses Fast Ethernet.

The Cisco 2960 switch has autosensing turned on, by default; therefore, connecting two 2960 switches together works with either a crossover or a straight-through cable. With some older switches, this is not the case and a crossover cable must be used.

In addition, the Cisco 1941 router Gigabit Ethernet interfaces are autosensing and a straight-through cable may be used to connect a PC directly to the router interface (bypassing the switch). With some older routers, this is not the case and a crossover cable must be used.

When directly connecting two hosts, it is generally advisable to use a crossover cable.

#### Step 1: Analyze diagrams and tables for the TIA/EIA 568-A standard Ethernet cable.

The following table and diagrams display the color scheme and pinouts, as well as the function of the four pairs of wires used for the 568-A standard.

Note: In LAN installations using 100Base-T (100 Mb/s), only two pairs out of the four are used.

Pin Number	Pair Number	Wire Color	10Base-T Signal 100Base-TX Signal	1000Base-T Signal
1	2	White/Green	Transmit	BI_DA+
2	2	Green	Transmit	BI_DA-
3	3	White/Orange	Receive	BI_DB+
4	1	Blue	Not Used	BI_DC+
5	1	White/Blue	Not Used	BI_DC-
6	3	Orange	Receive	BI_DB-
7	4	White/Brown	Not Used	BI_DD+
8	4	Brown	Not Used	BI_DD-

### 568-A 10/100/1000Base-TX Ethernet

The following diagrams display how the wire color and pinouts align with an RJ-45 jack for the 568-A standard.





### Step 2: Analyze diagrams and tables for the TIA/EIA 568-B standard Ethernet cable.

The following table and diagram display the color scheme and pinouts for the 568-B standard.

Pin Number	Pair Number	Wire Color	10Base-T Signal 100Base-TX Signal	1000Base-T Signal
1	2	White/Orange	Transmit	BI_DA+
2	2	Orange	Transmit	BI_DA-
3	3	White/Green	Receive	BI_DB+
4	1	Blue	Not Used	BI_DC+
5	1	White/Blue	Not Used	BI_DC-
6	3	Green	Receive	BI_DB-
7	4	White/Brown	Not Used	BI_DD+
8	4	Brown	Not Used	BI_DD-

568-B	10/100/10	00-BaseTX	Ethernet
	10/100/10	oo Buscin	Ethornot



### Part 2: Build an Ethernet Crossover Cable

A crossover cable has the second and third pairs on the RJ-45 connector at one end, reversed at the other end (refer to the table in Part 1, Step 2). The cable pinouts are the 568-A standard on one end and the 568-B standard on the other end. The two following diagrams illustrate this concept.



### Step 1: Build and terminate a TIA/EIA 568-A cable end.

a. Determine the cable length required. (Your instructor will let you know the cable length you should make.)

**Note**: If you were making a cable in a production environment, the general guideline is to add another 12 in. (30.48 cm) to the length.

- b. Cut off a piece of cable to the desired length and using your wire stripper, remove 5.08 cm (2 in.) of the cable jacket from both ends.
- c. Hold the four pairs of twisted cables tightly where the jacket was cut away. Reorganize the cable pairs into the order of the 568-A wiring standard. Refer to the diagrams, if necessary. Take as much care as possible to maintain the twists in the cable; this provides noise cancellation.
- d. Flatten, straighten, and line up the wires using your thumb and forefinger.
- e. Ensure that the cable wires are still in the correct order for the 568-A standard. Using your wire cutters, trim the four pairs in a straight line to within 1.25 to 1.9 cm (1/2 to 3/4 in.).
- f. Place an RJ-45 connector on the end of your cable, with the prong on the underside pointing downward. Firmly insert the wires into the RJ-45 connector. All wires should be seen at the end of the connector in their proper positions. If the wires are not extending to the end of the connector, take the cable out, rearrange the wires as necessary, and reinsert the wires back into the RJ-45 connector.
- g. If everything is correct, insert the RJ-45 connector with cable into the crimper. Crimp down hard enough to force the contacts on the RJ-45 connector through the insulation on the wires, thus completing the conducting path. See the following diagram for an example.



### Step 2: Build and terminate a TIA/EIA 568-B cable end.

Repeat steps 1a to 1g using the 568-B color wiring scheme for the other end.

### Part 3: Test an Ethernet Crossover Cable

#### Step 1: Test the cable.

Many cable testers will test for length and mapping of wires. If the cable tester has a wire map feature, it verifies which pins on one end of the cable are connected to which pins on the other end.

If your instructor has a cable tester, test the crossover cable for functionality. If it fails, check with your instructor first as to whether you should re-cable the ends and re-test.

### Step 2: Connect two PCs together via NICs using your Ethernet crossover cable.

- a. Working with a lab partner, set your PC to one of the IP addresses shown in the Addressing Table (see page 1). For example, if your PC is PC-A, your IP address should be set to 192.168.10.1 with a 24-bit subnet mask. You partner's IP address should be 192.168.10.2. The default gateway address can be left empty.
- b. Using the crossover cable you made, connect the two PCs together via their NICs.
- c. On the PC-A command prompt, ping the PC-B IP address.

**Note**: The Windows firewall may have to be temporarily disabled for pings to be successful. If the firewall is disabled, make sure you re-enable it at the conclusion of this lab.

d. Repeat the process and ping from PC-B to PC-A.

Assuming IP addressing and firewall are not issues, your pings should be successful if the cables were properly made.

### Reflection

- 1. Which part of making cables did you find the most difficult?
- 2. Why do you have to learn how to make a cable if you can easily buy pre-made cables?

# 4.2.4.6 Lab – Viewing Wireless and Wired NIC Information

### Objectives

Part 1: Identify and Work with PC NICs

Part 2: Identify and Use the System Tray Network Icons

### **Background / Scenario**

This lab requires you to determine the availability and status of the network interface cards (NICs) on the PC that you use. Windows provides a number of ways to view and work with your NICs.

In this lab, you will access the NIC information of your PC and change the status of these cards.

### **Required Resources**

• 1 PC (Windows 7, Vista, or XP with two NICs, wired and wireless, and a wireless connection)

**Note**: At the start of this lab, the wired Ethernet NIC in the PC was cabled to one of the integrated switch ports on a wireless router and the Local Area Connection (wired) was enabled. The wireless NIC was disabled initially. If the wired and wireless NICs are both enabled the PC will receive two different IP addresses and the wireless NIC will take precedence.

### Part 1: Identify and Work with PC NICs

In Part 1, you will identify the NIC types in the PC that you are using. You will explore different ways to extract information about these NICs and how to activate and deactivate them.

**Note**: This lab was performed using a PC running on the Windows 7 operating system. You should be able to perform the lab with one of the other Windows operating systems listed; however, menu selections and screens may vary.

### Step 1: Use the Network and Sharing Center.

- a. Open the **Network and Sharing Center** by clicking the Windows **Start** button > **Control Panel** > **View network status and tasks** under Network and Internet heading in the Category View.
- b. In the left pane, click the Change adapter settings link.
- c. The Network Connections window displays, which provides the list of NICs available on this PC. Look for your Local Area Connection and Wireless Network Connection adapters in this window.



**Note**: Virtual Private Network (VPN) adapters and other types of network connections may also be displayed in this window.

#### Step 2: Work with your wireless NIC.

a. Select the Wireless Network Connection option and right-click it to bring up a drop-down list. If your wireless NIC is disabled, you will have an option to Enable it. If your NIC was already enabled, then Disable would be the first option on this drop-down menu. If your Wireless Network Connection is currently disabled, then click Enable.



b. Right-click the Wireless Network Connection, and then click Status.



c. The Wireless Network Connection Status window displays where you can view information about your wireless connection.

I Wireless Network Connection	Status 🛛 🕅
General	
Connection	
IBv4 Connectivity	Internet
IPv6 Connectivity:	No petwork access
Media State:	Foobled
	rralace
Duration:	00:16:51
Social Social	144 0 Mbos
speed:	144.0 Mbps
Signal Quality:	lllee
Details Wireless F	Properties
Activity	
Sent —	Received
Bytes: 16,266	111,143
Properties Disable	Diagnose
	Close

What is the Service Set Identifier (SSID) for the wireless router of your connection?

What is the speed of your wireless connection? \_\_\_\_\_

d. Click **Details** to display the Network Connection Details window.

etwork Connection Details	
Network Connection Details:	
Property	Value
Connection-specific DNS Suffix	ph.cox.net
Description	Intel(R) Centrino(R) Advance
Physical Address	58-94-6B-34-92-1C
DHCP Enabled	Yes
IPv4 Address	192.168.87.118
IPv4 Subnet Mask	255.255.255.0
Lease Obtained	Wednesday, January 16, 2[ ≡
Lease Expires	Thursday, January 17, 2013
IPv4 Default Gateway	192.168.87.1
IPv4 DHCP Server	192.168.87.1
IPv4 DNS Servers	68.105.28.16
	68.105.29.16
	192.168.87.1
IPv4 WINS Server	
NetBIOS over Tcpip Enabled	Yes
Link-local IPv6 Address	fe80::284c.fc29:c659.f4db% 🚽
•	4
	Close

What is the MAC address of your wireless NIC? \_\_\_\_

Do you have multiple IPv4 DNS Servers listed? \_\_\_\_

Why would multiple DNS Servers be listed?

- e. When you have reviewed the network connection details, click **Close**.
- f. Open a command window prompt and type **ipconfig /all**.



Notice that the information displayed here is the same information that was displayed in the Network Connection Details window in Step d.

- g. Close the command window and the Network Connection Details windows. This should bring you back to the Wireless Network Connection Status window. Click **Wireless Properties**.
- h. In the Wireless Network Properties window, click the Security tab.

rrplace Wireless Netwo	rk Properties
Connection Security	>
Name:	rrplace
SSID:	rrplace
Network type:	Access point
Network availability:	All users
Connect automati	ically when this network is in range
Connect to a more	e preferred network if available
Connect even if t	he network is not broadcasting its name (SSID)
Enable Intel conn	ection settings
Copy this networ	k profile to a USB flash drive
L	
	OK Cancel

i. The type of security the connected wireless router has implemented displays. Click the **Show characters** check box to display the actual Network security key, instead of the hidden characters, and then click **OK**.

rrplace Wireless Networ	k Properties
Connection Security	
Security type:	WPA2-Personal
Encryption type:	AES 👻
Network security key	•••••
( (	show characters
Advanced antifacts	
Advanced settings	
	OK Cancel

j. Close the Wireless Network Properties and the Network Connection Status windows. Select and rightclick the Wireless Network Connection option > Connect/Disconnect. A pop-up window should appear at the bottom right corner of your desktop that displays your current connections, along with a list of SSIDs that are in range of the wireless NIC of your PC. If a scrollbar appears on the right side of this window, you can use it to display additional SSIDs.



k. To join one of the other wireless network SSIDs listed, click the SSID that you want to join, and then click **Connect**.

Currently connected to:	Â
Internet access	
isco.com Internet access	Ш
No network access	
Wireless Network Connection	
الجنيني م	
rrplace Connected	
rrplace 2 Connected	
rrplace 2 all blizzard	
rrplace 2 all blizzard all Connect automatical v Connect	>
rrplace 2 all blizzard all V Connect automatical V Connect Budworth	>

I. If you have selected a secure SSID, you are prompted to enter the **Security key** for the SSID. Type the security key for that SSID and click **OK**. You can click the **Hide characters** check box to prevent people from seeing what you type in the **Security key** field.



### Step 3: Work with your wired NIC.

a. On the Network Connections window, select and right-click the **Local Area Connection** option to display the drop-down list. If the NIC is disabled, enable it, and then click the **Status** option.

**Note**: You must have an Ethernet cable attaching your PC NIC to a switch or similar device to see the status. Many wireless routers have a small 4-port Ethernet switch built-in. You can connect to one of the ports using a straight-through Ethernet patch cable.



b. The Local Area Connection Status window will open. This window displays information about your wired connection to the LAN.

🏺 Local Area Connection Status	8
General	
Connection	
IPv4 Connectivity:	Internet
IPv6 Connectivity:	No Internet access
Media State:	Enabled
Duration:	00:01:00
Speed:	100.0 Mbps
Details	
Activity	
Sent —	Received
Bytes:	16,516
Properties Pisable	Diagnose
	Close

Click **Details...** to view the address information for your LAN connection.

Network Connection Details				
Network Connection Details:				
Property	Value			
Connection-specific DN Description Physical Address DHCP Enabled IPv4 Address IPv4 Subnet Mask Lease Obtained Lease Expires IPv4 Default Gateway IPv4 DHCP Server IPv4 DNS Servers	ph.cox.net Intel(R) 82577LM Gigabit Network Cor 5C-26-0A-24-2A-60 Yes 192.168.87.127 255.255.255.0 Thursday, January 17, 2013 10:38:14 Friday, January 18, 2013 10:38:14 AM 192.168.87.1 192.168.87.1 68.105.28.16 68.105.29.16			
IPv4 WINS Server	192.168.87.1			
NetBIOS over Tcpip En	Yes			
Link-local IPv6 Address	fe80::b875:731b:3c7b:c0b1%10 🖕			
•	4			
	Close			

c. Open a command window prompt and type **ipconfig /all**. Find your Local Area Connection information and compare this with the information displayed in the Network Connection Details window.

chernet adapter Local Area Connection:
Connection-specific DNS Suffix .: ph.cox.net
Description
Physical Address
DHČP Enabled Yes
Autoconfiguration Enabled : Yes
Link-local IPv6 Address : fe80::b875:731b:3c7b:c0b1%10 <preferred></preferred>
IPv4 Address
Subnet Mask
Lease Obtained Thursday, January 17, 2013 10:38:14 AM
Lease Expires Friday, January 18, 2013 10:38:14 AM
Default Gateway
DHCP Server
DHCPv6 IAID
DHCPv6 Client DUID
DNS Servers
68.105.29.16
192.168.87.1
NetBIOS over Tcpip Enabled

d. Close all windows on your desktop.

### Part 2: Identify and Use the System Tray Network Icons

In Part 2, you will use the network icons in your system tray to determine and control the NICs on your PC.

### Step 1: Use the Wireless Network icon.

a. Click the system tray Wireless Network icon to view the pop-up window that displays the SSIDs that are in-range of your wireless NIC. When the system tray displays the Wireless Network icon, the wireless NIC is active.



b. Click the Open Network and Sharing Center link. Note: This is a shortcut way to bring up this window.



- c. In the left pane, click the **Change adapter settings** link to display the Network Connections window.
- d. Select and right-click the **Wireless Network Connection**, and then click **Disable** to disable your wireless NIC.

		Wireless I rrplace	Network Connection
	Disable		entrino(R) Advanced-N
	Connect / Disconnect		
	Status		
	Diagnose		
۲	Bridge Connections		
	Create Shortcut		
0	Delete		
0	Rename		
۲	Properties		

e. Examine your system tray. The **Wireless Network Connection** icon should be replaced by the **Wired Network** icon, which indicates that you are using your wired NIC for network connectivity.



Note: If both NICs are active, the Wireless Network icon is the one that is displayed.

#### Step 2: Use the Wired Network icon.

a. Click the **Wired Network** icon. Notice that the Wireless SSIDs are no longer displayed in this pop-up window, but you still have the ability to get to the Network and Sharing Center window from here.



b. Click the Open Network and Sharing Center link > Change adapter settings and Enable your Wireless Network Connection. The Wireless Network icon should replace the Wired Network icon in your system tray.



### Step 3: Identify the Network Problem icon.

a. On the Network Connections window, disable both the **Wireless Network Connection** and the **Local Area Connection**.

b. The system tray now displays the **Network Disabled** icon, which indicates that network connectivity has been disabled.



c. You can click this icon to return to the Network and Sharing Center window (examine the network diagram at the top).



You can click the red  $\mathbf{X}$  to have the PC troubleshoot the problem with the network connection. Troubleshooting attempts to resolve the network issue for you.

d. If troubleshooting did not enable one of your NICs, then you should do this manually to restore the network connectivity of your PC.

**Note**: If a network adapter is enabled and the NIC is unable to establish network connectivity, then the **Network Problem** icon appears in the system tray.



If this icon appears, you can troubleshoot this issue just like you did in Step 3c.

### Reflection

Why would you activate more than one NIC on a PC?

# 4.5.1.1 Linked In!

### **Objectives**

### Connect devices using wired and wireless media.

In this activity, you will map your network cabling or technology type ideas to a physical topology. Because this chapter focuses on the network access layer, you should be able to prepare a basic physical model. No logical (IP addressing) schemes are required for this activity.

### **Physical Topology**



### Background/Scenario

Note: This activity is best completed in groups of 2-3 students.

Your small business is moving to a new location! Your building is brand new and you must come up with a physical topology so that network port installation can begin.

Your instructor will provide you with a blueprint created for this activity. The area on the blueprint, indicated by Number 1, is the reception area and the area labeled "RR" is the restroom area.

All rooms are within Category 6 UTP specifications (328 ft. [100 m]), so you have no concerns about hard-wiring the building to code. Each room in the diagram must have at least one network connection available for users/intermediary devices.

With your teammate(s), indicate on the drawing:

- Where would you locate your network main distribution facility, while keeping security in mind?
- How many intermediary devices would you use and where would you place them?
- What kind of cabling you would use (UTP, STP, wireless, fiber optics, etc.) and where would the ports be placed?
- What types of end devices you would use (wired, wireless, laptops, desktops, tablets, etc.)?

Do not go into excessive detail on your design. Just use the content from the chapter to be able to justify your decisions to the class.

### **Required Resources**

Packet Tracer software

### Reflection

- 1. Where would you locate your network main distribution facility, while keeping security in mind?
- 2. How many intermediary devices would you use and where would you place them?
- 3. What kind of cabling you would use (UTP, STP, wireless, fiber optics, etc.) and where would the ports be placed?

4. What types of end devices you would use (wired, wireless, laptops, desktops, tablets, etc.)?

# 5.0.1.2 Join my social circle!

### **Objectives**

### Describe the impact of ARP requests on network and host performance.

In this activity, you will discuss the ways in which local addressing (source and destination) is critical to data communication identification when using messaging, conferencing, emailing, and even gaming.

### Background/Scenario

Note: This activity can be completed individually in class or outside of class.

Much of our network communication takes the form of email, messaging (text or instant), video contact, and social media postings.

For this activity, choose one of the following types of network communications:

- Text or instant messaging
- Audio/video conferencing
- Emailing
- Online gaming

Now that you have selected a network communication type, record your answers to the following questions:

- 1. Is there a procedure you must follow to register others and yourself so that you form a communications account? Why do you think that a procedure is needed?
- 2. How do you initiate contact with the person or people with whom you wish to communicate?
- 3. How do you ensure that your conversations are received only by those with whom you wish to communicate? Be prepared to discuss your answers in class.

### **Required Resources**

Recording capabilities (paper, tablet, etc.) for reflective comments to be shared with the class

### Reflection

1. Is there a procedure you must follow to register others and yourself so that you form a communications account? Why do you think that a procedure is needed?
2. How do you initiate contact with the person or people with whom you wish to communicate?

3. How do you ensure that your conversations are received only by those with whom you wish to communicate?

# 5.1.3.6 Lab – Viewing Network Device MAC Addresses

# Topology



# Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway		
R1	G0/1	192.168.1.1	255.255.255.0	N/A		
S1	VLAN 1	N/A	N/A	N/A		
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1		

# Objectives

#### Part 1: Set Up the Topology and Initialize Devices

- Set up equipment to match the network topology.
- Initialize and restart (if necessary) the router and switch.

# Part 2: Configure Devices and Verify Connectivity

- Assign static IP address to PC-A NIC.
- Configure basic information on R1.
- Assign a static IP address to R1.
- Verify network connectivity.

#### Part 3: Display, Describe, and Analyze Ethernet MAC Addresses

- Analyze MAC address for PC-A.
- Analyze MAC addresses for router R1.
- Display the MAC address table on switch S1.

# **Background / Scenario**

Every device on an Ethernet LAN is identified by a Layer-2 MAC address. This address is burned into the NIC. This lab will explore and analyze the components that make up a MAC address, and how you can find this information on various networking devices, such as a router, switch, and PC.

You will cable the equipment as shown in the topology. You will then configure the router and PC to match the addressing table. You will verify your configurations by testing for network connectivity.

After the devices have been configured and network connectivity has been verified, you will use various commands to retrieve information from the devices to answer questions about your network equipment.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used.

Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

# Part 1: Set Up the Topology and Initialize Devices

In Part 1, you will set up the network topology, clear any configurations, if necessary, and configure basic settings, such as the interface IP addresses on the router and PC.

#### Step 1: Cable the network as shown in the topology.

- a. Attach the devices shown in the topology and cable as necessary.
- b. Power on all the devices in the topology.

#### Step 2: Initialize and reload the router and switch.

# Part 2: Configure Devices and Verify Connectivity

In Part 2, you will set up the network topology and configure basic settings, such as the interface IP addresses and device access. For device names and address information, refer to the Topology and Addressing Table.

#### Step 1: Configure the IPv4 address for the PC.

- a. Configure the IPv4 address, subnet mask, and default gateway address for PC-A.
- b. Ping the default gateway address from a PC-A command prompt.

Were the pings successful? Why or why not?

#### Step 2: Configure the router.

The configuration of a Cisco router is similar to configuring a Cisco switch. In this step, you will configure the device name and the IP address and disable DNS lookup on the router.

a. Console into the router and enter global configuration mode.

```
Router> enable
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

b. Assign a hostname to the router based on the Addressing Table.

Router(config) # hostname R1

c. Disable DNS lookup.

R1(config) # no ip domain-lookup

d. Configure and enable the G0/1 interface on the router.

```
R1(config)# interface GigabitEthernet0/1
R1(config-if)# ip address 192.168.1.1 255.255.255.0
R1(config-if)# no shutdown
R1(config-if)# end
*Feb 23 09:06:01.927: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to
down
*Feb 23 09:06:05.279: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to
up
*Feb 23 09:06:06.279: %LINEPROTO-5-UPDOWN: Line protocol on Interface
GigabitEthernet0/1, changed state to up
```

#### Step 3: Verify network connectivity.

Ping the default gateway address of R1 from PC-A.

Were the pings successful?

# Part 3: Display, Describe, and Analyze Ethernet MAC Addresses

Every device on an Ethernet LAN has a Media Access Control (MAC) address that is burned into the Network Interface Card (NIC). Ethernet MAC addresses are 48-bits long. They are displayed using six sets of hexadecimal digits usually separated by dashes, colons, or periods. The following example shows the same MAC address using the three different notation methods:

00-05-9A-3C-78-00 00:05:9A:3C:78:00 0005.9A3C.7800

**Note**: MAC addresses are also called physical addresses, hardware addresses, or Ethernet hardware addresses.

In Part 3, you will issue commands to display the MAC addresses on a PC, router, and switch, and you will analyze the properties of each one.

#### Step 1: Analyze the MAC address for the PC-A NIC.

Before you analyze the MAC address on PC-A, look at an example from a different PC NIC. You can issue the **ipconfig /all** command to view the MAC address of your NICs. An example screen output is shown below. When using the **ipconfig /all** command, notice that MAC addresses are referred to as physical addresses. Reading the MAC address from left to right, the first six hex digits refer to the vendor (manufacturer) of this device. These first six hex digits (3 bytes) are also known as the organizationally unique identifier (OUI). This 3-byte code is assigned to the vendor by the IEEE organization. To find the manufacturer, you can use a tool such as <u>www.macvendorlookup.com</u> or go to the IEEE web site to find the registered OUI vendor codes. The IEEE web site address for OUI information is <u>http://standards.ieee.org/develop/regauth/oui/public.html</u>. The last six digits are the NIC serial number assigned by the manufacturer.

a. Using the output from the **ipconfig /all** command, answer the following questions.

thernet	adapte	r Loc	al	Ar	•ea	ι (	;on	ine	ct	;10	n	:
Conneg	tion-s	pecif	ic	D١	IS	Su	ιff	i>	c		=	
Descri	ption											Realtek PCIe GBE Family Controller
Physic	al Add:	ress.									=	C8-0A-A9-FA-DE-0D
DHCP E	Enabled	l <b></b>									=	No
Autoco	nfigur	ation	ı Er	nat	le	:d					=	Yes
IPv4 A	Iddress										=	192.168.1.3(Preferred)
Subnet	: Mask										=	255.255.255.0
Defaul	lt Gate	way .									=	192.168.1.1
NetBIC	)S over	Tcpi	ip.								:	Enabled

What is the OUI portion of the MAC address for this device?

What is the serial number portion of the MAC address for this device?

Using the example above, find the name of the vendor that manufactured this NIC.

b. From the command prompt on PC-A, issue the **ipconfig /all** command and identify the OUI portion of the MAC address for the NIC of PC-A.

Identify the serial number portion of the MAC address for the NIC of PC-A.

Identify the name of the vendor that manufactured the NIC of PC-A.

#### Step 2: Analyze the MAC address for the R1 G0/1 interface.

You can use a variety of commands to display MAC addresses on the router.

a. Console into R1 and use the **show interfaces g0/1** command to find the MAC address information. A sample is shown below. Use output generated by your router to answer the questions.

```
R1# show interfaces g0/1
GigabitEthernet0/1 is up, line protocol is up
 Hardware is CN Gigabit Ethernet, address is 30f7.0da3.1821 (bia 30f7.0da3.1821)
 Internet address is 192.168.1.1/24
 MTU 1500 bytes, BW 100000 Kbit/sec, DLY 100 usec,
     reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation ARPA, loopback not set
 Keepalive set (10 sec)
 Full Duplex, 100Mbps, media type is RJ45
 output flow-control is unsupported, input flow-control is unsupported
 ARP type: ARPA, ARP Timeout 04:00:00
 Last input 00:00:00, output 00:00:00, output hang never
 Last clearing of "show interface" counters never
 Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
 Queueing strategy: fifo
 Output queue: 0/40 (size/max)
  5 minute input rate 3000 bits/sec, 4 packets/sec
```

```
5 minute output rate 0 bits/sec, 0 packets/sec
15183 packets input, 971564 bytes, 0 no buffer
Received 13559 broadcasts (0 IP multicasts)
0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 watchdog, 301 multicast, 0 pause input
1396 packets output, 126546 bytes, 0 underruns
0 output errors, 0 collisions, 1 interface resets
195 unknown protocol drops
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out
```

What is the MAC address for G0/1 on R1?

What is the MAC serial number for G0/1?

What is the OUI for G0/1?

Based on this OUI, what is the name of the vendor?

What does bia stand for?

Why does the output show the same MAC address twice?

b. Another way to display the MAC addresses on the router is to use the **show arp** command. Use the **show arp** command to display MAC address information. This command maps the Layer 2 address to its corresponding Layer 3 address. A sample is shown below. Use output generated by your router to answer the questions.

R1# show	arp					
Protocol	Address	Age	(min)	Hardware Addr	Туре	Interface
Internet	192.168.1.1		-	30f7.0da3.1821	ARPA	GigabitEthernet0/1
Internet	192.168.1.3		0	c80a.a9fa.de0d	ARPA	GigabitEthernet0/1

What Layer 2 addresses are displayed on R1?

What Layer 3 addresses are displayed on R1?

Why do you think there is no information showing for the switch with the **show arp** command?

#### Step 3: View the MAC addresses on the switch.

a. Console into the switch and use the **show interfaces** command for ports 5 and 6 to display MAC address information. A sample is shown below. Use output generated by your switch to answer the questions.

```
Switch> show interfaces f0/5
FastEthernet0/5 is up, line protocol is up (connected)
 Hardware is Fast Ethernet, address is 0cd9.96e8.7285 (bia 0cd9.96e8.7285)
 MTU 1500 bytes, BW 100000 Kbit, DLY 100 usec,
     reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation ARPA, loopback not set
 Keepalive set (10 sec)
 Full-duplex, 100Mb/s, media type is 10/100BaseTX
 input flow-control is off, output flow-control is unsupported
 ARP type: ARPA, ARP Timeout 04:00:00
 Last input 00:00:45, output 00:00:00, output hang never
 Last clearing of "show interface" counters never
 Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
 Queueing strategy: fifo
 Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
     3362 packets input, 302915 bytes, 0 no buffer
     Received 265 broadcasts (241 multicasts)
     0 runts, 0 giants, 0 throttles
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
     0 watchdog, 241 multicast, 0 pause input
     0 input packets with dribble condition detected
     38967 packets output, 2657748 bytes, 0 underruns
     0 output errors, 0 collisions, 1 interface resets
     0 babbles, 0 late collision, 0 deferred
     0 lost carrier, 0 no carrier, 0 PAUSE output
     0 output buffer failures, 0 output buffers swapped out
```

What is the MAC address for F0/5 on your switch?

Issue the same command and write down the MAC address for F0/6.

Are the OUIs shown on the switch the same as those that were displayed on the router?

The switch keeps track of devices by their Layer 2 MAC addresses. In our topology, the switch has knowledge of both MAC address of R1 and the MAC address of PC-A.

b. Issue the **show mac address-table** command on the switch. A sample is shown below. Use output generated by your switch to answer the questions.

Switch> show mac address-table Mac Address Table Vlan Mac Address Type Ports All 0100.0ccc.cccc STATIC CPU All 0100.0ccc.cccd STATIC CPU

All	0180.c200.0000	STATIC	CPU
All	0180.c200.0001	STATIC	CPU
All	0180.c200.0002	STATIC	CPU
All	0180.c200.0003	STATIC	CPU
All	0180.c200.0004	STATIC	CPU
All	0180.c200.0005	STATIC	CPU
All	0180.c200.0006	STATIC	CPU
All	0180.c200.0007	STATIC	CPU
All	0180.c200.0008	STATIC	CPU
All	0180.c200.0009	STATIC	CPU
All	0180.c200.000a	STATIC	CPU
All	0180.c200.000b	STATIC	CPU
All	0180.c200.000c	STATIC	CPU
All	0180.c200.000d	STATIC	CPU
All	0180.c200.000e	STATIC	CPU
All	0180.c200.000f	STATIC	CPU
All	0180.c200.0010	STATIC	CPU
All	ffff.fff.ffff	STATIC	CPU
1	30f7.0da3.1821	DYNAMIC	Fa0/5
1	<mark>c80a.a9fa.de0d</mark>	DYNAMIC	Fa0/6
[otal	Mac Addresses for	this criteri	on: 22

Did the switch display the MAC address of PC-A? If you answered yes, what port was it on?

Did the switch display the MAC address of R1? If you answered yes, what port was it on?

# Reflection

- 1. Can you have broadcasts at the Layer 2 level? If so, what would the MAC address be?
- 2. Why would you need to know the MAC address of a device?

# **Router Interface Summary Table**

	Router Interface Summary											
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2								
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)								
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)								
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)								
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)								
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)								

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 5.1.4.3 Lab – Using Wireshark to Examine Ethernet Frames





# **Objectives**

Part 1: Examine the Header Fields in an Ethernet II Frame

# Part 2: Use Wireshark to Capture and Analyze Ethernet Frames

# Background / Scenario

When upper layer protocols communicate with each other, data flows down the Open Systems Interconnection (OSI) layers and is encapsulated into a Layer 2 frame. The frame composition is dependent on the media access type. For example, if the upper layer protocols are TCP and IP and the media access is Ethernet, then the Layer 2 frame encapsulation will be Ethernet II. This is typical for a LAN environment.

When learning about Layer 2 concepts, it is helpful to analyze frame header information. In the first part of this lab, you will review the fields contained in an Ethernet II frame. In Part 2, you will use Wireshark to capture and analyze Ethernet II frame header fields for local and remote traffic.

# **Required Resources**

• 1 PC (Windows 7, Vista, or XP with Internet access with Wireshark installed)

# Part 1: Examine the Header Fields in an Ethernet II Frame

In Part 1, you will examine the header fields and content in an Ethernet II Frame. A Wireshark capture will be used to examine the contents in those fields.

Step 1:	<b>Review the Ethernet II hea</b>	ader field descriptions	and lengths.

Preamble	Destination Address	Source Address	Frame Type	Data	FCS
8 Bytes	6 Bytes	6 Bytes	2 Bytes	46 – 1500 Bytes	4 Bytes

# Step 2: Examine the network configuration of the PC.

This PC host IP address is 10.20.164.22 and the default gateway has an IP address of 10.20.164.17.

Ethernet adapter Local Area Connection: Connection-specific DNS Suffix . : cisco.com Link-local IPv6 Address . . . . : fe80::b875:731b:3c7b:c0b1%10 IPv4 Address. . . . . . . : 10.20.164.22 Subnet Mask . . . . . . . . : 255.255.255.240 Default Gateway . . . . . . . : 10.20.164.17

#### Step 3: Examine Ethernet frames in a Wireshark capture.

The Wireshark capture below shows the packets generated by a ping being issued from a PC host to its default gateway. A filter has been applied to Wireshark to view the ARP and ICMP protocols only. The session begins with an ARP query for the MAC address of the gateway router, followed by four ping requests and replies.

🗖 Inte	📶 Intel(R) 82577LM Gigabit Network Connection: \Device\NPF_(6179E093-A447-4EC8-81DF-5E22D08A6F63} [Wireshark 1.8.3 (SVN Rev 45256 from /trunk-1.8)]													
<u>F</u> ile	<u>E</u> dit <u>V</u> iew	<u>G</u> o <u>C</u> apture	<u>A</u> nalyze	<u>Statistics</u>	Telephony	<u>T</u> ools <u>I</u> nte	rnals <u>H</u> elp							
ev ë		🏽 🗎 🗎	) X 2	<b>4</b>   C	<b>)</b> ( ) ( )	ች 🕹		ર્ 🔍 🖻	¥.	M 🐻	%   🛱			
Filter:	arp or icm	ip				-	Expression Clear	Apply Sav	'e					
802.11 (	Channel:	Channel Offs	et: 🔻 FC	S Filter: All	Frames	✓ None	▼ Wireless Set	tings Decŋ	/ption K	eys				
No.	Time	Sou	ce		Destinatio	on	Protoco	l Length	Info					
	7 9.60	1177000 De	1_24:2a	a:60	Broadc	ast	ARP	42	Who h	nas 10.	20.164.17	? Tell 10.	20.164.22	
	8 9.60	1803000 Cis	co_7a:e	ec:84	De11_2	4:2a:60	ARP	60	10.20	.164.1	7 is at 3	0:f7:0d:7a:	ec:84	
	9 9.60	1827000 10.	20.164.	. 22	10.20.	164.17	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=37/9472,	tt1=128
	10 9.60	2807000 10.	20.164.	.17	10.20.	164.22	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=37/9472,	tt1=255
	12 10.6	0418700(10.	20.164.	. 22	10.20.	164.17	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=38/9728,	tt]=128
	13 10.6	2072800(10.	20.164.	.17	10.20.	164.22	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=38/9728,	tt1=255
_	14 11.6	0719200(10.	20.164.	. 22	10.20.	164.17	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=39/9984,	tt]=128
	15 11.6	0817700(10.	20.164.	.17	10.20.	164.22	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=39/9984,	tt1=255
	17 12.6	1025800(10.	20.164.	. 22	10.20.	164.17	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=40/10240	, ttl=128
	18 12.6	1131800(10.	20.164.	.17	10.20.	164.22	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=40/10240	, ttl=255
•						III								- F
🕀 Ena	ame 7: 4	2 bytes on	wire (	336 bits	), 42 bytes	s captur	ed (336 bits)	on inter	face (	)				
	hernet I	I. Src: De	11_24:2	a:60 (5c	:26:0a:24:2	2a:60).	Dst: Broadcas	t (ff:ff:	ff:ff:	ff:ff)				
	Destinat	ion: Broad	cast (f	f:ff:ḟf:	ff:ff:ff)									
	Source:	Dell_24:2a	:60 (5c	:26:0a:2	4:2a:60)									
1 1	Type: AR	P (0x0806)			· · · ·									
+ Add	dress Re	solution P	otocol	(reques	t)									
0000 0010 0020	ff ff 08 00 00 00	FF FF FF FF 06 04 00 01 00 00 00 00	5c 26 5c 26 0a 14	0a 24 0a 24 a4 11	2a 60 08 06 2a 60 0a 14	00 01 a4 16	\& .\$* \& .\$* 							

#### Step 4: Examine the Ethernet II header contents of an ARP request.

The following table takes the first frame in the Wireshark capture and displays the data in the Ethernet II header fields.

Field	Value	Description					
Preamble	Not shown in capture	This field contains synchronizing bits, processed by the NIC hardware.					
Destination Address	Broadcast (ff:ff:ff:ff:ff)	Layer 2 addresses for the frame. Each address is 48 bits long, or 6 octets, expressed as 12 hexadecimal digits, 0-					
Source Address	Dell_24:2a:60 (5c:26:0a:24:2a:60)	<ul> <li>9, A-F.</li> <li>A common format is 12:34:56:78:9A:BC.</li> <li>The first six hex numbers indicate the manufacturer of the network interface card (NIC), the last six hex numbers are the serial number of the NIC.</li> <li>The destination address may be a broadcast, which contains all ones, or a unicast. The source address is always unicast.</li> </ul>					
Frame Type	0x0806	For Ethernet II frames, this field contains a hexadecimal value that is used to indicate the type of upper-layer protocol in the data field. There are numerous upper-layer protocols supported by Ethernet II. Two common frame types are: Value Description 0x0800 IPv4 Protocol 0x0806 Address resolution protocol (ARP)					
Data	ARP	Contains the encapsulated upper-level protocol. The data field is between $46 - 1,500$ bytes.					
FCS	Not shown in capture	Frame Check Sequence, used by the NIC to identify errors during transmission. The value is computed by the sending machine, encompassing frame addresses, type, and data field. It is verified by the receiver.					

What is significant about the contents of the destination address field?

Why does the PC send out a broadcast ARP prior to sending the first ping request?

What is the MAC address of the source in the first frame?

What is the Vendor ID (OUI) of the Source's NIC?

What portion of the MAC address is the OUI?

What is the Source's NIC serial number?

# Part 2: Use Wireshark to Capture and Analyze Ethernet Frames

In Part 2, you will use Wireshark to capture local and remote Ethernet frames. You will then examine the information that is contained in the frame header fields.

#### Step 1: Determine the IP address of the default gateway on your PC.

Open a command prompt window and issue the **ipconfig** command.

What is the IP Address of the PC Default Gateway?

#### Step 2: Start capturing traffic on your PC's NIC.

- a. Open Wireshark.
- b. On the Wireshark Network Analyzer toolbar, click the Interface List icon.



c. On the Wireshark: Capture Interfaces window, select the interface to start traffic capturing by clicking the appropriate check box, and then click **Start**. If you are uncertain of what interface to check, click **Details** for more information about each interface listed.

📶 Wireshark: Captu	ure Interfaces				• ×
	Description	IP	Packets	Packets/s	
🔲 📂 Sun		fe80::50e4:c3e6:b635:a999	26	0	Details
🕡 🔊 Intel(R) 82	2577LM Gigabit Network Connection	fe80::b875:731b:3c7b:c0b1	95	1	<u>D</u> etails
Help	<u>S</u> tart	<u>St</u> op	<u>O</u> ption	s	<u>C</u> lose

d. Observe the traffic that appears in the Packet List window.

Filte	n	Expres	sion Clear	Apply Save
802.1	1 Channel: 💌 Channel Offset: 💌 FCS Filter: All Fra	imes Vone 💌	Wireless Settin	ings Decryption Keys
No.	Time Source	Destination	Protocol	Length Info
	18 10.40268/00(184.2/.190.41	10.20.104.22	ICP	ου πττρs > 6240% [ACK] Seq=1 ACK=1163 W1N=43412 Len=0
	19 10.60449100(184.27.190.41	10.20.164.22	TLSV1	587 Application Data
	20 10.80121900(10.20.164.22	184.27.190.41	TCP	54 62408 > https [ACK] Seq=1163 Ack=534 Win=16695 Len=0
	21 11.04927800(10.20.164.22	10.20.164.31	NBNS	92 Name query NB HP094B61<00>
	22 11.79926500(10.20.164.22	10.20.164.31	NBNS	92 Name query NB HP094B61<00>
	23 12.03732100(cisco_7a:ec:84	Spanning-tree-(for	-br:STP	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0 Port = 0x8001
	24 12.06936200(10.20.164.22	192.168.87.9	SNMP	120 get-request 1.3.6.1.2.1.25.3.2.1.5.1 1.3.6.1.2.1.25.3.5.1.1.1 1.3.6.1.2.1.2
	25 14.03733500(cisco_7a:ec:84	Spanning-tree-(for	-br:STP	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0 Port = 0x8001
	26 16.03704300(cisco_7a:ec:84	Spanning-tree-(for	-br:STP	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0 Port = 0x8001
	27 18.03657200(cisco_7a:ec:84	Spanning-tree-(for	-br:STP	60 Conf. Root = 32768/0/30:f7:0d:7a:ec:84 Cost = 0 Port = 0x8001
	28 19.75046200(10.20.164.22	70.42.228.171	TCP	66 62423 > https [SYN] Seq=0 Win=8192 Len=0 MSS=1260 WS=4 SACK_PERM=1
	29 19.81045200(70.42.228.171	10.20.164.22	TCP	66 https > 62423 [SYN, ACK] Seq=0 Ack=1 Win=5840 Len=0 MSS=1260 SACK_PERM=1 WS
	30 19, 81054600(10, 20, 164, 22	70,42,228,171	TCP	54 62423 > https [ACK] Seg=1 Ack=1 win=66780 Len=0

#### Step 3: Filter Wireshark to display only ICMP traffic.

You can use the filter in Wireshark to block visibility of unwanted traffic. The filter does not block the capture of unwanted data; it only filters what to display on the screen. For now, only ICMP traffic is to be displayed.

In the Wireshark **Filter** box, type **icmp**. The box should turn green if you typed the filter correctly. If the box is green, click **Apply** to apply the filter.

Filter: Icmp Expression Clear Apply Save	Filter:	icmp	•	Expression	Clear	Apply	Save
--	---------	------	---	------------	-------	-------	------

#### Step 4: From the command prompt window, ping the default gateway of your PC.

From the command window, ping the default gateway using the IP address that you recorded in Step 1.

#### Step 5: Stop capturing traffic on the NIC.

Click the **Stop Capture** icon to stop capturing traffic.



## Step 6: Examine the first Echo (ping) request in Wireshark.

The Wireshark main window is divided into three sections: the Packet List pane (top), the Packet Details pane (middle), and the Packet Bytes pane (bottom). If you selected the correct interface for packet capturing in Step 3, Wireshark should display the ICMP information in the Packet List pane of Wireshark, similar to the following example.

🗖 I	🛽 Intel(R) 82577LM Gigabit Network Connection: \Device\NPF_{6179E093-A447-4EC8-81DF-5E22D08A6F63} [Wireshark 1.8.3 (SVN Rev 45256 from /trunk-1.8)]																
<u>F</u> ile	<u>E</u> dit <u>V</u> iew	<u>G</u> o	<u>C</u> apture	<u>A</u> nalyze	<u>S</u> tatistics	Telephony	<u>T</u> ools	Intern	als <u>H</u> el	р							
	₩ Ø 9			🗙 🔁	8 Q	(	I 🖓	₽  [		⊕,⊝		T   👹	¥ 🍢	% 🛛 🔀			
Filte	er: icmp							▼ Đ	pression	Clear	Apply	Save					
802.1	02.11 Channel: 🔽 Channel Offset: 🔽 FCS Filter: All Frames 🔍 None 🔍 Wireless Settings Decryption Keys																
No.	Time		Sourc	e		Destin	ation			Protocol	Lengt	h Info					
	9 9.60	1827	000 10.2	20.164.	22	10.2	0.164.	17		ICMP		74 Echo	(ping)	request	id=0x0001,	seq=37/9472	, tt]=128
	10 9.60	2807	000 10.2	20.164.	L7	10.2	0.164.	22		ICMP		74 Echo	(ping)	reply	id=0x0001,	seq=37/9472	ttl=255
	12 10.6	0418	700(10.2	20.164.	22	10.2	0.164.	17	Ton	ICMP		74 Echo	(ping)	request	id=0x0001,	seq=38/9728	, ttl=128
	13 10.0	2072	800(10.2	20.164.	17	10.2	0.164.	22	rop	ICMP		74 Echo	(ping)	reply	1d=0x0001,	seq=38/9728	, ttl=255
	14 11.0	0/19	200(10.2	20.164.	22	10.2	0.164.	17		ICMP		74 ECNO	(ping)	request	1d=0x0001,	seq=39/9984	, TTI=128
	17 12 4	1025	/00(10.2	20.164.	L/	10.2	0.164.	17		TCMP		74 ECHO	(ping)	repty	id=0x0001,	seq=39/9984	, LLI=200
	18 12 6	1121	800(10.2	20.104.	17	10.2	0.164	22		TCMP		74 ECHO	(ping)	request	id=0x0001,	seq=40/10240	++1-255
	10 12.0	1111	000(10.2		L/	10.2	0.104.	~~		TCHE		74 ECHO	(ping)	терту	10-000001,	3Eq=40/10240	,=255
4																	
												~	-				
÷F	rame 9: 7	4 by	tes on i	wire (5	92 bits;	, 74 by	tes cap	tured	1 (592	bits) (	on int	erface	0				
± E	thernet	1, 5	rc: Del	1_24:2a	:60 (SC	26:0a:24	1:2a:60	), Ds	ST: C19	sco_/a:	ec:84	(30:17:	0d:/a:e	C:84)			
	nternet i	roto	cor ver:	sion 4,	Src: 10	0.20.164	22 (10	0.20.1	164.22	), DST:	10.20	).164.17	(10.20	.164.17)			
± 1	Middle																
000 001 002 003 004	000 30 f7 0d 7a ec 84 5c 26 0a 24 2a 60 08 00 45 00 010 00 3c 19 b3 00 00 80 01 c4 be 0a 14 a4 16 0a 14 020 a4 11 08 00 4d 36 00 01 00 25 6l 62 63 64 65 66 030 67 68 69 6a 6b 6c 6d 6e 6f 70 71 72 73 74 75 76 040 77 6l 62 63 64 65 66 67 68 69 wabcdefg hi 040 77 6l 62 63 64 65 66 67 68 69 040 77 61 72 73 74 75 76 040 72 72 74 75 76 040 72 75 76																
	Bottom																

- a. In the Packet List pane (top section), click the first frame listed. You should see **Echo (ping) request** under the **Info** heading. This should highlight the line blue.
- b. Examine the first line in the Packet Details pane (middle section). This line displays the length of the frame; 74 bytes in this example.
- c. The second line in the Packet Details pane shows that it is an Ethernet II frame. The source and destination MAC addresses are also displayed.

What is the MAC address of the PC's NIC?

What is the default gateway's MAC address?

d. You can click the plus (+) sign at the beginning of the second line to obtain more information about the Ethernet II frame. Notice that the plus sign changes to a minus (-) sign.

What type of frame is displayed? \_

e. The last two lines displayed in the middle section provide information about the data field of the frame. Notice that the data contains the source and destination IPv4 address information.

What is the source IP address?

What is the destination IP address?

f. You can click any line in the middle section to highlight that part of the frame (hex and ASCII) in the Packet Bytes pane (bottom section). Click the **Internet Control Message Protocol** line in the middle section and examine what is highlighted in the Packet Bytes pane.

B Frame 7: 74 bytes on wire (592 bits), 74 bytes captured (592 bits) on interface 0 B Ethernet II, Src: pell_24:2a:60 (5c:26:0a:24:2a:60), Dst: Cisco_7a:ec:84 (30:f7:0d:7a:ec:84)						
B Internet Protocol Version 4, Src: 10.20.164.22 (10.20.164.22), Dst: 10.20.164.17 (10.20.164.17)						
Internet Control Message Protocol						
Type: 8 (Echo (ping) request)						
Code: 0						
Checksum: 0x4d4e [correct]	Ŧ					
0000       30 f7 0d 7a ec 84 5c 26       0a 24 2a 60 08 00 45 00       0z\& .\$*`.E.         0010       00 3c 03 48 00 00 80 01       db 29 0a 14 a4 16 0a 14						

What do the last two highlighted octets spell? \_\_\_\_\_

g. Click the next frame in the top section and examine an Echo reply frame. Notice that the source and destination MAC addresses have reversed, because this frame was sent from the default gateway router as a reply to the first ping.

What device and MAC address is displayed as the destination address?

#### Step 7: Restart packet capture in Wireshark.

Click the **Start Capture** icon to start a new Wireshark capture. You will receive a popup window asking if you would like to save the previous captured packets to a file before starting a new capture. Click **Continue** without Saving.



#### Step 8: In the command prompt window, ping <u>www.cisco.com</u>.

#### Step 9: Stop capturing packets.



#### Step 10: Examine the new data in the packet list pane of Wireshark.

In the first echo (ping) request frame, what are the source and destination MAC addresses?

Source: \_\_\_

Destination:

What are the source and destination IP addresses contained in the data field of the frame?

Source: \_\_\_\_\_

Destination: \_\_\_\_\_

Compare these addresses to the addresses you received in Step 7. The only address that changed is the destination IP address. Why has the destination IP address changed, while the destination MAC address remained the same?

#### Reflection

Wireshark does not display the preamble field of a frame header. What does the preamble contain?

# 5.2.1.8 Lab – Observing ARP with the Windows CLI, IOS CLI, and Wireshark

Topology



# **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
S2	VLAN 1	192.168.1.12	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-B	NIC	192.168.1.2	255.255.255.0	192.168.1.1

# **Objectives**

- Part 1: Build and Configure the Network
- Part 2: Use the Windows ARP Command
- Part 3: Use the IOS Show ARP Command
- Part 4: Use Wireshark to Examine ARP Exchanges

# **Background / Scenario**

The Address Resolution Protocol (ARP) is used by TCP/IP to map a Layer 3 IP address to a Layer 2 MAC address. When a frame is placed on the network, it must have a destination MAC address. To dynamically

discover the MAC address for the destination device, an ARP request is broadcast on the LAN. The device that contains the destination IP address responds, and the MAC address is recorded in the ARP cache. Every device on the LAN keeps its own ARP cache, or small area in RAM that holds ARP results. An ARP cache timer removes ARP entries that have not been used for a certain period of time.

ARP is an excellent example of performance tradeoff. With no cache, ARP must continually request address translations each time a frame is placed on the network. This adds latency to the communication and could congest the LAN. Conversely, unlimited hold times could cause errors with devices that leave the network or change the Layer 3 address.

A network administrator should be aware of ARP, but may not interact with the protocol on a regular basis. ARP is a protocol that enables network devices to communicate with the TCP/IP protocol. Without ARP, there is no efficient method to build the datagram Layer 2 destination address. Also, ARP is a potential security risk. ARP spoofing, or ARP poisoning, is a technique used by an attacker to inject the wrong MAC address association in a network. An attacker forges the MAC address of a device, and frames are sent to the wrong destination. Manually configuring static ARP associations is one way to prevent ARP spoofing. Finally, an authorized MAC address list may be configured on Cisco devices to restrict network access to only approved devices.

In this lab, you will use the ARP commands in both Windows and Cisco routers to display the ARP table. You will also clear the ARP cache and add static ARP entries.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

# **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 2 Switches (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term and Wireshark installed)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

**Note**: The Fast Ethernet interfaces on Cisco 2960 switches are autosensing and an Ethernet straight-through cable may be used between switches S1 and S2. If using another Cisco switch model, it may be necessary to use an Ethernet crossover cable.

# Part 1: Build and Configure the Network

- Step 1: Cable the network according to the topology.
- Step 2: Configure the IP addresses for the devices according to the Addressing Table.
- Step 3: Verify network connectivity by pinging all the devices from PC-B.

# Part 2: Use the Windows ARP Command

The **arp** command allows the user to view and modify the ARP cache in Windows. You access this command from the Windows command prompt.

#### Step 1: Display the ARP cache.

a. Open a command window on PC-A and type arp.

C:\Users\User1> **arp** 

```
Displays and modifies the IP-to-Physical address translation tables used by address resolution protocol (ARP).
```

ARP -s inet\_addr eth\_addr [if\_addr]
ARP -d inet\_addr [if\_addr]
ARP -a [inet addr] [-N if addr] [-v]

-a	Displays current ARP entries by interrogating the current
	protocol data. If inet_addr is specified, the IP and Physical
	addresses for only the specified computer are displayed. If
	more than one network interface uses ARP, entries for each ARP
	table are displayed.
-g	Same as -a.
-v	Displays current ARP entries in verbose mode. All invalid
	entries and entries on the loop-back interface will be shown.
inet_addr	Specifies an internet address.
-N if_addr	Displays the ARP entries for the network interface specified
	by if_addr.
-d	Deletes the host specified by inet_addr. inet_addr may be
	wildcarded with $*$ to delete all hosts.
-s	Adds the host and associates the Internet address inet_addr
	with the Physical address eth addr. The Physical address is
	given as 6 hexadecimal bytes separated by hyphens. The entry
	is permanent.
eth addr	Specifies a physical address.
_ if addr	If present, this specifies the Internet address of the
—	interface whose address translation table should be modified.
	If not present, the first applicable interface will be used.
Example:	
> arp -s 157.	55.85.212 00-aa-00-62-c6-09 Adds a static entry.
> arp -a	Displays the arp table.
-	

b. Examine the output.

```
c. Type arp –a to display the ARP table.
```

```
C:\Users\User1> arp -a
```

```
Interface: 192.168.1.3 --- 0xb
 Internet Address Physical Address
                                     Type
                  d4-8c-b5-ce-a0-c1
 192.168.1.1
                                     dynamic
 192.168.1.255
                  ff-ff-ff-ff-ff static
 224.0.0.22
                   01-00-5e-00-00-16
                                     static
 224.0.0.252
                   01-00-5e-00-00-fc
                                     static
 239.255.255.250
                   01-00-5e-7f-ff-fa
                                     static
```

Note: The ARP table is empty if you use Windows XP (as displayed below).

C:\Documents and Settings\User1> **arp** -**a** No ARP Entries Found.

d. Ping from PC-A to PC-B to dynamically add entries in the ARP cache.

C:\Documents and Settings\User1> ping 192.168.1.2

```
Interface: 192.168.1.3 --- 0xb
Internet Address Physical Address Type
192.168.1.2 00-50-56-be-f6-db dynamic
```

What is the physical address for the host with IP address of 192.168.1.2?

#### Step 2: Adjust entries in the ARP cache manually.

To delete entries in ARP cache, issue the command **arp –d {inet-addr | \*}**. Addresses can be deleted individually by specifying the IP address, or all entries can be deleted with the wildcard \*.

Verify that the ARP cache contains the following entries: the R1 G0/1 default gateway (192.168.1.1), PC-B (192.168.1.2) and both switches (192.168.1.11 and 192.168.1.12).

- a. From PC-A, ping all the addresses in the Address Table.
- b. Verify that all the addresses have been added to the ARP cache. If the address is not in ARP cache, ping the destination address and verify that the address was added to the ARP cache.

C:\Users\User1> **arp** -a

Interface: 192.168.1.3 --- 0xb

Internet Address	Physical Address	Туре
192.168.1.1	d4-8c-b5-ce-a0-c1	dynamic
192.168.1.2	00-50-56-be-f6-db	dynamic
192.168.1.11	0c-d9-96-e8-8a-40	dynamic
192.168.1.12	0c-d9-96-d2-40-40	dynamic
192.168.1.255	ff-ff-ff-ff-ff	static
224.0.0.22	01-00-5e-00-00-16	static

224.0.0.252	01-00-5e-00-00-fc	static
239.255.255.250	01-00-5e-7f-ff-fa	static

c. As an administrator, access the command prompt. Click the Start icon, and in the Search programs and file box, type cmd. When the cmd icon appears, right-click the icon and select Run as administrator. Click Yes to allow this program to make changes.

**Note**: For Windows XP users, it is not necessary to have administrator privileges to modify ARP cache entries.

_	_	Open			
	0	Run as administrator			
		Pin to Taskbar			
		Pin to Start Menu			
		Restore previous versions			
		Send to			
		Cut			
		Сору			
		Delete			
		Open file location			
		Properties			
	_				
See more	recults				
Jee more	results				

d. In the Administrator command prompt window, type **arp –d**\*. This command deletes all the ARP cache entries. Verify that all the ARP cache entries are deleted by typing **arp –a** at the command prompt.

```
C:\windows\system32> arp -d *
C:\windows\system32> arp -a
No ARP Entries Found.
```

e. Wait a few minutes. The Neighbor Discovery protocol starts to populate the ARP cache again.

C:\Users\User1> arp -a

Interface:	192.168.1.3		0xb		
Internet	Address	Phy	rsical	Address	Туре
192.168.1	L.255	ff-	ff-ff-	-ff-ff-ff	static

Note: The Neighbor Discovery protocol is not implemented in Windows XP.

f. From PC-A, ping PC-B (192.168.1.2) and the switches (192.168.1.11 and 192.168.1.12) to add the ARP entries. Verify that the ARP entries have been added to the cache.

```
C:\Users\User1> arp -a
```

Γr	nterface: 192.168.1.3	0xb	
	Internet Address	Physical Address	Туре
	192.168.1.2	00-50-56-be-f6-db	dynamic
	192.168.1.11	0c-d9-96-e8-8a-40	dynamic
	192.168.1.12	0c-d9-96-d2-40-40	dynamic
	192.168.1.255	ff-ff-ff-ff-ff	static

- g. Record the physical address for switch S2.
- h. Delete a specific ARP cache entry by typing **arp –d** *inet-addr*. At the command prompt, type **arp -d 192.168.1.12** to delete the ARP entry for S2.

C:\windows\system32> arp -d 192.168.1.12

i. Type **arp** –**a** to verify that the ARP entry for S2 has been removed from the ARP cache.

C:\Users\User1> arp -a

Interface: 192.168.1.3	0xb	
Internet Address	Physical Address	Туре
192.168.1.2	00-50-56-be-f6-db	dynamic
192.168.1.11	0c-d9-96-e8-8a-40	dynamic
192.168.1.255	ff-ff-ff-ff-ff	static

j. You can add a specific ARP cache entry by typing arp -s inet\_addr mac\_addr. The IP address and MAC address for S2 will be used in this example. Use the MAC address recorded in step g.

C:\windows\system32> arp -s 192.168.1.12 0c-d9-96-d2-40-40

k. Verify that the ARP entry for S2 has been added to the cache.

# Part 3: Use the IOS show arp Command

The Cisco IOS can also display the ARP cache on routers and switches with the **show arp** or **show ip arp** command.

#### Step 1: Display ARP entries on router R1.

```
R1# show arpProtocolAddressAge (min)Hardware AddrTypeInterfaceInternet192.168.1.1-d48c.b5ce.a0c1ARPAGigabitEthernet0/1Internet192.168.1.200050.56be.f6dbARPAGigabitEthernet0/1Internet192.168.1.300050.56be.768cARPAGigabitEthernet0/1R1#
```

Notice there is no Age (-) for the first entry, router interface G0/1 (the LAN default gateway). The Age is the number of minutes (min) that the entry has been in ARP cache and is incremented for the other entries. The Neighbor Discovery protocol populates the PC-A and PC-B IP and MAC address ARP entries.

#### Step 2: Add ARP entries on router R1.

You can add ARP entries to the ARP table of the router by pinging other devices.

a. Ping switch S1.

```
R1# ping 192.168.1.11
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.1.11, timeout is 2 seconds:
.!!!!
Success rate is 80 percent (4/5), round-trip min/avg/max = 1/2/4 ms
```

b. Verify that an ARP entry for switch S1 has been added to the ARP table of R1.

```
R1# show ip arp
Protocol Address
                         Age (min) Hardware Addr
                                                  Туре
                                                         Interface
Internet 192.168.1.1
                                   d48c.b5ce.a0c1 ARPA GigabitEthernet0/1
                                _
                                   0050.56be.f6db ARPA
Internet 192.168.1.2
                                                         GigabitEthernet0/1
                                6
Internet 192.168.1.3
                                6
                                   0050.56be.768c ARPA
                                                         GigabitEthernet0/1
Internet 192.168.1.11
                              0
                                   Ocd9.96e8.8a40 ARPA GigabitEthernet0/1
R1#
```

#### Step 3: Display ARP entries on switch S1.

```
S1# show ip arp
Protocol Address
                                   Hardware Addr
                         Age (min)
                                                   Type
                                                          Interface
Internet 192.168.1.1
                               46
                                    d48c.b5ce.a0c1 ARPA
                                                          Vlan1
Internet 192.168.1.2
                                8
                                    0050.56be.f6db ARPA Vlan1
Internet 192.168.1.3
                                8
                                    0050.56be.768c ARPA Vlan1
Internet 192.168.1.11
                                _
                                    Ocd9.96e8.8a40 ARPA Vlan1
S1#
```

#### Step 4: Add ARP entries on switch S1.

By pinging other devices, ARP entries can also be added to the ARP table of the switch.

a. From switch S1, ping switch S2.

```
S1# ping 192.168.1.12
```

```
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.1.12, timeout is 2 seconds:
.!!!!
Success rate is 80 percent (4/5), round-trip min/avg/max = 1/2/8 ms
```

b. Verify that the ARP entry for switch S2 has been added to ARP table of S1.

```
S1# show ip arp
Protocol Address
                         Age (min)
                                   Hardware Addr
                                                   Type
                                                         Interface
Internet 192.168.1.1
                                5
                                   d48c.b5ce.a0c1 ARPA Vlan1
Internet 192.168.1.2
                               11
                                   0050.56be.f6db ARPA
                                                         Vlan1
Internet 192.168.1.3
                                    0050.56be.768c ARPA Vlan1
                               11
Internet 192.168.1.11
                                _
                                    0cd9.96e8.8a40 ARPA
                                                         Vlan1
Internet 192.168.1.12
                               2
                                  0cd9.96d2.4040 ARPA Vlan1
```

#### S1#

# Part 4: Use Wireshark to Examine ARP Exchanges

In Part 4, you will examine ARP exchanges by using Wireshark to capture and evaluate the ARP exchange. You will also examine network latency caused by ARP exchanges between devices.

#### Step 1: Configure Wireshark for packet captures.

- a. Start Wireshark.
- b. Choose the network interface to use for capturing the ARP exchanges.

#### Step 2: Capture and evaluate ARP communications.

- a. Start capturing packets in Wireshark. Use the filter to display only ARP packets.
- b. Flush the ARP cache by typing the **arp –d** \* command at the command prompt.
- c. Verify that the ARP cache has been cleared.
- d. Send a ping to the default gateway, using the ping 192.168.1.1 command.
- e. Stop the Wireshark capture after pinging to the default gateway is finished.
- f. Examine the Wireshark captures for the ARP exchanges in the packet details pane. What was the first ARP packet? \_\_\_\_\_

<u>F</u> ile	<u>E</u> dit <u>V</u> iew <u>G</u> o	<u>Capture</u> <u>A</u> nalyze <u>S</u>	tatistics Telephony	<u>T</u> ools <u>I</u> ntern	als <u>H</u> elp		
		🖹 🖥 🗶 🛃	l 🔍 🗢 🛸 🏟	₮ ⊻  (		⊕, ⊖, ₪, 🖭   👹	1 🛃 💥 🕅
Filter:	arp			<b>▼</b> Ð	pression	Clear Apply Save	
No.	Time	Source	Destination	Protocol	Length	Info	
6	1.795609000	Dell_19:55:92	Broadcast	ARP	42	Who has 192.168.1.	1? Tell 192.168.1.3
7	1.796075000	Cisco_45:73:a1	Dell_19:55:92	ARP	60	)192.168.1.1 is at	c4:71:fe:45:73:a1
•			III				
	ame 6: 42 byt hernet II, Sr dress Resolut Hardware type Protocol type Hardware size Protocol size Opcode: reque Sender MAC ac Sender IP add Target IP add	tes on wire (336 c: Dell_19:55:9 tion Protocol (n 2: Ethernet (1) 2: IP (0x0800) 2: 6 2: 4 2st (1) ddress: Dell_19: ddress: 192.168.1 ddress: 00:00:00 dress: 192.168.1	bits), 42 bytes 2 (5c:26:0a:19: equest) 55:92 (5c:26:0a: .3 (192.168.1.3) _00:00:00 (00:00 .1 (192.168.1.1)	s captured 55:92), Ds 19:55:92) 0:00:00:00 0	l (336 b t: Broa	nits) on interface ( dcast (ff:ff:ff:ff	) :ff:ff)
0000 0010 0020	ff ff ff ff 08 00 06 04 00 00 00 00	ff ff 5c 26 0 00 01 5c 26 0 00 00 c0 a8 0	a 19 55 92 08 06 a 19 55 92 c0 a8 1 01	00 01 01 03	·····	&U &U	

Fill in the following table with information about your first captured ARP packet.

Field	Value
Sender MAC address	
Sender IP address	
Target MAC address	
Target IP address	

What was the second ARP packet?

<u>F</u> ile <u>E</u>	dit <u>V</u> iew	<u>G</u> o	<u>C</u> apture	<u>A</u> nal	yze <u>S</u> t	atistic	s Te	lepho	n <u>y 1</u>	[ools	Interna	als <u>H</u> el	р												
	i 🗐 🔘			<b>X</b>	2		2, <	•	· 🎝	Ŧ	₽  [		]  @	Ð,	Q	11	++	Ì	<b>V</b> [	2		*		1	
Filter:	arp										▼ Ex	pression	C	Clear	r Aş	oply	Sav	ve							
No. T	ime		Source			Desti	natio	n		P	rotocol	Length	n Ir	nfo											
61	.795609	000	Dell_1	45:7	3:a1	Bro	adca	IST 1:55:	92	A	RP RP		42 W 60 1	nno 192	na:	5 19 8.1	92.1	168 is	at (	1? c4:	Те 71	211 :fe:	192	.168	3.1.3
																				_					
		. I			(100	6.2.4	->					(100	6.24					<i>c</i>							
⊞ Fran	ne /: 60 ernet TT	byt Sr	es on c: Cis	co 4	(480 5:73:	01t	s), c4:7	60 D 1:fe	ytes :45:	73:	al). D	(480 st: D	011 e11	19	on :55	1m :92	cer (5	тас с:2	ce 0 26:0	a:1	9:	55:9	92)		
⊟ Addr	ress Res	olut	ion Pr	otoc	ol (r	eply	)																		
Ha	ardware	type	: Ethe	rnet	(1)																				
Pr	rotocol	type	: IP (	0x08	00)																				
Ha	ardware	size	: 6																						
Pr	rotocol	size	: 4																						
54	ender MA	c ad	dress.	cis	co 45	.73.	a1 (	c4 · 7	1·fe		.73.a1	2													
56	ender IP	add	ress:	192.	168.1	.1 0	192.	168.	1.1)			·													
Та	arget MA	c ad	dress:	Del	1_19:	55:9	2 (5	c:26	:0a:	19:	55:92)														
Та	arget IP	add	ress:	192.	168.1	.3 (	192.	168.	1.3)																
0000	5c 26 0	a 19	55 92	c4 7	71 fe	45	73	a1 08	3 06	00	01	\&U.	. a	. ES	5										
0010	08 00 0	6 04	00 02	c4 7	71 fe	e 45	73	a1 c(	) a8	01	01		. q	. Es	5										
0020	5C 26 0	a 19 0 00	55 92	C0 a	18 01 00 00	L 03	00 0	00 00	00 0	00	00	\&U.	••	•••	• • • •	••									
0000	00 00 0	0.00	00 00	00 (		,	00 1						•••												

Fill in the following table with information about your second captured ARP packet.

Field	Value
Sender MAC address	
Sender IP address	
Target MAC address	
Target IP address	

#### Step 3: Examine network latency caused by ARP.

- a. Clear the ARP entries on PC-A.
- b. Start a Wireshark capture.
- c. Ping switch S2 (192.168.1.12). The ping should be successful after the first echo request.

Note: If all the pings were successful, S1 should be reloaded to observe network latency with ARP.

```
C:\Users\User1> ping 192.168.1.12
Request timed out.
Reply from 192.168.1.12: bytes=32 time=2ms TTL=255
Reply from 192.168.1.12: bytes=32 time=2ms TTL=255
Reply from 192.168.1.12: bytes=32 time=2ms TTL=255
Ping statistics for 192.168.1.12:
    Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
Approximate round trip times in milli-seconds:
```

Minimum = 1ms, Maximum = 3ms, Average = 2ms

- d. Stop the Wireshark capture after the pinging is finished. Use the Wireshark filter to display only ARP and ICMP outputs. In Wireshark, type **arp or icmp** in the **Filter:** entry area.
- e. Examine the Wireshark capture. In this example, frame 10 is the first ICMP request sent by PC-A to S1. Because there is no ARP entry for S1, an ARP request was sent to the management IP address of S1 asking for the MAC address. During the ARP exchanges, the echo request did not receive a reply before the request was timed out. (frames 8 12)

After the ARP entry for S1 was added to the ARP cache, the last three ICMP exchanges were successful, as displayed in frames 26, 27 and 30 - 33.

As displayed in the Wireshark capture, ARP is an excellent example of performance tradeoff. With no cache, ARP must continually request address translations each time a frame is placed on the network. This adds latency to the communication and could congest the LAN.

<u>F</u> ile	<u>E</u> dit <u>V</u> iew	<u>G</u> o	<u>C</u> apture <u>A</u> nalyze <u>S</u> t	atistics Telephony	<u>T</u> ools <u>I</u> nter	mals <u>H</u> e	lp				
			🖻 🖬 🗶 🈂 🖉	]  ○ ( ⇔ 🔹 😜	) 🕁 🕹		]  €	Q 10	TT 🕌	¥ 🖪 🔆	Ø
Filter	arp or icmp				<b>•</b> I	Expressior	n Cle	ar Apply	Save		
No.	Time		Source	Destination	Protocol l	Length	Info				
8	1.6499290	000	Dell_19:55:92	Broadcast	ARP	42	who ł	nas 192	.168.1.12	? Tell 192	.168.1.3
9	1.6512020	000	Cisco_59:91:c0	Dell_19:55:92	ARP	60	192.1	168.1.1	2 is at O	0:23:5d:59:	91:c0
10	1.6514890	000	192.168.1.3	192.168.1.12	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=1873
11	1.6537900	000	<pre>cisco_59:91:c0</pre>	Broadcast	ARP	60	who ł	nas 192	.168.1.3?	те]] 192.	168.1.12
12	1.6539990	000	Dell_19:55:92	Cisco_59:91:c0	ARP	42	192.1	168.1.3	is at 5c	:26:0a:19:5	5:92
26	6.5624090	000	192.168.1.3	192.168.1.12	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=1874
27	6.5644260	000	192.168.1.12	192.168.1.3	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=1874
30	7.5609770	000	192.168.1.3	192.168.1.12	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=1875
31	7.5635860	000	192.168.1.12	192.168.1.3	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=1875
32	8.5593520	000	192.168.1.3	192.168.1.12	ICMP	74	Echo	(ping)	request	id=0x0001,	seq=1876
33	8.5604660	000	192.168.1.12	192.168.1.3	ICMP	74	Echo	(ping)	reply	id=0x0001,	seq=1876
•											•
🕀 Er	ame 8: 42	bvt	es on wire (336	bits), 42 byte	s capture	ed (336	bits	) on ir	nterface (	)	
+ Et	hernet II,	, sr	c: Dell_19:55:9	2 (5c:26:0a:19:	55:9 <sup>2</sup> ), c	ost: Br	oadca	st (ff:	ff:ff:ff:	ff:ff)	
🗆 Ad	dress Reso	Jut	ion Protocol (r	equest)							
	Hardware t	type	: Ethernet (1)	1 1							
	Protocol t	type	: IP (0x0800)								
	Hardware s	ize	: 6								
	Protocol s	ize	: 4								
	Opcode: request (1)										
	Sender MAC address: Dell 19:55:92 (5c:26:0a:19:55:92)										
	Sender IP address: 192.168.1.3 (192.168.1.3)										
	Target MAC address: 00:00:00 00:00:00 (00:00:00:00:00)										
	Target IP address: 192.168.1.12 (192.168.1.12)										
0000		££	ff ff 5a 36 0a	10 55 03 00 00	. 00. 01		\ 0				
0000	08 00 06	04	00 01 5c 26 03	10 55 02 C0 38 10 55 02 C0 38	2 01 03		.\&	. 0			
0020	00 00 00	00	00 00 c0 a8 01	. 0C	, 01 05		(œ				
								-			

#### Reflection

- 1. How and when are static ARP entries removed?
- 2. Why do you want to add static ARP entries in the cache?
- 3. If ARP requests can cause network latency, why is it a bad idea to have unlimited hold times for ARP entries?

Router Interface Summary									
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2					
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)					
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					

# **Router Interface Summary Table**

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 5.3.1.10 Lab - Using IOS CLI with Switch MAC Address Tables

# Topology



# **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
S2	VLAN 1	192.168.1.12	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-B	NIC	192.168.1.2	255.255.255.0	192.168.1.1

# **Objectives**

#### Part 1: Build and Configure the Network

- Cable the network according to the topology diagram.
- Configure the network devices according to the Addressing Table.

#### Part 2: Examine the Switch MAC Address Table

• Use **show** commands to observe the process of building the switch MAC address table.

# **Background / Scenario**

The purpose of a Layer 2 LAN switch is to deliver Ethernet frames to host devices on the local network. The switch records host MAC addresses that are visible on the network, and maps those MAC addresses to its own Ethernet switch ports. This process is called building the MAC address table. When a switch receives a frame from a PC, it examines the frame's source and destination MAC addresses. The source MAC address

is recorded and mapped to the switch port from which it arrived. Then the destination MAC address is looked up in the MAC address table. If the destination MAC address is a known address, then the frame is forwarded out of the corresponding switch port of the MAC address. If the MAC address is unknown, then the frame is broadcast out of all switch ports, except the one from which it came. It is important to observe and understand the function of a switch and how it delivers data on the network. The way a switch operates has implications for network administrators whose job it is to ensure secure and consistent network communication.

Switches are used to interconnect and deliver information to computers on local area networks. Switches deliver Ethernet frames to host devices identified by network interface card MAC addresses.

In Part 1, you will build a multi-switch and router topology with a trunk linking the two switches. In Part 2, you will ping various devices and observe how the two switches build their MAC address tables.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 2 Switches (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

**Note**: The Fast Ethernet interfaces on Cisco 2960 switches are autosensing and an Ethernet straight-through cable may be used between switches S1 and S2. If using another model Cisco switch, it may be necessary to use an Ethernet crossover cable.

# Part 1: Build and Configure the Network

- Step 1: Cable the network according to the topology.
- Step 2: Configure PC hosts.
- Step 3: Initialize and reload the routers and switches as necessary.

#### Step 4: Configure basic settings for each switch.

- a. Configure device name as shown in the topology.
- b. Configure IP address and default gateway as listed in Addressing Table.
- c. Assign **cisco** as the console and vty passwords.
- d. Assign **class** as the privileged EXEC password.

#### Step 5: Configure basic settings for the router.

- a. Disable DNS lookup.
- b. Configure IP address for the router as listed in Addressing Table.
- c. Configure device name as shown in the topology.
- d. Assign cisco as the console and vty passwords.
- e. Assign **class** as the privileged EXEC password.

# Part 2: Examine the Switch MAC Address Table

A switch learns MAC addresses and builds the MAC address table, as network devices initiate communication on the network.

#### Step 1: Record network device MAC addresses.

a. Open a command prompt on PC-A and PC-B and type **ipconfig /all**. What are the Ethernet adapter physical addresses?

PC-A MAC Address: \_\_\_\_\_

PC-B MAC Address: \_\_\_\_

b. Console into router R1 and type the **show interface G0/1** command. What is the hardware address?

R1 Gigabit Ethernet 0/1 MAC Address: \_

c. Console into switch S1 and S2 and type the **show interface F0/1** command on each switch. On the second line of command output, what is the hardware addresses (or burned-in address [bia])?

S1 Fast Ethernet 0/1 MAC Address: \_\_\_\_

S2 Fast Ethernet 0/1 MAC Address: \_\_\_\_

#### Step 2: Display the switch MAC address table.

Console into switch S2 and view the MAC address table, both before and after running network communication tests with ping.

- a. Establish a console connection to S2 and enter privileged EXEC mode.
- b. In privileged EXEC mode, type the show mac address-table command and press Enter.

#### S2# show mac address-table

Even though there has been no network communication initiated across the network (i.e., no use of ping), it is possible that the switch has learned MAC addresses from its connection to the PC and the other switch.

Are there any MAC addresses recorded in the MAC address table?

What MAC addresses are recorded in the table? To which switch ports are they mapped and to which devices do they belong? Ignore MAC addresses that are mapped to the CPU.

If you had not previously recorded MAC addresses of network devices in Step 1, how could you tell which devices the MAC addresses belong to, using only the output from the **show mac address-table** command? Does it work in all scenarios?



#### Step 3: Clear the S2 MAC address table and display the MAC address table again.

a. In privileged EXEC mode, type the clear mac address-table dynamic command and press Enter.

```
S2# clear mac address-table dynamic
```

b. Quickly type the **show mac address-table** command again. Does the MAC address table have any addresses in it for VLAN 1? Are there other MAC addresses listed?

Wait 10 seconds, type the **show mac address-table** command, and press Enter. Are there new addresses in the MAC address table? \_\_\_\_\_\_

# Step 4: From PC-B, ping the devices on the network and observe the switch MAC address table.

- a. From PC-B, open a command prompt and type **arp -a**. Not including multicast or broadcast addresses, how many device IP-to-MAC address pairs have been learned by ARP?
- b. From the PC-B command prompt, ping the router/gateway R1, PC-A, S1, and S2. Did all devices have successful replies? If not, check your cabling and IP configurations.
- c. From a console connection to S2, enter the **show mac address-table** command. Has the switch added additional MAC addresses to the MAC address table? If so, which addresses and devices?

From PC-B, open a command prompt and retype **arp** -**a**. Does the PC-B ARP cache have additional entries for all network devices that were sent pings?

## Reflection

On Ethernet networks, data is delivered to devices by their MAC addresses. For this to happen, switches and PCs dynamically build ARP caches and MAC address tables. With only a few computers on the network this process seems fairly easy. What might be some of the challenges on larger networks?

Router	Interface	Summary	Table
--------	-----------	---------	-------

Router Interface Summary								
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2				
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)				
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				

Note: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 5.4.1.1 MAC and choose...

# Objectives

#### Explain basic switching concepts.

In this activity, you will indicate your knowledge of Ethernet technology by successfully comparing legacy to current standards. You will speculate on potential future Ethernet technology standards, and explain why MAC addresses and framing formats have stayed basically the same, in order to assist data transmission, during Ethernet's evolution.

# Background/Scenario

Note: This activity is best completed in groups of 2-3 students.

Please view the video, The History of Ethernet, located at the following link:

http://www.netevents.tv/video/bob-metcalfe-the-history-of-ethernet

Topics discussed in the video include not only where we have come from in Ethernet development, but where we are going with Ethernet technology in the future!

- 1. After viewing the video and comparing its contents to Chapter 10, go to the web and search for information about Ethernet:
  - How was Ethernet used when it was first developed?
  - How has Ethernet stayed the same over the past 25 years? What changes are being made to make it more useful and applicable to today's data transmission methods?
- 2. Collect three pictures of old, current, and possible future Ethernet physical media and devices. Focus your search on switches if possible. Share these pictures with the class and discuss:
  - How have Ethernet physical media and intermediary devices changed?
  - How have Ethernet physical media and intermediary devices stayed the same?
  - How do you think the Ethernet will change in the future? What factors could influence these changes?

#### **Required Resources**

- Internet access to video, History of Ethernet, located at: <u>http://www.netevents.tv/video/bob-metcalfe-the-history-of-ethernet</u>
- Hard- or soft-copy media for recording answers to questions and for in-class sharing.

#### Reflection

- 1. How was Ethernet used when it was first developed?
- 2. How has Ethernet stayed the same over the past 25 years? What changes are being made to make it more useful and applicable to today's data transmission methods?

- 3. How have Ethernet physical media and intermediary devices changed?
- 4. How have Ethernet physical media and intermediary devices stayed the same?
- 5. How do you think the Ethernet will change in the future? What factors could influence these changes?

# 6.0.1.2 The road less traveled...or is it?

# **Objectives**

#### Explain how network devices use routing tables to direct packets to a destination network.

In this activity, you will visualize how a hop-by-hop routing paradigm, with correct path selection at each hop, results in a successful delivery of packets. You will recognize that each router on the path must have correct knowledge about the destination network, and that path towards that network, to deliver packets over the shortest path.

# Background/Scenario

During the upcoming weekend, you decide to visit a schoolmate who is currently at home sick. You know his street address but you have never been to his town before. Instead of looking up the address on the map, you decide to take it easy and to simply ask town residents for directions after you arrive by train.

The citizens you ask for directions are very helpful. However, they all have an interesting habit. Instead of explaining the entire route to your destination, they all tell you, "Take this road and as soon as you arrive at the nearest crossroad, ask somebody there again." Somewhat bemused at this apparent oddity, you follow these instructions and finally arrive, crossroad by crossroad, and road by road, at your friend's house.

Answer the following questions:

- 1. Would it have made a significant difference if you were told about the whole route or a larger part of the route instead of just being directed to the nearest crossroad?
- 2. Would it have been more helpful to ask about the specific street address or just about the street name? What would happen if the person you asked for directions did not know where the destination street was or directed you through an incorrect road?
- 3. Assuming that on your way back home, you again choose to ask residents for directions. Would it be guaranteed that you would be directed via the same route you took to get to your friend's home? Explain your answer.
- 4. Is it necessary to explain where you depart from when asking directions to an intended destination?

# Reflection

1. Would it have made a significant difference if you were told about the whole route or a larger part of the route instead of just being directed to the nearest crossroad?

2. Would it have been more helpful to ask about the specific street address or just about the street name?

- 3. What would happen if the person you asked for directions did not know where the destination street was or directed you through an incorrect road?
- 4. Assuming that on your way back home, you again choose to ask residents for directions. Is it guaranteed that you will be directed via the same route you took to get to your friend's home? Explain your answer.
- 5. Is it necessary to explain where you depart from when asking directions to an intended destination?
# 6.2.2.8 Lab - Viewing Host Routing Tables

## Topology



## **Objectives**

Part 1: Access the Host Routing Table

Part 2: Examine IPv4 Host Routing Table Entries

Part 3: Examine IPv6 Host Routing Table Entries

## Background / Scenario

To access a resource on a network, your host will determine the route to the destination host using its routing table. The host routing table is similar to that of a router, but is specific to the local host and much less complex. For a packet to reach a local destination, the local host routing table is required. To reach a remote destination, both the local host routing table and the router routing table are required. The **netstat –r** and **route print** commands provide insight into how your local host routes packets to the destination.

In this lab, you will display and examine the information in the host routing table of your PC using the **netstat -r** and **route print** commands. You will determine how packets will be routed by your PC depending on the destination address.

Note: This lab cannot be completed using Netlab. This lab assumes that you have Internet access.

## **Required Resources**

• 1 PC (Windows 7, Vista, or XP with Internet and command prompt access)

## Part 1: Access the Host Routing Table

#### Step 1: Record your PC information.

On your PC, open a command prompt window and type the **ipconfig /all** command to display the following information and record it:

IPv4 Address	
MAC Address	
Default Gateway	

#### Step 2: Display the routing tables.

In a command prompt window type the **netstat –r** (or **route print**) command to display the host routing table.

C:\Users\user1>netstat -r \_\_\_\_\_ Interface List nterface List 13...90 4c e5 be 15 63 .....Atheros AR9285 802.11b/g/n WiFi Adapter 1.....Software Loopback Interface 1 25...00 00 00 00 00 00 00 e0 Microsoft ISATAP Adapter 12...00 00 00 00 00 00 00 e0 Microsoft 6to4 Adapter 26...00 00 00 00 00 00 00 e0 Microsoft ISATAP Adapter #2 14...00 00 00 00 00 00 00 e0 Teredo Tunneling Pseudo-Interface IPv4 Route Table \_\_\_\_\_\_ Active Routes: Network Destination 0.0.0.0 127.0.0.0 Netmask Gateway Interface Metri 192.168.1.1 On-link 192.168.1.11 127.0.0.1 0.0.0.0 5.0.0 255.2 127.0.0.1 On-link 255 0.0.1 306 127.255 On-link 30 255 192.168.1.0 25 On-link 192 192 168.1. 255. 2 On-link 11 1.255 192 255 255. 255 On-link 168 240.0.0 240.0.0 0n−link 224.0.0.0 30 Ø. Й. **Й**.И 0nlink 192 255.255 255.255 255.255. 55. 255 On-link Ø.1 255 306 255. 255.255.255 192.168. 255 On-link 1.11 281255 \_\_\_\_\_\_\_ \_\_\_\_\_ Persistent Routes: None IPv6 Route Table \_\_\_\_\_ Active Routes: Metric Network Destination 58 ::/0 If Gateway On-link On-link 14 306 ::1/128 1 2001::/32 On-link 2001::0:9d38:6ab8:1863:3bca:3f57:fef4/128 On-link 58 14 14 306 fe80::/64 On-link fe80::1863:3bca:3f57:fef4/128 306 14 306 14 On-link On-link On-link 306 ff00::/8 ff00::/8 306 14 Persistent Routes: None

What are the three sections displayed in the output?

#### Step 3: Examine the Interface List.

The first section, Interface List, displays the Media Access Control (MAC) addresses and assigned interface number of every network-capable interface on the host.

\_\_\_\_\_\_ Interface List .....Atheros AR9285 802.11b/g/n WiFi Adapter .....Software Loopback Interface 1 00 e0 Microsoft ISATAP Adapter 00 e0 Microsoft 6to4 Adapter 00 e0 Microsoft ISATAP Adapter #2 ....90 4c e5 be 15 63 00 00 00 00 00 00 00 00 00 00 00 2 00 - -26 ...00 00 00 00 00 00 ..00 00 00 00 00 00 00 e0 Teredo Tunneling Pseudo-Interface 14. \_\_\_\_\_ \_\_\_\_\_ \_\_\_\_\_\_ The first column is the interface number. The second column is the list of MAC addresses associated with the network-capable interfaces on the hosts. These interfaces can include Ethernet, Wi-Fi and Bluetooth adapters. The third column shows the manufacturer and a description of the interface.

In this example, the first line displays the wireless interface that is connected to the local network.

**Note**: If you have a PC with an Ethernet interface and a Wireless adapter enabled, both interfaces would be listed in the Interface List.

What is the MAC address of the interface connected to your local network? How does the MAC address compare to the recorded MAC address in Step 1?

The second line is loopback interface. The loopback interface is automatically assigned an IP address of 127.0.0.1 when the Transmission Control Protocol/Internet Protocol (TCP/IP) is running on a host.

The last four lines represent transition technology that allows communication in a mixed environment and includes IPv4 and IPv6.

## Part 2: Examine IPv4 Host Routing Table Entries

In Part 2, you will examine the IPv4 host routing table. This table is in the second section as a result of the **netstat –r** output. It lists all the known IPv4 routes, including direct connections, local network, and local default routes.

IPv4 Route Table				
Active Routes:				
Network Destination	n Netmask	Gateway	Interface	Metric
0.0.0.0	0.0.0.0	192.168.1.Ĭ	192.168.1.11	25
127.0.0.0	255.0.0.0	On-link	127.0.0.1	306
127.0.0.1	255.255.255.255	On-link	127.0.0.1	306
127.255.255.255	255.255.255.255	On-link	127.0.0.1	306
192.168.1.0	255.255.255.0	On-link	192.168.1.11	281
192.168.1.11	255.255.255.255	On-link	192.168.1.11	281
192.168.1.255	255.255.255.255	On-link	192.168.1.11	281
224.0.0.0	240.0.0.0	On-link	127.0.0.1	306
224.0.0.0	240.0.0.0	On-link	192.168.1.11	281
255.255.255.255	255.255.255.255	On-link	127.0.0.1	306
255.255.255.255	255.255.255.255	On-link	192.168.1.11	281
				======
Persistent Routes: None				
None None				

The output is divided in five columns: Network Destination, Netmask, Gateway, Interface, and Metric.

- The Network Destination column lists the reachable network. The Network Destination is used with Netmask to match the destination IP address.
- The Netmask lists the subnet mask that the host uses to determine the network and host portions of the IP address.
- The Gateway column lists the address that the host uses to send the packets to a remote network destination. If a destination is directly connected, the gateway is listed as On-link in the output.
- The Interface column lists the IP address that is configured on the local network adaptor. This is used to
  forward a packet on the network.
- The Metric column lists the cost of using a route. It is used to calculate the best route to a destination. A
  preferred route has a lower metric number than other routes listed.

The output displays five different types of active routes:

- The local default route 0.0.0.0 is used when the packet does not match other specified addresses in the routing table. The packet will be sent to the gateway from the PC for further processing. In this example, the packet will be sent to 192.168.1.1 from 192.168.1.11.
- The loopback addresses, 127.0.0.0 127.255.255.255, are related to direct connection and provide services to the local host.
- The addresses for the subnet, 192.168.1.0 192.168.1.255, are all related to the host and the local network. If the final destination of the packet is in the local network, the packet will exit 192.168.1.11 interface.
  - The local route address 192.168.1.0 represents all devices on the 192.168.1.0/24 network.
  - The address of the local host is 192.168.1.11.
  - The network broadcast address 192.168.1.255 is used to send messages to all the hosts on the local network.
- The special multicast class D addresses 224.0.0.0 are reserved for use through either the loopback interface (127.0.0.1) or the host (192.168.1.11).
- The local broadcast address 255.255.255.255 can be used through either the loopback interface (127.0.0.1) or host (192.168.1.11).

Based on the contents of the IPv4 routing table, if the PC wanted to send a packet to 192.168.1.15, what would it do and where would it send the packet?

If the PC wanted to send a packet to a remote host located at 172.16.20.23, what would it do and where would it send the packet?

## Part 3: Examine IPv6 Host Routing Table Entries

In Part 3, you will examine the IPv6 routing table. This table is in the third section displayed in the **netstat –r** output. It lists all the known IPv6 routes including direct connections, local network and local default routes.

IPvé	6 Route	Table	
Act:	ive Rout	:es:	
If	Metric	Network Destination	Gateway
14	58	::/0	On-link
1	306	::1/128	On-link
14	58	2001::/32	On-link
14	306	2001:0:9d38:6ab8:1863:3bc	a:3f57:fef4/128
			On-link
14	306	fe80::/64	On-link
14	306	fe80::1863:3bca:3f57:fef4	/128
			On-link
1	306	ff00::/8	On-link
14	306	ff00::/8	On-link
====			
Pers	sistent	Routes:	
No	one		

The output of the IPv6 Route Table differs in column headings and format because the IPv6 addresses are 128 bits versus only 32 bits for IPv4 addresses. The IPv6 Route Table section displays four columns:

- The If column lists the interface numbers of the IPv6-enabled network interfaces from the Interface List section of the netstat –r command.
- The Metric column lists the cost of each route to a destination. The lower cost is the preferred route, and the metric is used to select between multiple routes with the same prefix.
- The Network Destination column lists the address prefix for the route.
- The Gateway lists the next-hop IPv6 address to reach the destination. On-link is listed as the next-hop address if it is directly connected to the host.

In this example, the figure displays the IPv6 Route Table section generated by the **netstat –r** command to reveal the following network destinations:

- ::/0: This is the IPv6 equivalent of the local default route. The Gateway column provides the link-local address of the default router.
- ::1/128: This is equivalent to the IPv4 loopback address and provides services to the local host.
- 2001::/32: This is the global unicast network prefix.
- 2001:0:9d38:6ab8:1863:3bca:3f57:fef4/128: This is the global unicast IPv6 address of the local computer.
- fe80::/64: This is the local link network route address and represents all computers on the local-link IPv6 network.
- fe80::1863:3bca:3f57:fef4/128: This is the link-local IPv6 address of the local computer.
- ff00::/8: These are special reserved multicast class D addresses equivalent to the IPv4 224.x.x.x addresses.

The host routing table for IPv6 has similar information as the IPv4 routing table. What is the local default route for IPv4 and what is it for IPv6?

What is the loopback address and subnet mask for IPv4? What is the loopback IP address for IPv6?

How many IPv6 addresses have been assigned to this PC?

How many broadcast addresses does the IPv6 routing table contain?

## Reflection

- 1. How is the number of bits for the network indicated for IPv4. How is it done for IPv6?
- 2. Why is there both IPv4 and IPv6 information in the host routing tables?

# 6.3.1.9 Lab - Exploring Router Physical Characteristics

## Topology



## **Objectives**

#### Part 1: Examine Router External Characteristics

- Identify the various parts of a Cisco router, including:
  - Management ports
  - LAN interfaces
  - WAN interfaces
  - Module expansion slots
  - Compact Flash memory expansion slots
  - USB ports
- Examine the router activity and status lights.

#### Part 2: Examine Router Internal Characteristics Using Show Commands

- Establish a console connection to the router using Tera Term.
- Identify router internal characteristics using the **show version** command.
- Identify router interface characteristics using **show interface** commands.

## **Background / Scenario**

In this lab, you will examine the outside of the router to become familiar with its characteristics and components, such as its power switch, management ports, LAN and WAN interfaces, indicator lights, network expansion slots, memory expansion slots, and USB ports.

You will also identify the internal components and characteristics of the IOS by consoling into the router and issuing various commands, such as **show version** and **show interfaces**, from the CLI.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). Other routers and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs.

**Note**: Make sure that the routers have been erased and have no startup configurations. If you are unsure, contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports

## Part 1: Examine Router External Characteristics

Use the images below, as well as your own direct inspection of the backplane of a Cisco router, to answer the following questions. Feel free to draw arrows and circle the areas of the image that correctly identify the parts.

**Note**: The router depicted in the images below is a Cisco 1941 router, which may be different from the make and model of the routers in your particular academy. You can find device information and specifications for the Cisco 1941 series routers at the Cisco.com website. Additional information, including answers to many of the questions below can be found here:

http://www.cisco.com/en/US/prod/collateral/routers/ps10538/data\_sheet\_c78\_556319.html

#### Step 1: Identify the various parts of a Cisco router.

The image shown in this step is of the backplane of a Cisco 1941 ISR. Use it to answer the questions in this step. In addition, if you are examining a different model router, a space has been provided here for you to draw the backplane and identify components and interfaces as specified in the questions that follow.





- a. Circle and label the router's power switch. Is the power switch on your router in the same area as the router depicted in the image?
- b. Circle and label the management ports. What are the built-in management ports? Are the management ports the same on your router? If not, how are they different?
- c. Circle and label the router's LAN interfaces. How many LAN interfaces does the router in the image have and what is the interface technology type? Are the LAN interfaces the same on your router? If not, how are they different?
- d. Circle and label the router's WAN interfaces. How many WAN interfaces does the router in the image have and what is the interface technology type? Are the WAN interfaces the same on your router? If not, how are they different?
- e. The Cisco 1941 ISR is a modular platform and comes with module expansion slots for varied network connectivity requirements. Circle and label the module slots. How many module slots are there? How many are used? What type of module expansion slots are they? Are the module slots the same on your router? If not, how are they different?
- f. The Cisco 1941 router comes with CompactFlash memory slots for high speed storage. Circle and label the CompactFlash memory slots. How many memory slots are there? How many are used? How much memory can they hold? Are the memory slots the same on your router? If not, how are they different?
- g. The Cisco 1941 router comes with USB 2.0 ports. The built-in USB ports support eToken devices and USB flash memory. The USB eToken device feature provides device authentication and secure configuration of Cisco routers. The USB flash feature provides optional secondary storage capability and an additional boot device. Circle and label the USB ports. How many USB ports are there? Are there USB ports on your router?
- h. The Cisco 1941 router also comes with a mini-B USB console port. Circle and label the mini-B USB console port.

#### Step 2: Examine the router activity and status lights.

The following images highlight the activity and status lights of the front panel and backplane of a powered up and connected Cisco 1941 ISR.

**Note**: Some of the indicator lights are obscured from view in the image of the backplane of the Cisco 1941 router below.





- a. In the top image above, examine the indicator lights on the front panel of the router? The lights are labeled SYS, ACT, and POE. What do the labels refer to? What do the lights in the image indicate about the status of the router? These labels would be readable if they were not lit.
- b. In the backplane image above, examine the indicator lights on the router. There are three visible activity lights, one for each of the connected interfaces and management ports. Examine the interface lights on your router. How are the lights labeled, and what is their meaning?

c. Aside from the management ports and network interfaces, what other indicator lights are on the backplane of the router and what might their purpose be?

## Part 2: Examine Router Internal Characteristics Using Show Commands

#### Step 1: Establish a console connection to the router and use the show version command.

a. Using Tera Term, console into the router and enter privileged EXEC mode using the enable command:

```
Router> enable
Router#
```

 Display information about the router by using the show version command. Use the Spacebar on the keyboard to page through the output.

```
Router# show version
Cisco IOS Software, C1900 Software (C1900-UNIVERSALK9-M), Version 15.2(4)M3, RELEASE
SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2011 by Cisco Systems, Inc.
Compiled Thu 26-Jul-12 19:34 by prod rel team
ROM: System Bootstrap, Version 15.0(1r)M15, RELEASE SOFTWARE (fc1)
Router uptime is 1 day, 14 hours, 46 minutes
System returned to ROM by power-on
System restarted at 07:26:55 UTC Mon Dec 3 2012
System image file is "flash0:c1900-universalk9-mz.SPA.152-4.M3.bin"
Last reload type: Normal Reload
Last reload reason: power-on
<output omitted>
If you require further assistance please contact us by sending email to
export@cisco.com.
Cisco CISCO1941/K9 (revision 1.0) with 487424K/36864K bytes of memory.
Processor board ID FGL16082318
2 Gigabit Ethernet interfaces
2 Serial(sync/async) interfaces
1 terminal line
1 Virtual Private Network (VPN) Module
DRAM configuration is 64 bits wide with parity disabled.
255K bytes of non-volatile configuration memory.
250880K bytes of ATA System CompactFlash 0 (Read/Write)
<output omitted>
```

Technology Package License Information for Module: 'c1900'

Technology	Technology-pa	ckage	Technology-package
	Current	Туре	Next reboot
ipbase	ipbasek9	Permanent	ipbasek9
security	securityk9	Permanent	securityk9
data	None	None	None

Configuration register is 0x2102

- c. Based on the output of the **show version** command, answer the following questions about the router. If you are examining a different model router, include the information about it here.
  - 1) What is the version of the Cisco IOS and what is the system image filename?
  - 2) What is the Bootstrap program version in ROM BIOS?
  - 3) How long has the router been running without a restart (also known as its uptime)?
  - 4) How much dynamic random-access memory (DRAM) memory does the router have?
  - 5) What is the router's processor board ID number?
  - 6) What network interfaces does the router have?
  - 7) How much CompactFlash memory for IOS storage is there?
  - 8) How much nonvolatile random-access memory (NVRAM) memory for configuration file storage is there?
  - 9) What is the setting of the configuration register?

#### Step 2: Use the show interface command to examine the network interfaces.

a. Use the **show interface gigabitEthernet 0/0** command to see the status of the Gigabit Ethernet 0/0 interface.

**Note**: After typing part of the command, for example, **show interface g**, you can use the **Tab** key on your keyboard to complete the gigabitEthernet command parameter.

```
Router# show interface gigabitEthernet 0/0
GigabitEthernet0/0 is administratively down, line protocol is down
Hardware is CN Gigabit Ethernet, address is 442b.031a.b9a0 (bia 442b.031a.b9a0)
MTU 1500 bytes, BW 100000 Kbit/sec, DLY 100 usec,
reliability 255/255, txload 1/255, rxload 1/255
```

```
Encapsulation ARPA, loopback not set
Keepalive set (10 sec)
Full Duplex, 100Mbps, media type is RJ45
output flow-control is unsupported, input flow-control is unsupported
ARP type: ARPA, ARP Timeout 04:00:00
Last input never, output never, output hang never
Last clearing of "show interface" counters never
Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
Queueing strategy: fifo
Output queue: 0/40 (size/max)
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
   3 packets input, 276 bytes, 0 no buffer
  Received 0 broadcasts (0 IP multicasts)
   0 runts, 0 giants, 0 throttles
   0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
   0 watchdog, 0 multicast, 0 pause input
   0 packets output, 0 bytes, 0 underruns
   0 output errors, 0 collisions, 0 interface resets
   0 unknown protocol drops
   0 babbles, 0 late collision, 0 deferred
   0 lost carrier, 0 no carrier, 0 pause output
   0 output buffer failures, 0 output buffers swapped out
```

b. Given the output of the show interface gigabitEthernet 0/0 command depicted above, or using the output from your router, answer the following questions:

What is the hardware type and MAC address of the Gigabit Ethernet interface?

What is the interface media type? Is the interface up or down?

c. Use the show interfaces serial 0/0/0 command to view the status of the Serial 0/0/0 interface.

```
Router# show interface serial 0/0/0
Serial0/0/0 is administratively down, line protocol is down
 Hardware is WIC MBRD Serial
 MTU 1500 bytes, BW 1544 Kbit/sec, DLY 20000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation HDLC, loopback not set
 Keepalive set (10 sec)
 Last input 07:41:21, output never, output hang never
 Last clearing of "show interface" counters never
 Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
 Queueing strategy: fifo
 Output queue: 0/40 (size/max)
 5 minute input rate 0 bits/sec, 0 packets/sec
 5 minute output rate 0 bits/sec, 0 packets/sec
    1 packets input, 24 bytes, 0 no buffer
    Received 1 broadcasts (0 IP multicasts)
    0 runts, 0 giants, 0 throttles
```

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort 0 packets output, 0 bytes, 0 underruns 0 output errors, 0 collisions, 2 interface resets 0 unknown protocol drops 0 output buffer failures, 0 output buffers swapped out 1 carrier transitions DCD=down DSR=down DTR=down RTS=down CTS=down

d. Given the output command depicted above, answer the following questions:What is the frame encapsulation type?

What is the hardware type? Is the interface up or down?

#### Reflection

- 1. Why might you need to use an EHWIC expansion slot?
- 2. Why might you need to upgrade the Flash memory?
- 3. What is the purpose of the mini-USB port?
- 4. What is the purpose of the ISM/WLAN indicator light on the backplane of the router? What does it refer to?

## 6.4.3.5 Lab - Building a Switch and Router Network

## Topology



## Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/0	192.168.0.1	255.255.255.0	N/A
	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	N/A	N/A	N/A
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-B	NIC	192.168.0.3	255.255.255.0	192.168.0.1

## **Objectives**

#### Part 1: Set Up the Topology and Initialize Devices

- Set up equipment to match the network topology.
- Initialize and restart the router and switch.

#### Part 2: Configure Devices and Verify Connectivity

- Assign static IP information to the PC interfaces.
- Configure the router.
- Verify network connectivity.

#### Part 3: Display Device Information

- Retrieve hardware and software information from the network devices.
- Interpret the output from the routing table.
- Display interface information on the router.
- Display a summary list of the interfaces on the router and switch.

## **Background / Scenario**

This is a comprehensive lab to review previously covered IOS commands. In this lab, you will cable the equipment as shown in the topology diagram. You will then configure the devices to match the addressing table. After the configurations have been saved, you will verify your configurations by testing for network connectivity.

After the devices have been configured and network connectivity has been verified, you will use IOS commands to retrieve information from the devices to answer questions about your network equipment.

This lab provides minimal assistance with the actual commands necessary to configure the router. However, the required commands are provided in Appendix A. Test your knowledge by trying to configure the devices without referring to the appendix.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Ensure that the routers and switches have been erased and have no startup configurations. Refer to Appendix B for the procedure to initialize and reload a router and switch.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

**Note**: The Gigabit Ethernet interfaces on Cisco 1941 routers are autosensing and an Ethernet straightthrough cable may be used between the router and PC-B. If using another model Cisco router, it may be necessary to use an Ethernet crossover cable.

## Part 1: Set Up Topology and Initialize Devices

#### Step 1: Cable the network as shown in the topology.

- a. Attach the devices shown in the topology diagram, and cable, as necessary.
- b. Power on all the devices in the topology.

#### Step 2: Initialize and reload the router and switch.

If configuration files were previously saved on the router and switch, initialize and reload these devices back to their basic configurations. For information on how to initialize and reload these devices, refer to Appendix B.

## Part 2: Configure Devices and Verify Connectivity

In Part 2, you will set up the network topology and configure basic settings, such as the interface IP addresses, device access, and passwords. Refer to the Topology and Addressing Table at the beginning of this lab for device names and address information.

**Note**: Appendix A provides configuration details for the steps in Part 2. You should attempt to complete Part 2 prior to reviewing this appendix.

#### Step 1: Assign static IP information to the PC interfaces.

- a. Configure the IP address, subnet mask, and default gateway settings on PC-A.
- b. Configure the IP address, subnet mask, and default gateway settings on PC-B.

c. Ping PC-B from a command prompt window on PC-A.

Why were the pings not successful?

#### Step 2: Configure the router.

- a. Console into the router and enable privileged EXEC mode.
- b. Enter configuration mode.
- c. Assign a device name to the router.
- d. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were host names.
- e. Assign **class** as the privileged EXEC encrypted password.
- f. Assign cisco as the console password and enable login.
- g. Assign cisco as the VTY password and enable login.
- h. Encrypt the clear text passwords.
- i. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- j. Configure and activate both interfaces on the router.
- k. Configure an interface description for each interface indicating which device is connected to it.
- I. Save the running configuration to the startup configuration file.
- m. Set the clock on the router.

**Note**: Use the question mark (?) to help with the correct sequence of parameters needed to execute this command.

n. Ping PC-B from a command prompt window on PC-A.

Were the pings successful? Why?

## Part 3: Display Device Information

In Part 3, you will use **show** commands to retrieve information from the router and switch.

#### Step 1: Retrieve hardware and software information from the network devices.

a. Use the **show version** command to answer the following questions about the router.What is the name of the IOS image that the router is running?

How much DRAM memory does the router have?

How much NVRAM memory does the router have?

How much Flash memory does the router have?

b. Use the show version command to answer the following questions about the switch.What is the name of the IOS image that the switch is running?

How much dynamic random access memory (DRAM) does the switch have?

How much nonvolatile random-access memory (NVRAM) does the switch have?

What is the model number of the switch?

#### Step 2: Display the routing table on the router.

Use the **show ip route** command on the router to answer the following questions. What code is used in the routing table to indicate a directly connected network? \_\_\_\_\_ How many route entries are coded with a C code in the routing table? \_\_\_\_\_ What interface types are associated to the C coded routes?

#### Step 3: Display interface information on the router.

Use the **show interface g0/1** to answer the following questions. What is the operational status of the G0/1 interface?

What is the Media Access Control (MAC) address of the G0/1 interface?

How is the Internet address displayed in this command?

#### Step 4: Display a summary list of the interfaces on the router and switch.

There are several commands that can be used to verify an interface configuration. One of the most useful of these is the **show ip interface brief** command. The command output displays a summary list of the interfaces on the device and provides immediate feedback to the status of each interface.

#### a. Enter the show ip interface brief command on the router.

#### R1# show ip interface brief

Interface	IP-Address	OK?	Method	Status		Protocol
Embedded-Service-Engine0/0	unassigned	YES	unset	administratively	down	down
GigabitEthernet0/0	192.168.0.1	YES	manual	up		up
GigabitEthernet0/1	192.168.1.1	YES	manual	up		up
Serial0/0/0	unassigned	YES	unset	administratively	down	down
Serial0/0/1	unassigned	YES	unset	administratively	down	down
R1#						

b. Enter the **show ip interface brief** command on the switch.

Switch# show ip :	interface brief			
Interface	IP-Address	OK? Method	Status	Protocol
Vlan1	unassigned	YES manual	up	up
FastEthernet0/1	unassigned	YES unset	down	down
FastEthernet0/2	unassigned	YES unset	down	down
FastEthernet0/3	unassigned	YES unset	down	down
FastEthernet0/4	unassigned	YES unset	down	down
FastEthernet0/5	unassigned	YES unset	up	up
FastEthernet0/6	unassigned	YES unset	up	up
FastEthernet0/7	unassigned	YES unset	down	down
FastEthernet0/8	unassigned	YES unset	down	down
FastEthernet0/9	unassigned	YES unset	down	down
FastEthernet0/10	unassigned	YES unset	down	down
FastEthernet0/11	unassigned	YES unset	down	down
FastEthernet0/12	unassigned	YES unset	down	down
FastEthernet0/13	unassigned	YES unset	down	down
FastEthernet0/14	unassigned	YES unset	down	down
FastEthernet0/15	unassigned	YES unset	down	down
FastEthernet0/16	unassigned	YES unset	down	down
FastEthernet0/17	unassigned	YES unset	down	down
FastEthernet0/18	unassigned	YES unset	down	down
FastEthernet0/19	unassigned	YES unset	down	down
FastEthernet0/20	unassigned	YES unset	down	down
FastEthernet0/21	unassigned	YES unset	down	down
FastEthernet0/22	unassigned	YES unset	down	down
FastEthernet0/23	unassigned	YES unset	down	down
FastEthernet0/24	unassigned	YES unset	down	down
GigabitEthernet0/1	unassigned	YES unset	down	down
GigabitEthernet0/2	unassigned	YES unset	down	down
Switch#				

## Switch# show ip interface brief

## Reflection

- 1. If the G0/1 interface showed administratively down, what interface configuration command would you use to turn the interface up?
- 2. What would happen if you had incorrectly configured interface G0/1 on the router with an IP address of 192.168.1.2?

Router Interface Summary									
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2					
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)					
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					

#### Router Interface Summary Table

**Note**: To find out how the router is configured, look at the interfaces to identify the router type and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

## Appendix A: Configuration Details for Steps in Part 2

#### Step 1: Configure the PC interfaces.

a. Configure the IP address, subnet mask, and default gateway settings on PC-A.

Internet Protocol Version 4 (TCP/IPv4) Properties								
General								
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.								
Obtain an IP address automatical	ly							
Ouse the following IP address:								
IP address:	192.168.1.3							
Subnet mask:	255.255.255.0							
Default gateway:	192.168.1.1							

b. Configure the IP address, subnet mask, and default gateway settings on PC-B.

Internet Protocol Version 4 (TCP/IPv4) Properties							
General							
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.							
Obtain an IP address automatically							
Our of the following IP address: -							
IP address:	192.168.0.3						
Subnet mask:	255.255.255.0						
Default gateway:	192.168.0.1						
Default gateway:	192.168.0.1						

c. Ping PC-B from a command prompt window on PC-A.

C:\>ping 192.168.0.3
Pinging 192.168.0.3 with 32 bytes of data:
Reply from 192.168.1.3: Destination host unreachable.
Ping statistics for 192.168.0.3: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
C:\>

#### Step 2: Configure the router.

a. Console into the router and enable privileged EXEC mode.

```
Router> enable
Router#
```

b. Enter configuration mode.

```
Router# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

c. Assign a device name to the router.

```
Router(config) # hostname R1
```

d. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were host names.

R1(config) # no ip domain-lookup

e. Assign **class** as the privileged EXEC encrypted password.

R1(config) # enable secret class

f. Assign cisco as the console password and enable login.

```
R1(config)# line con 0
R1(config-line)# password cisco
R1(config-line)# login
```

```
R1 (config-line) # exit
R1 (config) #
g. Assign cisco as the vty password and enable login.
R1 (config) # line vty 0 4
R1 (config-line) # password cisco
R1 (config-line) # login
```

```
R1(config-line)# exit
R1(config)#
```

- . 5.
- h. Encrypt the clear text passwords.
  - R1(config) # service password-encryption
- i. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.

```
R1(config)# banner motd #
Enter TEXT message. End with the character '#'.
Unauthorized access prohibited!
#
```

```
R1(config)#
```

j. Configure and activate both interfaces on the router.

```
R1(config) # int g0/0
R1(config-if) # description Connection to PC-B.
R1(config-if) # ip address 192.168.0.1 255.255.255.0
R1(config-if) # no shut
R1(config-if)#
*Nov 29 23:49:44.195: %LINK-3-UPDOWN: Interface GigabitEthernet0/0, changed state to
down
*Nov 29 23:49:47.863: %LINK-3-UPDOWN: Interface GigabitEthernet0/0, changed state to
up
*Nov 29 23:49:48.863: %LINEPROTO-5-UPDOWN: Line protocol on Interface
GigabitEthernet0/0, changed state to up
R1(config-if) # int g0/1
R1(config-if) # description Connection to S1.
R1(config-if)# ip address 192.168.1.1 255.255.255.0
R1(config-if) # no shut
R1(config-if)# exit
R1(config) # exit
*Nov 29 23:50:15.283: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to
down
*Nov 29 23:50:18.863: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to
up
*Nov 29 23:50:19.863: %LINEPROTO-5-UPDOWN: Line protocol on Interface
GigabitEthernet0/1, changed state to up
R1#
```

k. Save the running configuration to the startup file.

```
R1# copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
```

[OK] R1#

I. Set the clock on the router.

```
R1# clock set 17:00:00 29 Nov 2012
R1#
*Nov 29 17:00:00.000: %SYS-6-CLOCKUPDATE: System clock has been updated from 23:55:46
UTC Thu Nov 29 2012 to 17:00:00 UTC Thu Nov 29 2012, configured from console by
console.
R1#
```

**Note**: Use the question mark (?) to help determine the correct sequence of the parameters needed to execute this command.

m. Ping PC-B from a command prompt window on PC-A.

```
C:\>ping 192.168.0.3
Pinging 192.168.0.3 with 32 bytes of data:
Reply from 192.168.0.3: bytes=32 time<1ms TTL=127
Ping statistics for 192.168.0.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\>
```

Appendix B: Initializing and Reloading a Router and Switch

## Part 1: Initialize the Router and Reload

#### Step 1: Connect to the router.

Console into the router and enter privileged EXEC mode using the enable command.

Router> **enable** Router#

#### Step 2: Erase the startup configuration file from NVRAM.

Type the **erase startup-config** command to remove the startup configuration from nonvolatile randomaccess memory (NVRAM).

```
Router# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
Erase of nvram: complete
Router#
```

#### Step 3: Reload the router.

Issue the **reload** command to remove an old configuration from memory. When prompted to Proceed with reload, press Enter to confirm the reload. Pressing any other key will abort the reload.

```
Router# reload
```

\*Nov 29 18:28:09.923: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload Command. Note: You may receive a prompt to save the running configuration prior to reloading the router. Respond by typing **no** and press Enter.

System configuration has been modified. Save? [yes/no]: no

#### Step 4: Bypass the initial configuration dialog.

Proceed with reload? [confirm]

After the router reloads, you are prompted to enter the initial configuration dialog. Enter **no** and press Enter.

Would you like to enter the initial configuration dialog? [yes/no]: **no** 

#### Step 5: Terminate the autoinstall program.

You will be prompted to terminate the autoinstall program. Respond yes and then press Enter.

```
Would you like to terminate autoinstall? [yes]: yes
Router>
```

## Part 2: Initialize the Switch and Reload

#### Step 1: Connect to the switch.

Console into the switch and enter privileged EXEC mode.

```
Switch> enable
Switch#
```

#### Step 2: Determine if there have been any virtual local-area networks (VLANs) created.

Use the **show flash** command to determine if any VLANs have been created on the switch.

Switch# show flash

```
Directory of flash:/
2 -rwx 1919 Mar 1 1993 00:06:33 +00:00 private-config.text
3 -rwx 1632 Mar 1 1993 00:06:33 +00:00 config.text
4 -rwx 13336 Mar 1 1993 00:06:33 +00:00 multiple-fs
5 -rwx 11607161 Mar 1 1993 02:37:06 +00:00 c2960-lanbasek9-mz.150-2.SE.bin
6 -rwx 616 Mar 1 1993 00:07:13 +00:00 vlan.dat
32514048 bytes total (20886528 bytes free)
```

```
Step 3: Delete the VLAN file.
```

Switch#

a. If the vlan.dat file was found in flash, then delete this file.

Switch# delete vlan.dat

Delete filename [vlan.dat]?

You will be prompted to verify the file name. At this point, you can change the file name or just press Enter if you have entered the name correctly. b. When you are prompted to delete this file, press Enter to confirm the deletion. (Pressing any other key will abort the deletion.)

```
Delete flash:/vlan.dat? [confirm]
Switch#
```

#### Step 4: Erase the startup configuration file.

Use the **erase startup-config** command to erase the startup configuration file from NVRAM. When you are prompted to remove the configuration file, press Enter to confirm the erase. (Pressing any other key will abort the operation.)

```
Switch# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
Erase of nvram: complete
Switch#
```

#### Step 5: Reload the switch.

Reload the switch to remove any old configuration information from memory. When you are prompted to reload the switch, press Enter to proceed with the reload. (Pressing any other key will abort the reload.)

```
Switch# reload
Proceed with reload? [confirm]
```

**Note**: You may receive a prompt to save the running configuration prior to reloading the switch. Type **no** and press Enter.

System configuration has been modified. Save? [yes/no]: no

#### Step 6: Bypass the initial configuration dialog.

After the switch reloads, you should see a prompt to enter the initial configuration dialog. Type **no** at the prompt and press Enter.

```
Would you like to enter the initial configuration dialog? [yes/no]: no Switch>
```

# 6.5.1.1 Can you read this map?

## **Objectives**

#### Explain how network devices use routing tables to direct packets to a destination network.

In this activity, given a scenario, you will determine whether high-reliability messaging should be used. You will focus on whether the final message is complete, correct, and delivered in a timely manner.

#### Background/Scenario

**Note:** It is suggested that students work in pairs; however, if preferred, students can complete this activity individually.

Your instructor will provide you with output generated by a router's **show ip route** command. Use Packet Tracer to build a topology model using this routing information.

At a minimum, the following should be used in your topology model:

- One Catalyst 2960 switch
- One Cisco Series 1941 Router with one HWIC-4ESW switching port modular card and IOS Version 15.1 or higher
- Three PCs (can be servers, generic PCs, laptops, etc.)

Use the note tool in Packet Tracer to indicate the addresses of the router interfaces and possible addresses for the end devices you chose for your model.

Label all end devices, ports, and addresses ascertained from the **show ip route** output/routing table information in your Packet Tracer file. Save your work in hard or soft copy to share with the class.

#### **Required Resources**

- Packet Tracer software program.
- Routing **Table 1** You can use the table to assist one another as you read the information provided, and then construct the model using Packet Tracer.

## Table 1

```
R1# show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B -
BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
ia - IS-IS inter area, * - candidate default, U - per-user static
route
o - ODR, P - periodic downloaded static route, H - NHRP, 1 - LISP
+ - replicated route, % - next hop override
Gateway of last resort is not set
192.168.0.0/24 is variably subnetted, 2 subnets, 2 masks
C 192.168.0.0/24 is directly connected, GigabitEthernet0/0
L 192.168.0.1/32 is directly connected, GigabitEthernet0/0
192.168.1.0/24 is variably subnetted, 2 subnets, 2 masks
C 192.168.1.0/24 is directly connected, GigabitEthernet0/1
L 192.168.1.1/32 is directly connected, GigabitEthernet0/1
```

#### Reflection

1. What was the hardest part of designing this network model? Explain your answer.

# 7.0.1.2 We Need to Talk

## **Objectives**

#### Explain how transport layer protocols and services support communications across data networks.

In this activity, you will determine whether high or low data communication delivery methods should be utilized in a situational context.

## Background/Scenario

Note: This activity works best with medium-sized groups of 6 to 8 students per group.

This chapter helps you understand how transport layer protocols and services support network data communications.

Your instructor will whisper a complex message to the first student in a group. An example of the message might be "Our final exam will be given next Tuesday, February 5th, at 2:00 p.m. in Room 1151."

That student whispers the message to the next student in the group. Each group follows this process until all members of each group have heard the whispered message.

Here are the rules to follow:

- You can whisper the message only once to your neighbor.
- The message must keep moving from one person to the other with no skipping of participants. The instructor should ask a student to keep time of the full message activity from first participant to last participant stating the messages. The first or last person would mostly likely be the best one to keep this time.
- The last student will say aloud exactly what he or she heard.

Your instructor will repeat the original message so that the group can compare it to the message that was delivered by the last student in the group.

#### **Required Resources**

• Timer for the student who is keeping a record of the conversation's duration.

#### Reflection

1. Would the contents of this message need to be fully correct when you received them if you were depending on this message to drive your personal/business calendar, studying schedule, etc.?

2. Would the length of time taken to deliver the message be an important factor to the sender and recipient?

# 7.2.1.8 Lab - Using Wireshark to Observe the TCP 3-Way Handshake

Topology



## **Objectives**

Part 1: Prepare Wireshark to Capture Packets

• Select an appropriate NIC interface to capture packets.

#### Part 2: Capture, Locate, and Examine Packets

- Capture a web session to www.google.com.
- Locate appropriate packets for a web session.
- Examine information within packets, including IP addresses, TCP port numbers, and TCP control flags.

#### **Background / Scenario**

In this lab, you will use Wireshark to capture and examine packets generated between the PC browser using the HyperText Transfer Protocol (HTTP) and a web server, such as www.google.com. When an application, such as HTTP or File Transfer Protocol (FTP) first starts on a host, TCP uses the three-way handshake to establish a reliable TCP session between the two hosts. For example, when a PC uses a web browser to surf the Internet, a three-way handshake is initiated and a session is established between the PC host and web server. A PC can have multiple, simultaneous, active TCP sessions with various web sites.

Note: This lab cannot be completed using Netlab. This lab assumes that you have Internet access.

#### **Required Resources**

1 PC (Windows 7, Vista, or XP with a command prompt access, Internet access, and Wireshark installed)

## Part 1: Prepare Wireshark to Capture Packets

In Part 1, you start the Wireshark program and select the appropriate interface to begin capturing packets.

#### Step 1: Retrieve the PC interface addresses.

For this lab, you need to retrieve your PC's IP address and its network interface card (NIC) physical address, also called the MAC address.

a. Open a command prompt window, type **ipconfig /all** and then press Enter.

Physical Address.							=	C8-0A-A9-FA-DE-0D
DHCP Enabled							=	Yes
Autoconfiguration	En	al	le	ed			-	Yes
IPv4 Address							-	192.168.1.130(Preferred)
Subnet Mask							:	255.255.255.0
Lease Obtained							-	Saturday, December 01, 2012 1:43:35 PM
Lease Expires								Sunday, December 02, 2012 1:43:35 PM
Default Gateway .							-	192.168.1.1
DHCP Server							-	192.168.1.1
DNS Servers							:	192.168.1.1
NetBIOS over Topip	).						-	Enabled

b. Write down the IP and MAC addresses associated with the selected Ethernet adapter, because that is the source address to look for when examining captured packets.

The PC host IP address: \_\_\_\_\_\_
The PC host MAC address: \_\_\_\_\_\_

#### Step 2: Start Wireshark and select the appropriate interface.

- a. Click the Windows Start button and on the pop-up menu, double-click Wireshark.
- b. After Wireshark starts, click Interface List.



c. In the **Wireshark: Capture Interfaces** window, click the check the box next to the interface connected to your LAN.

l	📶 Wireshark: C	pture Interfaces				- • •
ſ		Description	IP	Packets	Packets/s	
		Intel(R) PRO/1000 MT Network Connection		19	0	<u>D</u> etails
K		Intel(R) 82577LM Gigabit Network Connection	192.168.1.11	47	0	Details
	<u>H</u> elp		Start	Stop	<u>O</u> ptions	<u>C</u> lose

**Note**: If multiple interfaces are listed and you are unsure which interface to check, click **Details**. Click the **802.3 (Ethernet)** tab, and verify that the MAC address matches what you wrote down in Step 1b. Close the Interface Details window after verification.

## Part 2: Capture, Locate, and Examine Packets

#### Step 1: Click the Start button to start the data capture.

a. Go to www.google.com. Minimize the Google window, and return to Wireshark. Stop the data capture. You should see captured traffic similar to that shown below in step b.

**Note**: Your instructor may provide you with a different website. If so, enter the website name or address here:

b. The capture window is now active. Locate the Source, Destination, and Protocol columns.

▋▋▋ & &   =   × 2 +   < + + + 7 ±   = =   • < < 0   =   # ≥
Filter: Vepression Clear Apply Save
Time Source Destination Protocol Length Info
1 0.000000000 192.168.1.130 157.55.130.157 TCP 54 49166 > 40013 [ACK] Seq=1 Ack=1 win=255 Len=0
2 0.033696000 157.55.130.157 192.168.1.130 TCP 144 40013 > 49166 [PSH, ACK] seq=1 Ack=1 win=83 Len=9
3 0.034064000 192.168.1.130 157.55.130.157 TCP 58 49166 > 40013 [PSH, ACK] seq=1 Ack=91 Win=255 Len
4 0.069409000 157.55.130.157 192.168.1.130 TCP 60 40013 > 49166 [ACK] seq=91 Ack=5 win=83 Len=0
5 0.069469000 192.168.1.130 157.55.130.157 TCP 66 49166 > 40013 [PSH, ACK] seq=5 Ack=91 win=255 Len
6 0.120203000 157.55.130.157 192.168.1.130 TCP 60 40013 > 49166 [ACK] seq=91 Ack=17 Win=83 Len=0
7 0.120559000 157.55.130.157 192.168.1.130 TCP 60 40013 > 49166 [PSH, ACK] seq=91 Ack=17 Win=83 Len
8 0.327738000 192.168.1.130 157.55.130.157 TCP 54 49166 > 40013 [ACK] Seq=17 Ack=95 Win=255 Len=0
9 0.360199000 157.55.130.157 192.168.1.130 TCP 326 40013 > 49166 [PSH, ACK] Seq=95 Ack=17 Win=83 Len
10 0.561615000 192.168.1.130 157.55.130.157 TCP 54 49166 > 40013 [ACK] Seq=17 ACK=367 Win=254 Len=0
11 1.140459000 192.168.1.130 192.168.1.1 DNS /4 Standard query 0xded2 A www.google.com
12 1.15524/000 192.168.1.1 192.168.1.130 DNS 154 Standard query response 0xded2 A /4.125.225.209
13 1. 23 2568000 192.168.1.130 1/2.1/.0.254 SNNP 119 get-request 1. 5. 6.1.2.1.25.3.2.1.5.1 1. 5. 6.1.2.1.
14 1.5/6595000 192.168.1.130 /4.125.225.209 TCP 66 49522 > http [StN] Sed=0 win=8192 Len=0 MSS=1400
15 1.5/6/34000 192.165.1.130 /4.125.225.209 TCP 06 49523 > http [5/k] Sed=0 Wil=8192 Len=0 MSS=1400
101.011218000 /4.123.223.209 192.108.1.130 TCP 00 TCP 2923 [SYN, ACK] Seq=0 ACK=1 WITH=14300 LCP
1/1.011293000 192.100.1130
161.01133000 /4.123.223.209 192.100.1.130 ICP 00 IICP 49322 [SIN, ACK] Seq-0 ACK=1 WIH=14300 [CP
4
🗑 Frame 4: 60 bytes on wire (480 bits), 60 bytes captured (480 bits) on interface 0
B Internet Protocol Version 4, Src: 157.55.130.157 (157.55.130.157), Dst: 192.168.1.130 (192.168.1.130)
🗄 Transmission Control Protocol, Src Port: 40013 (40013), Dst Port: 49166 (49166), Seq: 91, Ack: 5, Len: 0

#### Step 2: Locate appropriate packets for the web session.

If the computer was recently started and there has been no activity in accessing the Internet, you can see the entire process in the captured output, including the Address Resolution Protocol (ARP), Domain Name System (DNS), and the TCP three-way handshake. The capture screen in Part 2, Step 1 shows all the packets the computer must get to www.google.com. In this case, the PC already had an ARP entry for the default gateway; therefore, it started with the DNS query to resolve www.google.com.

a. Frame 11 shows the DNS query from the PC to the DNS server, attempting to resolve the domain name, www.google.com to the IP address of the web server. The PC must have the IP address before it can send the first packet to the web server.

What is the IP address of the DNS server that the computer queried?

- b. Frame 12 is the response from the DNS server with the IP address of www.google.com.
- c. Find the appropriate packet for the start of your three-way handshake. In this example, frame 15 is the start of the TCP three-way handshake.

What is the IP address of the Google web server? \_

d. If you have many packets that are unrelated to the TCP connection, it may be necessary to use the Wireshark filter capability. Enter **tcp** in the filter entry area within Wireshark and press Enter.

<u>F</u> ile	<u>E</u> dit <u>V</u> iew	<u>G</u> o	<u>C</u> apture	<u>A</u> nalyze	<u>Statistics</u>	Telephony	<u> </u>	Internals I	<u>H</u> elp							
				* 2	8   Q	, 🗢 🔿	🧼 不	1	<b>.</b>	ର୍ ପ୍	TT 🛛 🖬	1	8 🖗	Ø		
File	er: tcp							Express	on Clea	r Apply	Save					
No.	Turne		Source		Destinatio	n	Protoco	ol Length	Info							
	1 0.000000	0000	192.168	.1.130	157.55	.130.157	ТСР	54	49166	> 40013	B [ACK]	Seq=1	L Ack=1	Win=25	5 Len=0	
	2 0.033696	5000	157.55.	130.157	/ 192.16	8.1.130	TCP	144	40013 :	> 49166	δ [PSH,	ACK	Seq=1	Ack=1 W	/in=83 L6	en=90
	3 0.034064	1000	192.168	.1.130	157.55	.130.157	TCP	58	3 49166	> 40013	LPSH,	ACK	Seq=1	Ack=91	Win=255	Len=4
	4 0.069409	9000	157.55.	130.15/	192.16	8.1.130	TCP	60	0 40013 :	> 49166	EACK]	Seq=9	)1 ACK=	5 W1n=8	3 Len=0	1.000 1.0
	5 0.069469	9000	192.168	120 153	157.55	.130.15/	TCP	6	49166	> 40013	[PSH,	ACK	seq=5	ACK=91	W1n=255	Len=12
	7 0 120203	3000	157.55.	130.15/	192.10	8.1.130	TCP	00	40013	> 49100	E CDCH	Seq=s	ACK=	1/ WITH	ios Len=u	
	7 0.120555 8 0 227729	0000	102 169	130.13/	192.10	120 157	TCP	5	40013	> 49100	EACK	ACK	Seq=91	ACK=17	255 Lop	Len=4
	9.0.360190	2000	157 55	130 157	7 102 16	8 1 130	TCP	32/	49100 ·	> 40015	E [ACK]	ACK	Seg-05	Ack-17	win-83	Len-272
1	0 0 56161	5000	192 168	1 1 30	157 55	130 157	тср	5/	40015	> 40013	[ACK]	Sed-1		367 Wir		1-0
- 1	4 1. 57659	5000	192.168	1.1.130	74.125	. 225. 209	TCP		5 49522	> http	[SYN]	Sea=0	Win=81	92 Len=	0 MSS=14	160 WS=4 54
1	5 1. 576754	1000	192.168	.1.130	74.125	. 225. 209	TCP	6	5 4 9 5 2 3	> http	[SYN]	Seq=0	Win=81	92 Len=	0 MSS=14	160 WS=4 5A
1	6 1.611218	3000	74.125.	225,209	9 192.16	8.1.130	TCP	60	5 http >	49523	[SYN.	ACK] S	Sea=0 A	ck=1 Wi	n=14300	Len=0 MSS=
1	7 1.61129	3000	192.168	.1.130	74.125	.225.209	TCP	54	49523	> http	[ACK]	Sea=1	Ack=1	Win=657	'80 Len=0	)
1	8 1.61155	3000	74.125.	225.209	9192.16	8.1.130	тср	66	5 http >	49522	[SYN,	ACK] S	Seq=0 A	ck=1 Wi	n=14300	Len=0 MSS=
1	9 1.611614	1000	192.168	.1.130	74.125	.225.209	ТСР	54	49522	> http	[ACK]	Seq=1	Ack=1	Win=657	'80 Len=(	)
2	0 1.613640	5000	192.168	.1.130	74.125	.225.209	) HTTP	619	GET /	НТТР/1.	1					
2	1 1.651662	2000	74.125.	225.209	9192.16	8.1.130	TCP	60	) http >	49523	[ACK]	Seq=1	Ack=56	6 Win=1	.5488 Ler	า=0
•																
±Ε	rame 4: 60	0 by	rtes on w	vire (4	80 bits)	), 60 by	tes cap	otured (4	30 bits)	on int	terface	e 0				
+ E	thernet I	I, S	rc: Ciso	:o-Li_f	6:84:6e	(58:6d:	8f:f6:8	84:6e), D	st: Quan	itaCo_fa	a:de:0o	l (c8:	0a:a9:f	a:de:0	d)	
+ I	nternet Pi	roto	col Vers	sion 4,	Src: 15	57.55.13	0.157 (	(157.55.1)	30.157),	Dst: 1	192.168	3.1.13	0 (192.	168.1.3	L30)	
+ T	ransmissi	on c	ontrol F	rotoco	l, Src F	Port: 40	013 (40	0013), Ds1	Port:	49166 (	(49166)	, Seq	: 91, A	Ack: 5,	Len: 0	

# Step 3: Examine information within packets including IP addresses, TCP port numbers, and TCP control flags.

- a. In our example, frame 15 is the start of the three-way handshake between the PC and the Google web server. In the packet list pane (top section of the main window), select the frame. This highlights the line and displays the decoded information from that packet in the two lower panes. Examine the TCP information in the packet details pane (middle section of the main window).
- b. Click the + icon to the left of the Transmission Control Protocol in the packet details pane to expand the view of the TCP information.
- c. Click the + icon to the left of the Flags. Look at the source and destination ports and the flags that are set.

**Note**: You may have to adjust the top and middle windows sizes within Wireshark to display the necessary information.

File Edit View Go Capture Analyze Statistics Telephony Iools Internals Help											
프 프 프 프 프 프 프 프 프 프 프 프 프 프 프 프 프 프 프											
Filter tcp Expression Clear Apply Save											
40. Time Source Destination Protocol Length Info 10 07-516/51000 1922, 1635 1, 350 1322, 555, 160, 552 (29) 162 ≤ 240013   ACK  Sec=17 ACK=367 (#11=255   Len=0											
14 1.576595000 102.168.1.130 74.125.225.200 TCP 66.49522 > http [SYN] Seq=0 Win=8102.Len=0 MS5=1460 WS=4 SACK PERM-1											
161.611218000 74.125.225.209 192.168.1.130 TCP 66 http > 49523 [SYN, ACK] Seq=0 Ack=1 Win=14300 Len=0 MSS=1430 SACK_PERM=1 WS=64											
17 1.01729000 192.105.1130 74.125.225.20 192.105.1130 TCP 66 http > 4952 > http [Ack] Seq=1 Ack=1 Win=05780 Len=0 18 1.611553000 74.125.225.20 192.165.1130 TCP 66 http > 4952 [SVN, Ack=1 Win=14300 Len=0 MS5=1430 SACK_PERM=1 WS=64											
*											
Transmission Control Protocol, Src Port: 49523 (49523), Dst Port: http (80), Seq: 0, Len: 0											
Source porc: 49523 (49523) Destination port: http (80)											
[Stream index: 2] Sequence number: 0 (relative sequence number)											
Header length: 32 bytes											
000 ekserved: Not set											
Normannia Nordez: Not set											
0 = ECN-Echo: Not set											
0 = Acknowledgment: Not set											
Window size value: 8192 [calculated window size: 8192]											
Checksum: 0xceof [validation disabled]											
3000       58       6d       8f       6f       84       6e       c8       0a       a9       fa       de       0d       004       00       74       00       00       a4       a4       n.											
M Frame (frame), 66 bytes         Packets: 178 Displayed: 170 Marked: 0 Load time: 0:00.046         Profile: Default											
What is the TCP source port number?											
How would you classify the source port?											
What is the TCP destination port number?											
How would you classify the destination port?											
Which flag (or flags) is set?											
What is the relative sequence number set to?											

d. To select the next frame in the three-way handshake, select Go on the Wireshark menu and select Next Packet In Conversation. In this example, this is frame 16. This is the Google web server reply to the initial request to start a session.

Eile Edit View Go Capture Analyze Statistics Telephony Iools Internals Help
🖳 😹 🛎 😫 🔚 🔚 🗶 😂 음   9, 수 💠 🗢 7 🔽   🗐 🗐   9, 9, 9, 9, 11 📓 🗵 🥵 😕   12
Filter: tcp Expression Clear Apply Save
do. Time Source Destination Protocol Length Info 100 INSTATISTICS DESTINGTION STATISTICS
14 1.52659500 192.166.1.130 74.125.225.209 TCP 66.49522 > http://sce.owinesig.com/science/intersorterior/science/i
15 1.576754000 192.168.1.130 74.125.225.209 TCP 66 49523 > http [SVN] Seq=0 win=8192 Len=0 MSS=1460 WS=4 SACK_PERM=1
16 1.611218000 74.125.225.209 192.168.1.130 TCP 66 http > 49523 [SYN, ACK] Seq=0 Ack=1 win=14300 Len=0 MSS=1430 SACK_PERM=1 WS=64
17 1.611293000 192.168.1.130 74.125.225.209 TCP 54 49523 > http [ACK] Seq=1 Ack=1 win=65780 Len=0
18 1.611553000 74.125.225.209 192.168.1.130 TCP 66 http > 49522 [SYN, ACK] Seq=0 Ack=1 win=14300 Len=0 MSS=1430 SACK_PERM=1 WS=64
<pre></pre>
🖂 Transmission Control Protocol, Src Port: http (80), Dst Port: 49523 (49523), Seq: 0, Ack: 1, Len: 0
Source port: http (80)
Destination port: 49523 (49523)
[Stream index: 2]
Sequence number: 0 (relative sequence number)
Acknowledgment number: 1 (relative ack number)
neader Tength: 32 Dytes
000 = Peservad' Not set
0 = Congestion Window Reduced (CWR): Not set
0 = Urgent: Not set
1 = Acknowledgment: Set
0 = Push: Not set
0 = Reset: Not set
⊕1. = Syn: Set
0 = Fin: Not set
Window size value: 14300
[Calculated window Size: 14300]
e crecksum, oxodes i variadi or arsabled
JUDU C8 U8 A9 TA GE U8 38 68 8T T6 84 6E 08 00 45 20
020 01 82 00 50 c1 73 a2 e5 5b 91 3b 89 92 21 80 12P.S. [:!.
030 37 dc ba e5 00 00 02 04 05 96 01 01 04 02 01 03 7
Judu US UO

What are the values of the source and destination ports? \_\_\_\_\_

Which flags are set? \_\_\_\_

What are the relative sequence and acknowledgement numbers set to?

e. Finally, examine the third packet of the three-way handshake in the example. Clicking frame 17 in the top window displays the following information in this example:

<u>File Edit View Go Capture Analyze Statistics</u>	Telephony <u>T</u> ools <u>I</u> nternals <u>H</u> elp										
	- 	0. 0. 17   🖉 🗏 🧏 🎉   💢									
Filter:	Expression	. Clear Apply Save									
No. Time Source	Destination Protocol	ol Length Info									
12 1.155247000 192.168.1.1	192.168.1.130 DNS	154 Standard query response 0xded2 A 74.125.225.209 A 74.125.225.210 A 74.125.225.212 A									
13 1.232568000 192.168.1.130	172.17.0.254 SNMP	119 get-request 1.3.6.1.2.1.25.3.2.1.5.1 1.3.6.1.2.1.25.3.5.1.1.1 1.3.6.1.2.1.25.3.5.1.2.									
14 1.576595000 192.168.1.130	74.125.225.209 TCP	66 49522 > http [SYN] Seq=0 win=8192 Len=0 MSS=1460 WS=4 SACK_PERM=1									
15 1.576754000 192.168.1.130	74.125.225.209 TCP	66 49523 > http [SYN] seq=0 win=8192 Len=0 MSS=1460 WS=4 SACK_PERM=1									
16 1.611218000 74.125.225.209	192.168.1.130 TCP	66 http > 49523 [SYN, ACK] seq=0 Ack=1 win=14300 Len=0 MSS=1430 SACK_PERM=1 WS=64									
17 1.611293000 192.168.1.130	74.125.225.209 TCP	54 49523 > http [ACK] seq=1 Ack=1 win=65780 Len=0									
18 1.611553000 74.125.225.209	192.168.1.130 TCP	66 http > 49522 [SYN, ACK] seq=0 Ack=1 win=14300 Len=0 MSS=1430 SACK_PERM=1 wS=64									
<		· · · · · · · · · · · · · · · · · · ·									
<pre>10 1.01103000 /*.22.20.009 192.105.1.100 10 to bottp &gt; 49522 [SYN, Ack] Seq-0 Ack-1 Win=14300 Len-0 MSS=1430 SACK_PERM=1 WS=64</pre>											
0010 00 28 20 38 40 00 80 06 00 00 c0 0020 e1 d1 c1 73 00 50 3b 89 92 21 a2 0030 40 3d ee 93 00 00	a8 01 82 4a 7d . (8@ e5 5b 92 50 10s.P;.	· · · · · · · · ]} · · · ! · . [.P.									

Examine the third and final packet of the handshake.

Which flag (or flags) is set?

The relative sequence and acknowledgement numbers are set to 1 as a starting point. The TCP connection is now established, and communication between the source computer and the web server can begin.

f. Close the Wireshark program.

#### Reflection

- 1. There are hundreds of filters available in Wireshark. A large network could have numerous filters and many different types of traffic. Which three filters in the list might be the most useful to a network administrator?
- 2. What other ways could Wireshark be used in a production network?

# 7.2.3.5 Lab - Using Wireshark to Examine a UDP DNS Capture





## **Objectives**

Part 1: Record a PC's IP Configuration Information

Part 2: Use Wireshark to Capture DNS Queries and Responses

#### Part 3: Analyze Captured DNS or UDP Packets

## **Background / Scenario**

If you have ever used the Internet, you have used the Domain Name System (DNS). DNS is a distributed network of servers that translates user-friendly domain names like www.google.com to an IP address. When you type a website URL into your browser, your PC performs a DNS query to the DNS server's IP address. Your PC's DNS server query and the DNS server's response make use of the User Datagram Protocol (UDP) as the transport layer protocol. UDP is connectionless and does not require a session setup as does TCP. DNS queries and responses are very small and do not require the overhead of TCP.

In this lab, you will communicate with a DNS server by sending a DNS query using the UDP transport protocol. You will use Wireshark to examine the DNS query and response exchanges with the name server.

Note: This lab cannot be completed using Netlab. This lab assumes that you have Internet access.

## **Required Resources**

1 PC (Windows 7, Vista, or XP with a command prompt access, Internet access, and Wireshark installed)

## Part 1: Record a PC's IP Configuration Information

In Part 1, you will use the **ipconfig /all** command on your local PC to find and record the MAC and IP addresses of your PC's network interface card (NIC), the IP address of the specified default gateway, and the DNS server IP address specified for the PC. Record this information in the table provided. The information will be used in the following parts of this lab with packet analysis.

IP address	
MAC address	
Default gateway IP address	
DNS server IP address	

## Part 2: Use Wireshark to Capture DNS Queries and Responses

In Part 2, you will set up Wireshark to capture DNS query and response packets to demonstrate the use of UDP transport protocol while communicating with a DNS server.

a. Click the Windows Start button and navigate to the Wireshark program.

Note: If Wireshark is not yet installed, it can be downloaded at <u>http://www.wireshark.org/download.html</u>.

- b. Select an interface for Wireshark for capturing packets. Use the **Interface List** to choose the interface that is associated with the recorded PC's IP and Media Access Control (MAC) addresses in Part 1.
- c. After selecting the desired interface, click Start to capture the packets.
- d. Open a web browser and type www.google.com. Press Enter to continue.
- e. Click **Stop** to stop the Wireshark capture when you see Google's home page.

## Part 3: Analyze Captured DNS or UDP Packets

In Part 3, you will examine the UDP packets that were generated when communicating with a DNS server for the IP addresses for www.google.com.

#### Step 1: Filter DNS packets.

a. In the Wireshark main window, type **dns** in the entry area of the **Filter** toolbar. Click **Apply** or press Enter.

**Note**: If you do not see any results after the DNS filter was applied, close the web browser and in the command prompt window, type **ipconfig /flushdns** to remove all previous DNS results. Restart the Wireshark capture and repeat the instructions in Part 2b –2e. If this does not resolve the issue, in the command prompt window, you can type **nslookup www.google.com** as an alternative to the web browser.

🗖 Ca	Capturing from Microsoft: \Device\NPF_{853821E3-ACB7-400B-8CCB-9B26B91F82AB} [Wireshark 1.8.3 (SVN Rev 45256 from /trunk-1.8)]																								
Eile	<u>E</u> dit	View	/ <u>G</u>	<u>o (</u>	aptu	re <u>4</u>	Analyze	<u>S</u> tat	istics	Tel	epho	п <u>у</u> .	<u>I</u> ools	Inte	ernals <u>H</u> el	р									
	<b>1</b>		۵	Ĺ			X 2	8		2 4	•		Ŧ	⊉		⊕ <b>€</b>			¥ 1	2 🍕	5 %	g	2		
Filter	r: dns													-	Expression	Clear	Apply	y Sav	e						
No.	1	ime			So	urce			Dest	inatio	n		Prot	ocol	Length	Info									
	4 :	L.61	L 3 5 5	5600	0 19	92.1	68.1.	11	192	2.168	3.1.	1	DNS	5	74	Standa	rd qu	uery	0x3f7	5 A	WWW.	goog	jle.c	om	
	5 :	L.62	2437	7600	0 19	92.1	68.1.	.1	192	2.168	3.1.	11	DNS	5	290	Standa	rd qu	uery	respo	nse	0x3f7	′6 A	A 74.	125.	
	47	2.18	3098	3500	0 19	92.1	68.1.	11	192	2.168	3.1.3	1	DNS	5	75	Standa	rd qı	uery	0x6bd	C A	plus	.god	gle.	com	
	48	2.18	3186	5600	0 19	92.1	68.1.	11	192	2.168	3.1.3	1	DNS	5	75	Standa	rd qu	uery	0x318	FΑ	maps	.god	ogle.	com	
	49	2.18	3244	1000	0 19	92.1	68.1.	11	192	2.168	3.1.3	1	DNS	5	75	Standa	rd qu	uery	0x5d41	FΑ	play	/ <b>.</b> goo	ogle.	com	Ŧ
-		_									1	11								_				•	
	rame 4	1: 7	74 b	ovte	s or	n wi	re (	592 ł	bits	i). 7	74 b	vte	; ca	ptur	ed (592	bits)	on i	nteri	face 0						
	thern	et I	Π.	Src	: н	onHa	iPr	be:15	5:63	6 (90	):4c	:e5	be:	15:6	3). Dst:	Netae	ar 9	9:c5	:72 (3	0:46	:9a:9	99:c	5:72)		
II H	ntern	et F	rot	oco	ol ve	ersi	on 4	. Sro	c: 1	92.1	168.	1.11	(1	92.1	68.1.11	). Dst:	192	.168	1.1 (	192.	168.1	1.1)			
H US	ser D	atad	aran	n Pr	oto	col.	Snc	Port	t: 5	52110	) (5	2110	nÈ	Dst	Port: do	omain (	53)					1			
+ D0	omain	Nan	ne s	syst	em	(que	ry)						· ·												
				1																					
0000	) 30	46	9a	99	c5 7	29	0 4c	e5	be	15 6	3 08	3 00	45	00	0Fr	.L	с <b></b> Е.								
0010	00	3c	40	9f	00 0	0 8	0 11	76	b5	c0 a	8 01	0b	c0	a8	.<@	· · · · · ·									
0020	0 01	01	CD	8e	00 d	5 0	0 28	e2	51	3T /	6 01 7 6f	00	00	01		· ( · _?\	/								
0030	65	03	63	6f	6d 0		0 01	66	61	00 0	0	01	07	oc	e.com.	.w ww. <u>c</u>	yoogi	1							
		-	-						-																
	2		\D.			05202		007.40		Deal		0 D:		1.40	DCl.	N-6It									_
	🔵 💅 Microsoft: \Device\NPF_{853821E3-ACB7-40 🛛 Packets: 630 Displayed: 40 🛛 F											Profile: Default													

b. In the packet list pane (top section) of the main window, locate the packet that includes "standard query" and "A www.google.com". See frame 4 as an example.
#### Step 2: Examine UDP segment using DNS query.

Examine UDP by using a DNS query for www.google.com as captured by Wireshark. In this example, Wireshark capture frame 4 in the packet list pane is selected for analysis. The protocols in this query are displayed in the packet details pane (middle section) of the main window. The protocol entries are highlighted in gray.

 B Frame 4: 74 bytes on wire (592 bits), 74 bytes captured (592 bits) on interface 0
 B Ethernet II, Src: HonHaiPr\_be:15:63 (90:4c:e5:be:15:63), Dst: Netgear\_99:c5:72 (30:46:9a:99:c5:72)
 B Internet Protocol Version 4, Src: 192.168.1.11 (192.168.1.11), Dst: 192.168.1.1 (192.168.1.1)
 □ User Datagram Protocol, Src Port: 52110 (52110), Dst Port: domain (53) Source port: 52110 (52110) Destination port: domain (53) Length: 40
 B Checksum: 0xe25f [validation disabled]
 B Domain Name System (query)

- a. In the packet details pane, frame 4 had 74 bytes of data on the wire as displayed on the first line. This is the number of bytes to send a DNS query to a name server requesting the IP addresses of www.google.com.
- b. The Ethernet II line displays the source and destination MAC addresses. The source MAC address is from your local PC because your local PC originated the DNS query. The destination MAC address is from the default gateway, because this is the last stop before this query exits the local network.

Is the source MAC address the same as recorded from Part 1 for the local PC? \_

c. In the Internet Protocol Version 4 line, the IP packet Wireshark capture indicates that the source IP address of this DNS query is 192.168.1.11, and the destination IP address is 192.168.1.1. In this example, the destination address is the default gateway. The router is the default gateway in this network.

Can you pair up the IP and MAC addresses for the source and destination devices?

Device	IP Address	MAC Address
Local PC		
Default Gateway		

The IP packet and header encapsulates the UDP segment. The UDP segment contains the DNS query as the data.

d. A UDP header only has four fields: source port, destination port, length, and checksum. Each field in UDP header is only 16 bits as depicted below.

	UDP SEGMENT									
0	) 16									
	UDP SOURCE PORT UDP DESTINATION PORT									
	UDP MESSAGE LENGTH	UDP CHECKSUM								
	DATA									
	DAT	A								

Expand the User Datagram Protocol in the packet details pane by clicking the plus (+) sign. Notice that there are only four fields. The source port number in this example is 52110. The source port was randomly generated by the local PC using port numbers that are not reserved. The destination port is 53. Port 53 is a well-known port reserved for use with DNS. DNS servers listen on port 53 for DNS queries from clients.

```
    □ User Datagram Protocol, Src Port: 52110 (52110), Dst Port: domain (53)
Source port: 52110 (52110)
    Destination port: domain (53)
    Length: 40
    □ Checksum: 0xe25f [validation disabled]
    [Good Checksum: False]
    [Bad Checksum: False]
```

In this example, the length of this UDP segment is 40 bytes. Out of 40 bytes, 8 bytes are used as header. The other 32 bytes are used by DNS query data. The 32 bytes of DNS query data is highlighted in the following illustration in the packet bytes pane (lower section) of the Wireshark main window.



The checksum is used to determine the integrity of the packet after it has traversed the Internet.

The UDP header has low overhead because UDP does not have fields that are associated with three-way handshake in TCP. Any data transfer reliability issues that occur must be handled by the application layer.

Record your Wireshark results in the table below:

Frame Size	
Source MAC address	
Destination MAC address	
Source IP address	
Destination IP address	
Source Port	
Destination Port	

Is the source IP address the same as the local PC's IP address recorded in Part 1?

Is the destination IP address the same as the default gateway noted in Part 1? \_\_\_\_\_

#### Step 3: Examine UDP using DNS response.

In this step, you will examine the DNS response packet and verify that DNS response packet also uses UDP.

a. In this example, frame 5 is the corresponding DNS response packet. Notice the number of bytes on the wire is 290 bytes. It is a larger packet as compared to the DNS query packet.

Filter:	dns			-	Expression.	Clear Ap	oply Sav	/e		
No.	Time	Source	Destination	Protocol	Length	Info				
	4 1.61355600	0 192.168.1.11	192.168.1.1	DNS	74	Standard	query	0x3f76	A www.google.d	:om 📟
	5 1.62437600	0 192.168.1.1	192.168.1.11	DNS	290	Standard	query	respons	e 0x3f76 A 74.	125
	47 2.18098500	0 192.168.1.11	192.168.1.1	DNS	75	Standard	query	0x6bdc	A plus.google.	CON
	48 2.18186600	0 192.168.1.11	192.168.1.1	DNS	75	Standard	query	0x318f	A maps.google.	CON
	49 2.18244000	0 192.168.1.11	192.168.1.1	DNS	75	Standard	query	0x5d4f	A play.google.	con 👻
•										P.
🗄 Fra	ame 5: 290 byt	es on wire (232	20 bits), 290 b	ytes cap	otured (2	2320 bits	) on i	nterface	e O	
🗄 Et	hernet II, Src	: Netgear_99:c!	5:72 (30:46:9a:	99:c5:72	2), Dst:	HonHaiPr	_be:15	:63 (90:	4c:e5:be:15:63)	)
🗄 Int	ternet Protoco	l Version 4, Sr	<pre>`c: 192.168.1.1</pre>	(192.16	58.1.1),	Dst: 192	.168.1	.11 (192	.168.1.11)	
🖃 Use	er Datagram Pr	otocol, Src Por	rt: domain (53)	, Dst Po	ort: 5211	0 (52110)	)			
5	Source port: d	omain (53)								
(	Destination po	rt: 52110 (5211	L0)							
1	Length: 256									
	Checksum: 0xc4	ca [validation	disabled]							
	[Good Checks	um: False]								
	[Bad Checksu	m: False]								
🗄 🗄 Dor	main Name Syst	em (response)								

- b. In the Ethernet II frame for the DNS response, from what device is the source MAC address and what device is the destination MAC address?
- c. Notice the source and destination IP addresses in the IP packet. What is the destination IP address? What is the source IP address?

Destination IP address: \_\_\_\_\_Source IP address: \_\_\_\_\_

What happened to the roles of source and destination for the local host and default gateway?

d. In the UDP segment, the role of the port numbers has also reversed. The destination port number is 52110. Port number 52110 is the same port that was generated by the local PC when the DNS query was sent to the DNS server. Your local PC listens for a DNS response on this port.

The source port number is 53. The DNS server listens for a DNS query on port 53 and then sends a DNS response with a source port number of 53 back to originator of the DNS query.

When the DNS response is expanded, notice the resolved IP addresses for www.google.com in the **Answers** section.

User Datagram Protocol. Src Port: domain (53). Dst Port: 52110 (52110)
Source port: domain (53)
Destination port: 52110 (52110)
Length: 256
□ Checksum: 0xc4ca [validation disabled]
[Good Checksum: False]
[Bad Checksum: False]
🖬 Domain Name System (response)
[Request In: 4]
[Time: 0.010820000 seconds]
Transaction ID: 0x3776
🗄 Flags: 0x8180 Standard query response, No error
Questions: 1
Answer RRs: 5
Authority RRS: 4
Additional RRS: 4
Quernes
Answers
Www.google.com: type A, class IN, addr /4.125.22/.84
Www.google.com: type A, class IN, addr /4.125.22/.80
Www.google.com: type A, class IN, addr /4.125.22/.81
Www.google.com: type A, Class IN, addr 74.125.227.82
Www.google.com: type A, Class IN, addr 74.125.227.85
Authoritative nameservers
B google com: type NS, class IN, IS ISI.google.com
B google.com: type NS, class IN, ns ns2.google.com
B google com: type NS, class IN, ns nss google com
□ google.com
# ns1.google.com: type A, class IN, addr 216.239.32.10
m ns2.google.com: type A. class IN. addr 216,239,34.10
ℜ ns3.google.com: type A, class IN, addr 216,239.36.10
⊞ ns4.google.com: type A, class IN, addr 216.239.38.10

## Reflection

What are the benefits of using UDP instead of TCP as a transport protocol for DNS?

## 7.2.4.3 Lab - Using Wireshark to Examine FTP and TFTP Captures

## Topology – Part 1 (FTP)

Part 1 will highlight a TCP capture of an FTP session. This topology consists of a PC with Internet access.



## Topology – Part 2 (TFTP)

Part 2 will highlight a UDP capture of a TFTP session. The PC must have both an Ethernet connection and a console connection to Switch S1.



## Addressing Table (Part 2)

Device	Interface	IP Address	Subnet Mask	Default Gateway
S1	VLAN 1	192.168.1.1	255.255.255.0	N/A
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## **Objectives**

### Part 1: Identify TCP Header Fields and Operation Using a Wireshark FTP Session Capture

Part 2: Identify UDP Header Fields and Operation Using a Wireshark TFTP Session Capture

## **Background / Scenario**

The two protocols in the TCP/IP transport layer are the TCP, defined in RFC 761, and UDP, defined in RFC 768. Both protocols support upper-layer protocol communication. For example, TCP is used to provide transport layer support for the HyperText Transfer Protocol (HTTP) and FTP protocols, among others. UDP provides transport layer support for the Domain Name System (DNS) and TFTP among others.

**Note**: Understanding the parts of the TCP and UDP headers and operation are a critical skill for network engineers.

In Part 1 of this lab, you will use Wireshark open source tool to capture and analyze TCP protocol header fields for FTP file transfers between the host computer and an anonymous FTP server. The Windows command line utility is used to connect to an anonymous FTP server and download a file. In Part 2 of this lab, you will use Wireshark to capture and analyze UDP protocol header fields for TFTP file transfers between the host computer and Switch S1.

**Note**: The switch used is a Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the available commands and output produced might vary from what displays in the labs.

**Note**: Make sure that the switch has been erased and has no startup configurations. If you are unsure, contact your instructor.

**Note:** Part 1 assumes the PC has Internet access and cannot be performed using Netlab. Part 2 is Netlab compatible.

## **Required Resources – Part 1 (FTP)**

1 PC (Windows 7, Vista, or XP with command prompt access, Internet access, and Wireshark installed)

## **Required Resources – Part 2 (TFTP)**

- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with Wireshark and a TFTP server, such as tftpd32 installed)
- Console cable to configure the Cisco IOS devices via the console port
- Ethernet cable as shown in the topology

# Part 1: Identify TCP Header Fields and Operation Using a Wireshark FTP Session Capture

In Part 1, you use Wireshark to capture an FTP session and inspect TCP header fields.

### Step 1: Start a Wireshark capture.

- a. Close all unnecessary network traffic, such as the web browser, to limit the amount traffic during the Wireshark capture.
- b. Start the Wireshark capture.

### Step 2: Download the Readme file.

- a. From the command prompt, enter **ftp ftp.cdc.gov**.
- b. Log into the FTP site for Centers for Disease Control and Prevention (CDC) with user **anonymous** and no password.
- c. Locate and download the Readme file.

```
C:\Users\user1>ftp ftp.cdc.gov
Connected to ftp.cdc.gov.
220 Microsoft FTP Service
User (ftp.cdc.gov:(none>): anonymous
331 Anonymous access allowed, send identity (e-mail name) as password.
Password:
230 Anonymous user logged in.
ftp> 1s
200 PORT command successful.
150 Opening ASCII mode data connection for file list.
aspnet_client
pub
Readme
Siteinfo
up.htm
w3c
web.config
welcome.msg
226 Transfer complete.
ftp: 76 bytes received in 0.00Seconds 19.00Kbytes/sec.
ftp> get Readme
200 PORT command successful.
150 Opening ASCII mode data connection for Readme(1428 bytes).
226 Transfer complete.
ftp: 1428 bytes received in 0.01Seconds 204.00Kbytes/sec.
ftp> quit
221
```

#### Step 3: Stop the Wireshark capture.

#### Step 4: View the Wireshark Main Window.

Wireshark captured many packets during the FTP session to ftp.cdc.gov. To limit the amount of data for analysis, type **tcp and ip.addr == 198.246.112.54** in the **Filter: entry** area and click **Apply**. The IP address, 198.246.112.54, is the address for ftp.cdc.gov.

<u>F</u> ile	: I	Edit	View	<u> </u>	0	<u>C</u> apt	ure	<u>A</u> n	alyze	<u>S</u> tat	istics	; 1	Felep	hony	<u>1</u>	ools	Inte	ernals	<u>H</u> e	lp									
	ë	6	( )	(	í I			X	2	₽		S	4	١		T	⊉				Ð, (	Ð,	11	++	<b>X</b>	Y	•	*	Ø
Filt	er:	tcp a	and ip	o.add	lr = :	= 198	.246.	112.	54								•	Expre	ession	ı	Clear	A	pply	Save					
No.		Time			S	ourc	e			Des	tinat	ion			Pr	otoc	ol	Lengtł	n I	nfo									
	5	1.1	3671	.600	00 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54		СР			66 4	4924	3 >	• ft	:р[	SYN]	Se	q=0	Win	=819	92 Ler
	7	1.22	2650	200	00 1	L98.	246	5.11	L2.54	119	2.1	68.	1.1	.7	Т	СР			66 f	Ftp	> 4	924	3 [	SYN,	ACI	<] :	5eq=	0 AC	:k=1 W
	8	1.22	2662	2700	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	T	СР			54 4	4924	13 >	ft	:p [	ACK]	Se	<b>q=1</b>	Ack	=1 W	/in=81
	9	1.31	1456	800	0 1	L98.	246	5.11	L2.54	119	2.1	68.	1.1	.7	F	ТΡ			81 F	Resp	ons	e:	220	) Mic	ros	oft	FTP	Ser	vice
1	10	1.52	2337	200	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	T	СР			54 4	4924	3 >	ft	:р[	ACK]	Se	<b>q=1</b>	Ack	=28	Win=8
1	12	4.58	8518	3500	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	F	TP			70 F	Requ	iest	:: U	JSER	and	nym	ous			
1	13	4.67	7504	000	0 1	L98.	246	5.11	L2.54	19	2.1	68.	1.1	.7	F	ТΡ		1	26 F	Resp	ons	e:	331	And	nym	ous	acc	ess	allow
1	14	4.87	7724	500	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	T	СР			54 4	4924	13 >	- ft	:р[	ACK]	Se	q=17	7 AC	k=10	0 Wir
1	19	5.90	5151	.400	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	F	ТΡ			61 F	Requ	iest	: F	ASS	;					
- 1	20	6.04	1892	900	0 1	L98.	246	5.11	L2.54	19	2.1	68.	1.1	.7	F	TP			85 F	Resp	ons	e:	230	And	nym	ous	use	r 10	ogged
- 1	21	6.2	5008	300	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	T	СР			54 4	4924	13 >	• ft	:р[	ACK]	See	q=24	4 AC	k=13	1 Wir
- 1	25	8.8	5522	500	0 1	L92.	168	3.1.	.17	19	8.2	46.	112	. 54	F	ТΡ			80 F	Requ	iest	: F	ORT	192	,16	8,1	,17,	192,	92
	_			_	_			_			_	11	1		_							_							-
			<i>.</i>						- /5	20 1			~ ~							1.2	>					~			
	-na	ume	); (	1 00	yt	es (	on v	NIL.	e (S	28 0	1115	2.	00	by	ces	Ca	ptur	ea (	228	DI	(S)	on	10	certa	ace	0			0
	Etr	iern	et I	ц,	Sr	C: I	Hone	han	Pr_D	e:1:	0:0:		90:	40:	e5:	be:	12:0	)3), (0, 1	DST	: N	etg	ear	_99	:05:	(2 (	30:	40:	9a:9	9:05:
	Int	.ern	eti	rot	.0C		vers	510	n 4,	Sro		.92	.10	8.1	. 17	(1)	92.1	1.80.1		),	DST	: I	98.	246		54	(190	5.24	0.112
±	ina	เกรต	1551	on	CO	ntro		ro	τοςο	1, 3	src	PO	rt:	49.	243	(4)	9243	9), L	sτ	Por	τ: 1	гτр	(2.	1), :	seq:	Ο,	Lei	1: 0	
000	00	30	46	9a	99	c5	72	90	4c	e5	be	15	63	08	00	45	00	0F	1	r.L		с	Ε.						
001	0	00	34	03	d8	40	00	80	06	fe	05	c0	a8	01	11	c6	f6	. 4	@										
002	0	70	36	c0	5b	00	15	4f	9e	03	са	00	00	00	00	80	02	p6	. [.	.0.			• •						
003	0	20	00	43	21	00	00	02	04	04	ec	01	03	03	00	01	01	•	C!.	• • •	• • •	• • •	••						
004	0	04	02																										

#### Step 5: Analyze the TCP fields.

After the TCP filter has been applied, the first three frames in the packet list pane (top section) displays the transport layer protocol TCP creating a reliable session. The sequence of [SYN], [SYN, ACK], and [ACK] illustrates the three-way handshake.

5 1.136716000	192.168.1.17	198.246.112.54	TCP	66 49243 > ftp [SYN] Seq=0 Win=8192 Le
7 1.226502000	198.246.112.54	192.168.1.17	TCP	66 ftp > 49243 [SYN, ACK] Seq=0 Ack=1
8 1.226627000	192.168.1.17	198.246.112.54	TCP	54 49243 > ftp [ACK] Seq=1 Ack=1 Win=8

TCP is routinely used during a session to control datagram delivery, verify datagram arrival, and manage window size. For each data exchange between the FTP client and FTP server, a new TCP session is started. At the conclusion of the data transfer, the TCP session is closed. Finally, when the FTP session is finished, TCP performs an orderly shutdown and termination.

In Wireshark, detailed TCP information is available in the packet details pane (middle section). Highlight the first TCP datagram from the host computer, and expand the TCP record. The expanded TCP datagram appears similar to the packet detail pane shown below.





The image above is a TCP datagram diagram. An explanation of each field is provided for reference:

- The **TCP source port number** belongs to the TCP session host that opened a connection. The value is normally a random value above 1,023.
- The TCP destination port number is used to identify the upper layer protocol or application on the remote site. The values in the range 0–1,023 represent the "well-known ports" and are associated with popular services and applications (as described in RFC 1700, such as Telnet, FTP, HTTP, and so on). The combination of the source IP address, source port, destination IP address, and destination port uniquely identifies the session to both sender and receiver.

**Note**: In the Wireshark capture below, the destination port is 21, which is FTP. FTP servers listen on port 21 for FTP client connections.

- The **Sequence number** specifies the number of the last octet in a segment.
- The Acknowledgment number specifies the next octet expected by the receiver.
- The **Code bits** have a special meaning in session management and in the treatment of segments. Among interesting values are:
  - ACK Acknowledgement of a segment receipt.
  - SYN Synchronize, only set when a new TCP session is negotiated during the TCP three-way handshake.
  - FIN Finish, request to close the TCP session.
- The **Window size** is the value of the sliding window; determines how many octets can be sent before waiting for an acknowledgement.
- The **Urgent pointer** is only used with an Urgent (URG) flag when the sender needs to send urgent data to the receiver.
- The **Options** has only one option currently, and it is defined as the maximum TCP segment size (optional value).

Using the Wireshark capture of the first TCP session startup (SYN bit set to 1), fill in information about the TCP header:

From the PC to CDC server (only the SYN bit is set to 1):

Source IP Address:	
Destination IP Address:	
Source port number:	
Destination port number:	
Sequence number:	
Acknowledgement number:	
Header length:	
Window size:	

In the second Wireshark filtered capture, the CDC FTP server acknowledges the request from the PC. Note the values of the SYN and ACK bits.



Fill in the following information regarding the SYN-ACK message.

Source IP address:	
Destination IP address:	
Source port number:	
Destination port number:	
Sequence number:	
Acknowledgement number:	
Header length:	
Window size:	

In the final stage of the negotiation to establish communications, the PC sends an acknowledgement message to the server. Notice only the ACK bit is set to 1, and the Sequence number has been incremented to 1.

```
⊕ Frame 8: 54 bytes on wire (432 bits), 54 bytes captured (432 bits) on interface 0

    ⊞ Ethernet II, Src: HonHaiPr_be:15:63 (90:4c:e5:be:15:63), Dst: Netgear_99:c5:72 (30:46:9a:99:c5:72)

B Internet Protocol Version 4, Src: 192.168.1.17 (192.168.1.17), Dst: 198.246.112.54 (198.246.112.54)
□ Transmission Control Protocol, Src Port: 49243 (49243), Dst Port: ftp (21), Seq: 1, Ack: 1, Len: 0
   Source port: 49243 (49243)
   Destination port: ftp (21)
   [Stream index: 0]
                      (relative sequence number)
   Sequence number: 1
   Acknowledgment number: 1 (relative ack number)
   Header length: 20 bytes
 □ Flags: 0x010 (ACK)
    000. .... = Reserved: Not set
...0 .... = Nonce: Not set
     .... 0.... = Congestion Window Reduced (CWR): Not set
     ..... .0.. .... = ECN-Echo: Not set
     .... 0... = Push: Not set
     .... .... ...0 = Fin: Not set
   Window size value: 8192
   [Calculated window size: 8192]
   [Window size scaling factor: 1]
```

Fill in the following information regarding the ACK message.

Source IP address:	
Destination IP address:	
Source port number:	
Destination port number:	
Sequence number:	
Acknowledgement number:	
Header length:	
Window size:	

How many other TCP datagrams contained a SYN bit?

After a TCP session is established, FTP traffic can occur between the PC and FTP server. The FTP client and server communicate between each other, unaware that TCP has control and management over the session. When the FTP server sends a Response: 220 to the FTP client, the TCP session on the FTP client sends an acknowledgment to the TCP session on the server. This sequence is visible in the Wireshark capture below.

	9 1.314568000	198.246.112.54	192.168.1.17	FTP	81 Response: 22	0 Microsoft F	TP Service					
	10 1.523372000	192.168.1.17	198.246.112.54	TCP	54 49243 > ftp	[ACK] Seq=1 A	ck=28 Win≕					
	12 4.585185000	192.168.1.17	198.246.112.54	FTP	70 Request: USE	R anonymous						
	13 4.675040000	198.246.112.54	192.168.1.17	FTP	126 Response: 33	1 Anonymous a	ccess allo					
4												
_		1 (212	1.1		Concertain States of C	-						
+	Frame 9: 81 bytes on wire (648 bits), 81 bytes captured (648 bits) on interface 0											
+	Ethernet II, Sr	<pre>`c: Netgear_99:c</pre>	5:72 (30:46:9a:9	9:c5:72),	Dst: HonHaiPr_be:15:0	53 (90:4c:e5:k	be:15:63)					
+	Internet Protoc	col Version 4, S	rc: 198.246.112.	54 (198.2	46.112.54), Dst: 192.1	168.1.17 (192.	168.1.17)					
+	Transmission Co	ontrol Protocol,	Src Port: ftp ()	21), Dst	Port: 49243 (49243), 9	5eq: 1, Ack: 1	L, Len: 27					
	File Transfer F	Protocol (FTP)										
	220 Microsoft FTP Service\r\n											
	Response co	de: Service rea	dy for new user	(220)								
	Despense ar	. Wieneseft FT	. Convideo									
	кеsponse ar	'g: MICLOSOTT FI	service									

When the FTP session has finished, the FTP client sends a command to "quit". The FTP server acknowledges the FTP termination with a Response: 221 Goodbye. At this time, the FTP server TCP session sends a TCP datagram to the FTP client, announcing the termination of the TCP session. The FTP client TCP session acknowledges receipt of the termination datagram, then sends its own TCP session termination. When the originator of the TCP termination, FTP server, receives a duplicate termination, an ACK datagram is sent to acknowledge the termination and the TCP session is closed. This sequence is visible in the diagram and capture below.



By applying an **ftp** filter, the entire sequence of the FTP traffic can be examined in Wireshark. Notice the sequence of the events during this FTP session. The username anonymous was used to retrieve the Readme file. After the file transfer completed, the user ended the FTP session.

Filter:	ftp			▼ Expre	ession C	lear Apply Save	
No.	Time	Source	Destination	Protocol	Length	Info	
9	1.314568000	198.246.112.54	192.168.1.17	FTP	81	Response: 220	Microsoft FTP Service
12	4.585185000	192.168.1.17	198.246.112.54	FTP	70	Request: USER	anonymous
13	4.675040000	198.246.112.54	192.168.1.17	FTP	126	Response: 331	Anonymous access allowe
19	5.961514000	192.168.1.17	198.246.112.54	FTP	61	Request: PASS	
20	6.048929000	198.246.112.54	192.168.1.17	FTP	85	Response: 230	Anonymous user logged i
25	8.855225000	192.168.1.17	198.246.112.54	FTP	80	Request: PORT	192,168,1,17,192,92
26	8.945530000	198.246.112.54	192.168.1.17	FTP	84	Response: 200	PORT command successful
27	8.955549000	192.168.1.17	198.246.112.54	FTP	60	Request: NLST	
29	9.053034000	198.246.112.54	192.168.1.17	FTP	109	Response: 150	Opening ASCII mode data
39	9.347432000	198.246.112.54	192.168.1.17	FTP	78	Response: 226	Transfer complete.
42	12.621720000	192.168.1.17	198.246.112.54	FTP	80	Request: PORT	192,168,1,17,192,93
43	12.709658000	198.246.112.54	192.168.1.17	FTP	84	Response: 200	PORT command successful
44	12.722592000	192.168.1.17	198.246.112.54	FTP	67	Request: RETR	Readme
45	12.811097000	198.246.112.54	192.168.1.17	FTP	118	Response: 150	Opening ASCII mode data
58	13.107294000	198.246.112.54	192.168.1.17	FTP	78	Response: 226	Transfer complete.
61	15.514815000	192.168.1.17	198.246.112.54	FTP	60	Request: QUIT	
62	15.601920000	198.246.112.54	192.168.1.17	FTP	61	Response: 221	

Apply the TCP filter again in Wireshark to examine the termination of the TCP session. Four packets are transmitted for the termination of the TCP session. Because TCP connection is full-duplex, each direction must terminate independently. Examine the source and destination addresses.

In this example, the FTP server has no more data to send in the stream; it sends a segment with the FIN flag set in frame 63. The PC sends an ACK to acknowledge the receipt of the FIN to terminate the session from the server to the client in frame 64.

In frame 65, the PC sends a FIN to the FTP server to terminate the TCP session. The FTP server responds with an ACK to acknowledge the FIN from the PC in frame 67. Now the TCP session terminated between the FTP server and PC.

	61 15.514815000 192.168.1.17	198.246.112.54	FTP	60 Request: QUIT	
	62 15.601920000 198.246.112.54	192.168.1.17	FTP	61 Response: 221	
	63 15.602245000 198.246.112.54	192.168.1.17	ТСР	54 ftp > 49243 [FIN	, АСК] Seq=365 Ack=
	64 15.602314000 192.168.1.17	198.246.112.54	ТСР	54 49243 > ftp [ACK]	Seq=101 Ack=366 V
	65 15.605832000 192.168.1.17	198.246.112.54	ТСР	54 49243 > ftp [FIN	, АСК] Seq=101 Ack=
	67 15.696497000 198.246.112.54	192.168.1.17	TCP	54 ftp > 49243 [ACK]	Seq=366 Ack=102 ₩
		III			F.
÷	Frame 63: 54 bytes on wire (432	2 bits), 54 bytes	captured (432	bits) on interface	0
Đ	Ethernet II, Src: Netgear_99:c!	5:72 (30:46:9a:99:	c5:72), Dst:	HonHaiPr_be:15:63 (9	0:4c:e5:be:15:63)
Đ	Internet Protocol Version 4, SH	rc: 198.246.112.54	(198.246.112	.54), Dst: 192.168.1	.17 (192.168.1.17)
÷	Transmission Control Protocol,	Src Port: ftp (21	.), Dst Port:	49243 (49243), seq:	365, Ack: 101, Len

# Part 2: Identify UDP Header Fields and Operation Using a Wireshark TFTP Session Capture

In Part 2, you use Wireshark to capture a TFTP session and inspect UDP header fields.

### Step 1: Set up this physical topology and prepare for TFTP capture.



- a. Establish a console and Ethernet connection between PC-A and Switch S1.
- b. If not already done, manually configure the IP address on the PC to 192.168.1.3. It is not required to set the default gateway.

Internet Protocol Version 4 (TCP/IPv4)	Properties							
General								
You can get IP settings assigned auton this capability. Otherwise, you need to for the appropriate IP settings.	natically if your network supports ask your network administrator							
Obtain an IP address automatically								
• Use the following IP address:								
IP address:	192.168.1.3							
Subnet mask:	255.255.255.0							
Default gateway:	· · ·							
Obtain DNS server address autom	natically							
• Use the following DNS server add	resses:							
Preferred DNS server:								
Alternate DNS server:	• • •							
🔲 Validate settings upon exit	Ad <u>v</u> anced							
	OK Cancel							

c. Configure the switch. Assign an IP address of 192.168.1.1 to VLAN 1. Verify connectivity with the PC by pinging 192.168.1.3. Troubleshoot as necessary.

```
Switch> enable
Switch# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) # host S1
S1(config)# interface vlan 1
S1(config-if)# ip address 192.168.1.1 255.255.255.0
S1(config-if) # no shut
*Mar 1 00:37:50.166: %LINK-3-UPDOWN: Interface Vlan1, changed state to up
*Mar 1 00:37:50.175: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1,
changed state to up
S1(config-if) # end
S1# ping 192.168.1.3
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.1.3, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/203/1007 ms
```

d. Save the running configuration to NVRAM:
 S1# copy run start

#### Step 2: Prepare the TFTP server on the PC.

- a. If it does not already exist, create a folder on the PC desktop called **TFTP**. The files from the switch will be copied to this location.
- b. Start **tftpd32** on the PC.
- c. Click **Browse** and change the current directory to **C:\Users\user1\Desktop\TFTP** by replacing user1 with your username.

The TFTP server should look like this:

🏘 Tftpd32 by Ph. Joun	in		- • •
Current Directory C:\Us	ers\user1\Desktop\	IFTP •	Browse
Server interrace [192.1	68.1.3		Show <u>D</u> ir
Tftp Server Tftp Client	DHCP server Sy	slog server 🛛 L	.og viewer
peer	file	start time	progress
•			4
<u>A</u> bout	<u>S</u> ettings		<u>H</u> elp

Notice that in Current Directory, it lists the user and the Server (PC-A) interface as the IP address of **192.168.1.3**.

d. Test the ability to copy a file using TFTP from the switch to the PC. Troubleshoot as necessary.

```
S1# copy start tftp
Address or name of remote host []? 192.168.1.3
Destination filename [s1-confg]?
!!
1638 bytes copied in 0.026 secs (63000 bytes/sec)
```

If you see that the file has copied (as in the above output), then you are ready to go on to the next step. If not, then troubleshoot. If you get the <code>%Error opening tftp (Permission denied)</code> error, first check to make sure your firewall is not blocking TFTP, and that you are copying to a location where your username has adequate permission, such as the desktop.

#### Step 3: Capture a TFTP session in Wireshark

a. Open Wireshark. From the Edit menu, choose Preferences and click the (+) sign to expand Protocols. Scroll down and select UDP. Click the Validate the UDP checksum if possible check box and click Apply. Then click OK.

Wireshark:	Preferences - Profile: De	fault	
UAUDP		User Datagram Protocol	
UCP		Show UDP summary in protocol tree:	
UDP			
UDPlite		Try heuristic sub-dissectors first:	
ULP		Validate the UDP checksum if possible:	<b>V</b>
UMA		Collectore and for information	
UNISTI	N	Collect process flow information:	

- b. Start a Wireshark capture.
- c. Run the copy start tftp command on the switch.
- d. Stop the Wireshark capture.

Ele E	dit Yiew Go	Capture Analyze St	atistics Telephony Iools	Internals Help
	8 9 8	••**	3   4 + 4 7 3	🛓 🇐 🗊 Q Q Q 🖾 👹 🕅 🥵 💥 📓
Filter	tftp			Expression Clear Apply Save
No.	Time	Source	Destination	Protocol Length Info
1	2 9.7556470	0 192.168.1.1	192.168.1.3	TFTP 60 write Request, File: s1-confg, Transfer type: octet
1	3 9:7566870	0192.168.1.3	192.168.1.1	TETP 46 Acknowledgement, Block: 0
1	4 9.7579480	0 192.168.1.1	192.168.1.3	TETP 558 Data Packet, Block: 1
1	5 9.7580440	0192.168.1.3	192.168.1.1	TETP 46 Acknowledgement, Block: 1
1	6 9.7590510	0 192.168.1.1	192.168.1.3	TETP 558 Data Packet, Block: 2
1	7 9,7591170	0 192 168 1 3	192.168.1.1	TETP 46 Acknowledgement, Block: 2
1	8 9.7601320	0192.168.1.1	192.168.1.3	TFTP 558 Data Packet, Block: 3
1	9 9.7601870	0 192.168.1.3	192.168.1.1	TETP 46 Acknowledgement, Block: 3
2	0 9.7622730	0 192.168.1.1	192.168.1.3	TFTP 148 Data Packet, Block: 4 (last)
2	1 9.7624000	0 192.168.1.3	192.168.1.1	TETP 46 Acknowledgement, Block: 4

e. Set the filter to **tftp**. Your output should look similar to the output shown above. This TFTP transfer is used to analyze transport layer UDP operations.

In Wireshark, detailed UDP information is available in the Wireshark packet details pane. Highlight the first UDP datagram from the host computer, and move the mouse pointer to the packet details pane. It may be necessary to adjust the packet details pane and expand the UDP record by clicking the protocol expand box. The expanded UDP datagram should look similar to the diagram below.

	■ User Datagram Protocol, Src Port: 62513 (62513), Dst Port: tftp (69)
UDP Header	Source port: 62513 (62513) Destination port: tftp (69) Length: 25 P Checksum: 0x482c [correct]
UDP Data	<pre>∃ Trivial File Transfer Protocol [DESTINATION File: s1-confg] Opcode: Write Request (2) DESTINATION File: s1-confg Type: octet</pre>

The figure below is a UDP datagram diagram. Header information is sparse, compared to the TCP datagram. Similar to TCP, each UDP datagram is identified by the UDP source port and UDP destination port.

UDP SEGMENT

0	16	31
UDP SOURCE PORT	UDP DESTINATION PORT	
UDP MESSAGE LENGTH	UDP CHECKSUM	
DA	TA	
DAT	Ά	

Using the Wireshark capture of the first UDP datagram, fill in information about the UDP header. The checksum value is a hexadecimal (base 16) value, denoted by the preceding 0x code:

Source IP Address:	
Destination IP Address:	
Source Port Number:	
Destination Port Number:	
UDP Message Length:	
UDP Checksum:	

How does UDP verify datagram integrity?

Examine the first frame returned from tftpd server. Fill in the information about the UDP header:

Source IP Address:	
Destination IP Address:	
Source Port Number:	
Destination Port Number:	
UDP Message Length:	
UDP Checksum:	

-	User	Datagra	um Prot	ocol,	Src Po	rt: 585	65	(58565)	, Dst I	Port:	6251	625 (625	13)	
	Sou	rce por	t: 5856	55 (58	565)									
	Des	tinatio	n port:	6251	3 (625)	13)								
	Len	gth: 12												
	🗉 Che	cksum: (	0x8372	[inco	rrect,	shou1d	be	0xa385	(maybe	e caus	ed by	UDP	checksum	offloa
	Trivi	ial Eilo	Trans	for Dr	otocol									

[DESTINATION File: s1-confg] Opcode: Acknowledgement (4) Block: 0

Notice that the return UDP datagram has a different UDP source port, but this source port is used for the remainder of the TFTP transfer. Because there is no reliable connection, only the original source port used to begin the TFTP session is used to maintain the TFTP transfer.

Also notice that the UDP Checksum is incorrect. This is most likely caused by UDP checksum offload. You can learn more about why this happens by searching for "UDP checksum offload".

## Reflection

This lab provided the opportunity to analyze TCP and UDP protocol operations from captured FTP and TFTP sessions. How does TCP manage communication differently than UDP?



## Challenge

Because neither FTP nor TFTP are secure protocols, all transferred data is sent in clear text. This includes any user IDs, passwords, or clear-text file contents. Analyzing the upper-layer FTP session will quickly identify the user ID, password, and configuration file passwords. Upper-layer TFTP data examination is a bit more complicated, but the data field can be examined and the configuration user ID and password information extracted.

## Cleanup

Unless directed otherwise by your instructor:

- 1) Remove the files that were copied to your PC.
- 2) Erase the configurations on switch **S1**.
- 3) Remove the manual IP address from the PC and restore Internet connectivity.

## 7.3.1.1 We Need to Talk, Again

## **Objectives**

#### Explain how transport layer protocols and services support communications across data networks.

In this activity, given a scenario, you will determine whether high-reliability messaging should be used. You will focus on whether the final message is complete, correct, and delivered in a timely manner

## Background/Scenario

**Note:** It is important that the students have completed the Introductory MA for this chapter. This activity works best in medium-sized groups of 6 to 8 students.

Your instructor will whisper a complex message to the first student in a group. An example of the message might be "We are expecting a blizzard tomorrow. It should be arriving in the morning and school will be delayed 2 two hours so bring your homework."

That student whispers the message to the next student in the group. Each group follows this process until all members of each group have heard the whispered message.

Here are the rules to follow:

- You can whisper the message in short parts to your neighbor AND you can repeat the message parts after verifying your neighbor heard the correct message.
- Small parts of the message may be checked and repeated again (clockwise OR counterclockwise to ensure accuracy of the message parts) by whispering. A student will be assigned to time the entire activity.
- When the message has reached the end of the group, the last student will say aloud what was heard. Small parts of the message may be repeated (i.e., re-sent), and the process can be restarted to ensure that ALL parts of the message are fully delivered and correct.
- Your instructor will repeat the original message to check for quality delivery.

## Reflection

- 1. Would the contents of this message need to be clear and correct when you received them, if you were depending on this message to drive your personal/business calendar, studying schedule, etc.?
- 2. Would the length of time taken to deliver the message be an important factor to the sender and recipient?
- 3. Compare the Introductory Modeling Activity of this chapter to this activity. What differences do you notice about the delivery of the message?

## 8.0.1.2 The Internet of Everything (IoE)

## Objectives

#### Explain how network devices use routing tables to direct packets to a destination network.

IPv6 is important to help manage the data traffic identification, which will be needed in the future. Many addresses will assist in this endeavor, and IPv6 helps to alleviate this need.

## **Background /Scenario**

Today, more than 99% of our world remains unconnected. Tomorrow, we will be connected to almost everything. 37 billion devices will be connected to the Internet by 2020. From trees to water to cars, the organic and the digital will work together for a more intelligent and connected world. This tomorrow of networking is known as "The Internet of Everything" or "IoE."

If traffic, transportation, networking and space exploration depend on digital information sharing, how will that information be identified from its source to its destination?

In this activity, you will begin to think about not only what will be identified in the IoE world, but how everything will be addressed in the same world!

Activity directions for class or individual students:

- Read the blog/news source, "Internet of Everything: Fueling an Amazing Future #TomorrowStartsHere" authored by John Chambers regarding the Internet of Everything (IoE). This blog is located at <u>http://blogs.cisco.com/news/internet-of-everything-2.</u>
- 2. Then view the video, "Cisco Commercial: Tomorrow Starts Here" located halfway down the page.
- 3. Next, navigate to the IoE main page located at <a href="http://www.cisco.com/web/tomorrow-starts-here/index.html">http://www.cisco.com/web/tomorrow-starts-here/index.html</a>. Then click on a category that interests you from within the graphic collage.
- Next, watch the video or read through the blog or .pdf that belongs to your IoE category of interest.
- 5. Write 5 comments or questions about what you saw or read. Be prepared to share with the class.

## **Required Resources**

- Internet connectivity for research on the cisco.com site. Headphones may also be useful if students are individually completing this activity within a group setting.
- Recording capabilities (paper, tablet, etc.) for comments or questions regarding the videos, blogs and/or .pdfs read or viewed for Step 3.

## Reflection

1. Why do you think there is a need to address trees? Windmills? Cars? Refrigerators? Why will just about anything be able to use an IP address?

# 8.1.2.7 Lab – Using the Windows Calculator with Network Addresses

Calculator								
<u>V</u> iew <u>E</u> dit <u>F</u>	<u>l</u> elp							
								0
0000 000 63 0000 000 31	00 00 00 00	300 300	0000 0000	0000 47 0000 15	000 000	0 0000 0 0000		0000 32 0000 0
) Hex		Mod	Α	MC	MR	MS	M+	M-
Dec     Oct	(	)	В	-	CE	с	±	√
© Bin	RoL	RoR	С	7	8	9	/	%
Qword	Or	Xor	D	4	5	6	*	1/x
Oword	Lsh	Rsh	Ε	1	2	3	-	
🔘 Byte	Not	And	F	(	)	•	+	

## **Objectives**

Part 1: Access the Windows Calculator

- Part 2: Convert between Numbering Systems
- Part 3: Convert Host IPv4 Addresses and Subnet Masks into Binary
- Part 4: Determine the Number of Hosts in a Network Using Powers of 2
- Part 5: Convert MAC Addresses and IPv6 Addresses to Binary

## **Background / Scenario**

Network technicians use binary, decimal, and hexadecimal numbers when working with computers and networking devices. Microsoft provides a built-in Calculator application as part of the operating system. The Windows 7 version of Calculator includes a Standard view that can be used to perform basic arithmetic tasks such as addition, subtract, multiplication, and division. The Calculator application also has advanced programming, scientific, and statistical capabilities.

In this lab, you will use the Windows 7 Calculator application Programmer view to convert between the binary, decimal, and hexadecimal number systems. You will also use the Scientific view powers function to determine the number of hosts that can be addressed based on the number of host bits available.

## **Required Resources**

• 1 PC (Windows 7, Vista, or XP)

**Note**: If using an operating system other than Windows 7, the Calculator application views and functions available may vary from those shown in this lab. However, you should be able to perform the calculations.

## Part 1: Access the Windows Calculator

In Part 1, you will become familiar with the Microsoft Windows built-in calculator application and view the available modes.

### Step 1: Click the Windows Start button and select All Programs.

Step 2: Click the Accessories folder and select Calculator.

### Step 3: After Calculator opens, click the View menu.

What are the four available modes?

Note: The Programmer and Scientific modes are used in this lab.

## Part 2: Convert between Numbering Systems

In the Windows Calculator Programmer view, several number system modes are available: Hex (Hexadecimal or base 16), Dec (Decimal or base 10), Oct (Octal or base 8), and Bin (Binary or base 2).

We are accustomed to using the decimal number system that uses the digits 0 to 9. The decimal numbering system is used in everyday life for all counting, money, and financial transactions. Computers and other electronic devices use the binary numbering system with only the digits 0 and 1 for data storage, data transmission and numerical calculations. All computer calculations are ultimately performed internally in binary (digital) form, regardless of how they are displayed.

One disadvantage of binary numbers is that the binary number equivalent of a large decimal number can be quite long. This makes them difficult to read and write. One way to overcome this problem is to arrange binary numbers into groups of four as hexadecimal numbers. Hexadecimal numbers are base 16, and a combination of numbers from 0 to 9 and the letters A to F are used to represent the binary or decimal equivalent. Hexadecimal characters are used when writing or displaying IPv6 and MAC addresses.

The octal numbering system is very similar in principle to hexadecimal. Octal numbers represent binary numbers in groups of three. This numbering system uses digits 0 to 7. Octal numbers are also a convenient way to represent a large binary number in smaller groups, but this numbering system is not commonly used.

In this lab, the Windows 7 Calculator is used to convert between different numbering systems in the Programmer mode.

a. Click the View menu and select Programmer to switch to Programmer mode.

**Note**: For Windows XP and Vista, only two modes, Standard and Scientific, are available. If you are using one of these operating systems, you can use the Scientific mode to perform this lab.

Which number system is currently active? \_\_\_\_

Which numbers on the number pad are active in decimal mode? \_\_\_\_

b. Click the Bin (Binary) radio button. Which numbers are active on the number pad now?

Why do you think the other numbers are grayed out?

c. Click the Hex (Hexadecimal) radio button. Which characters are activated on the number pad now?

d. Click the **Dec** radio button. Using your mouse, click the number **1** followed by the number **5** on the number pad. The decimal number 15 is now entered.

**Note**: The numbers and letters on the keyboard can also be used to enter the values. If using the numerical keypad, type the number **15**. If the number does not enter into the calculator, press the **Num Lock** key to enable the numeric keypad.

Click the Bin radio button. What happened to the number 15?

- e. Numbers are converted from one numbering system to another by selecting the desired number mode. Click the **Dec** radio button again. The number converts back to decimal.
- f. Click the **Hex** radio button to change to Hexadecimal mode. Which hexadecimal character (0 through 9 or A to F) represents decimal 15? \_\_\_\_\_\_
- g. As you were switching between the numbering systems, you may have noticed the binary number 1111 is displayed during the conversion. This assists you in relating the binary digits to other numbering system values. Each set of 4 bits represents a hexadecimal character or potentially multiple decimal characters.

							15
0000 63	0000	0000	0000	0000 47	0000	0000	0000 32
0000 31	0000	0000	0000	<b>0000</b> 15	0000	0000	1111 0

h. Clear the values in the window by clicking **C** above the 9 on the calculator keypad. Convert the following numbers between the binary, decimal, and hexadecimal numbering systems.

Decimal	Binary	Hexadecimal
86		
175		
204		
	0001 0011	
	0100 1101	
	0010 1010	
		38
		93
		E4

i. As you record the values in the table above, do you see a pattern between the binary and hexadecimal numbers?

## Part 3: Convert Host IPv4 Addresses and Subnet Masks into Binary

Internet Protocol version 4 (IPv4) addresses and subnet masks are represented in a dotted decimal format (four octets), such as 192.168.1.10 and 255.255.255.0, respectively. This makes these addresses more readable to humans. Each of the decimal octets in the address or a mask can be converted to 8 binary bits. An octet is always 8 binary bits. If all 4 octets were converted to binary, how many bits would there be?

a. Use the Windows Calculator application to convert the IP address 192.168.1.10 into binary and record the binary numbers in the following table:

Decimal	Binary
192	
168	
1	
10	

b. Subnet masks, such as 255.255.255.0, are also represented in a dotted decimal format. A subnet mask will always consist of four 8-bit octets, each represented as a decimal number. Using the Windows Calculator, convert the 8 possible decimal subnet mask octet values to binary numbers and record the binary numbers in the following table:

Decimal	Binary
0	
128	
192	
224	
240	
248	
252	
254	
255	

c. With the combination of IPv4 address and the subnet mask, the network portion can be determined and the number of hosts available in a given IPv4 subnet can also be calculated. The process is examined in Part 4.

## Part 4: Determine the Number of Hosts in a Network Using Powers of 2

Given an IPv4 network address and a subnet mask, the network portion can be determined along with the number of hosts available in the network.

a. To calculate the number of hosts on a network, you must determine the network and host portion of the address.

Using the example of 192.168.1.10 with a subnet of 255.255.248.0, the address and subnet mask are converted to binary numbers. Align the bits as you record your conversions to binary numbers.

Decimal IP Address and Subnet Mask	Binary IP Address and Subnet Mask
192.168.1.10	
255.255.248.0	

Because the first 21 bits in the subnet mask are consecutive numeral ones, the corresponding first 21 bits in the IP address in binary is 110000001010100000000; these represent the network portion of the address. The remaining 11 bits are 00100001010 and represent the host portion of the address.

What is the decimal and binary network number for this address?

What is the decimal and binary host portion for this address?

Because the network number and the broadcast address use two addresses out of the subnet, the formula to determine the number of hosts available in an IPv4 subnet is the number 2 to the power of the number of host bits available, minus 2:

Number of available hosts =  $2^{(number of host bits)} - 2$ 

- b. Using the Windows Calculator application, switch to the Scientific mode by clicking the **View** menu, then select **Scientific**.
- c. Input **2**. Click the  $\mathbf{x}^{\mathbf{y}}$  key. This key raises a number to a power.
- d. Input **11**. Click =, or press Enter on the keyboard for the answer.
- e. Subtract **2** from the answer by using the calculator if desired.
- f. In this example, there are 2046 hosts are available on this network  $(2^{11}-2)$ .
- g. If given the number of host bits, determine the number of hosts available and record the number in the following table.

Number of Available Host Bits	Number of Available Hosts
5	
14	
24	
10	

h. For a given subnet mask, determine the number of hosts available and record the answer in the following table.

Subnet Mask	Binary Subnet Mask	Number of Available Host Bits	Number of Available Hosts
255.255.255.0	11111111.11111111.11111111.00000000		
255.255.240.0	11111111.11111111.11110000.00000000		
255.255.255.128	11111111.11111111.11111111.10000000		
255.255.255.252	11111111.11111111.11111111.11111100		
255.255.0.0	11111111.1111111.0000000.0000000		

## Part 5: Convert MAC Addresses and IPv6 Addresses to Binary

Both Media Access Control (MAC) and Internet Protocol version 6 (IPv6) addresses are represented as hexadecimal digits for readability. However, computers only understand binary digits and use these binary digits for computations. In this part, you will convert these hexadecimal addresses to binary addresses.

### Step 1: Convert MAC addresses to binary digits.

- a. The MAC or physical address is normally represented as 12 hexadecimal characters, grouped in pairs and separated by hyphens (-). Physical addresses on a Windows-based computer are displayed in a format of xx-xx-xx-xx-xx, where each x is a number from 0 to 9 or a letter from A to F. Each of the hex characters in the address can be converted to 4 binary bits, which is what the computer understands. If all 12 hex characters were converted to binary, how many bits would there be?
- b. Record the MAC address for your PC.
- c. Convert the MAC address into binary digits using the Windows Calculator application.

### Step 2: Convert an IPv6 address into binary digits.

IPv6 addresses are also written in hexadecimal characters for human convenience. These IPv6 addresses can be converted to binary numbers for computer use.

- a. IPv6 addresses are binary numbers represented in human-readable notations: 2001:0DB8:ACAD:0001:0000:0000:00001 or in a shorter format: 2001:DB8:ACAD:1::1.
- b. An IPv6 address is 128 bits long. Using the Windows Calculator application, convert the sample IPv6 address into binary numbers and record it in the table below.

Hexadecimal	Binary
2001	
0DB8	
ACAD	
0001	
0000	
0000	
0000	
0001	

## Reflection

- 1. Can you perform all the conversions without the assistance of the calculator? What can you do to make it happen?
- 2. For most IPv6 addresses, the network portion of the address is usually 64 bits. How many hosts are available on a subnet where the first 64 bits represent the network? Hint: All host addresses are available in the subnet for hosts.

## 8.1.2.8 Lab – Converting IPv4 Addresses to Binary

## **Objectives**

Part 1: Convert IPv4 Addresses from Dotted Decimal to Binary

Part 2: Use Bitwise ANDing Operation to Determine Network Addresses

Part 3: Apply Network Address Calculations

## **Background / Scenario**

Every IPv4 address is comprised of two parts: a network portion and a host portion. The network portion of an address is the same for all devices that reside in the same network. The host portion identifies a specific host within a given network. The subnet mask is used to determine the network portion of an IP address. Devices on the same network can communicate directly; devices on different networks require an intermediary Layer 3 device, such as a router, to communicate.

To understand the operation of devices on a network, we need to look at addresses the way devices do—in binary notation. To do this, we must convert the dotted decimal form of an IP address and its subnet mask to binary notation. After this has been done, we can use the bitwise ANDing operation to determine the network address.

This lab provides instructions on how to determine the network and host portion of IP addresses by converting addresses and subnet masks from dotted decimal to binary, and then using the bitwise ANDing operation. You will then apply this information to identify addresses in the network.

## Part 1: Convert IPv4 Addresses from Dotted Decimal to Binary

In Part 1, you will convert decimal numbers to their binary equivalent. After you have mastered this activity, you will convert IPv4 addresses and subnet masks from dotted decimal to their binary form.

### Step 1: Convert decimal numbers to their binary equivalent.

Fill in the following table by converting the decimal number to an 8-bit binary number. The first number has been completed for your reference. Recall that the eight binary bit values in an octet are based on the powers of 2, and from left to right are 128, 64, 32, 16, 8, 4, 2, and 1.

Decimal	Binary
192	11000000
168	
10	
255	
2	

#### Step 2: Convert the IPv4 addresses to their binary equivalent.

An IPv4 address can be converted using the same technique you used above. Fill in the table below with the binary equivalent of the addresses provided. To make your answers easier to read, separate the binary octets with a period.

Decimal	Binary
192.168.10.10	11000000.10101000.00001010.00001010
209.165.200.229	
172.16.18.183	
10.86.252.17	
255.255.255.128	
255.255.192.0	

## Part 2: Use Bitwise ANDing Operation to Determine Network Addresses

In Part 2, you will use the bitwise ANDing operation to calculate the network address for the provided host addresses. You will first need to convert an IPv4 decimal address and subnet mask to their binary equivalent. Once you have the binary form of the network address, convert it to its decimal form.

**Note**: The ANDing process compares the binary value in each bit position of the 32-bit host IP with the corresponding position in the 32-bit subnet mask. If there two 0s or a 0 and a 1, the ANDing result is 0. If there are two 1s, the result is a 1, as shown in the example here.

|--|

Description	Decimal	Binary
IP Address	192.168.10.131	11000000.10101000.00001010.10000011
Subnet Mask	255.255.255.192	11111111.11111111.11111111.11000000
Network Address	192.168.10.128	11000000.10101000.00001010.10000000

How do you determine what bits to use to calculate the network address?

In the example above, how many bits are used to calculate the network address?

## Step 2: Use the ANDing operation to determine the network address.

a. Enter the missing information into the table below:

Description	Decimal	Binary
IP Address	172.16.145.29	
Subnet Mask	255.255.0.0	
Network Address		

b. Enter the missing information into the table below:

Description	Decimal	Binary
IP Address	192.168.10.10	
Subnet Mask	255.255.255.0	
Network Address		

c. Enter the missing information into the table below:

Description	Decimal	Binary
IP Address	192.168.68.210	
Subnet Mask	255.255.255.128	
Network Address		

d. Enter the missing information into the table below:

Description	Decimal	Binary
IP Address	172.16.188.15	
Subnet Mask	255.255.240.0	
Network Address		

e. Enter the missing information into the table below:

Description	Decimal	Binary
IP Address	10.172.2.8	
Subnet Mask	255.224.0.0	
Network Address		

## Part 3: Apply Network Address Calculations

In Part 3, you must calculate the network address for the given IP addresses and subnet masks. After you have the network address, you should be able to determine the responses needed to complete the lab.

#### Step 1: Determine whether IP addresses are on same network.

a. You are configuring two PCs for your network. PC-A is given an IP address of 192.168.1.18, and PC-B is given an IP address of 192.168.1.33. Both PCs receive a subnet mask of 255.255.255.240.

What is the network address for PC-A?

What is the network address for PC-B?

Will these PCs be able to communicate directly with each other?

What is the highest address that can be given to PC-B that allows it to be on the same network as PC-A?

b. You are configuring two PCs for your network. PC-A is given an IP address of 10.0.0.16, and PC-B is given an IP address of 10.1.14.68. Both PCs receive a subnet mask of 255.254.0.0.

What is the network address for PC-A?

What is the network address for PC-B?

Will these PCs be able to communicate directly with each other? \_\_\_\_\_

What is the lowest address that can be given to PC-B that allows it to be on the same network as PC-A?

#### Step 2: Identify the default gateway address.

a. Your company has a policy to use the first IP address in a network as the default gateway address. A host on the local-area network (LAN) has an IP address of 172.16.140.24 and a subnet mask of 255.255.192.0.

What is the network address for this network?

What is the default gateway address for this host?

b. Your company has a policy to use the first IP address in a network as the default gateway address. You have been instructed to configure a new server with an IP address of 192.168.184.227 and a subnet mask of 255.255.255.248.

What is the network address for this network?

What is the default gateway for this server?

## Reflection

Why is the subnet mask important in determining the network address?

## 8.1.4.8 Lab- Identifying IPv4 Addresses

## Objectives

## Part 1: Identify IPv4 Addresses

- Identify the network and host portion of an IP address.
- Identify the range of host addresses given a network/prefix mask pair.

## Part 2: Classify IPv4 Addresses

- Identify the type of address (network, host, multicast, or broadcast).
- Identify whether an address is public or private.
- Determine if an address assignment is a valid host address.

## **Background / Scenario**

Addressing is an important function of network layer protocols because it enables data communication between hosts on the same network, or on different networks. In this lab, you will examine the structure of Internet Protocol version 4 (IPv4) addresses. You will identify the various types of IPv4 addresses and the components that help comprise the address, such as network portion, host portion, and subnet mask. Types of addresses covered include public, private, unicast, and multicast.

## **Required Resources**

- Device with Internet access
- Optional: IPv4 address calculator

## Part 1: Identify IPv4 Addresses

In Part 1, you will be given several examples of IPv4 addresses and will complete tables with appropriate information.

## Step 1: Analyze the table shown below and identify the network portion and host portion of the given IPv4 addresses.

The first two rows show examples of how the table should be completed.

### Key for table:

N = all 8 bits for an octet are in the network portion of the address

n = a bit in the network portion of the address

- H = all 8 bits for an octet are in the host portion of the address
- h = a bit in the host portion of the address

IP Address/Prefix	Network/Host N,n = Network H,h = Host	Subnet Mask	Network Address
192.168.10.10/24	N.N.N.H	255.255.255.0	192.168.10.0
10.101.99.17/23	N.N.nnnnnnh.H	255.255.254.0	10.101.98.0
209.165.200.227/27			
172.31.45.252/24			
10.1.8.200/26			
172.16.117.77/20			
10.1.1.101/25			
209.165.202.140/27			
192.168.28.45/28			

## Step 2: Analyze the table below and list the range of host and broadcast addresses given a network/prefix mask pair.

The first row shows an example of how the table should be completed.

IP Address/Prefix	First Host Address	Last Host Address	Broadcast Address
192.168.10.10/24	192.168.10.1	192.168.10.254	192.168.10.255
10.101.99.17/23			
209.165.200.227/27			
172.31.45.252/24			
10.1.8.200/26			
172.16.117.77/20			
10.1.1.101/25			
209.165.202.140/27			
192.168.28.45/28			

## Part 2: Classify IPv4 Addresses

In Part 2, you will identify and classify several examples of IPv4 addresses.

## Step 1: Analyze the table shown below and identify the type of address (network, host, multicast, or broadcast address).

The first row shows an example of how the table should be completed.

IP Address	Subnet Mask	Address Type
10.1.1.1	255.255.255.252	host
192.168.33.63	255.255.255.192	
239.192.1.100	255.252.0.0	
172.25.12.52	255.255.255.0	
10.255.0.0	255.0.0.0	
172.16.128.48	255.255.255.240	
209.165.202.159	255.255.255.224	
172.16.0.255	255.255.0.0	
224.10.1.11	255.255.255.0	

## Step 2: Analyze the table shown below and identify the address as public or private.

IP Address/Prefix	Public or Private
209.165.201.30/27	
192.168.255.253/24	
10.100.11.103/16	
172.30.1.100/28	
192.31.7.11/24	
172.20.18.150/22	
128.107.10.1/16	
192.135.250.10/24	
64.104.0.11/16	

Step 3: Analyze the table shown below and identify whether the address/prefix pair is a valid host address.

IP Address/Prefix	Valid Host Address?	Reason
127.1.0.10/24		
172.16.255.0/16		
241.19.10.100/24		
192.168.0.254/24		
192.31.7.255/24		
64.102.255.255/14		
224.0.0.5/16		
10.0.255.255/8		
198.133.219.8/24		

## Reflection

Why should we continue to study and learn about IPv4 addressing if the available IPv4 address space is depleted?

## 8.2.5.4 Lab – Identifying IPv6 Addresses

Topology



## **Objectives**

## Part 1: Identify the Different Types of IPv6 Addresses

- Review the different types of IPv6 addresses.
- Match the IPv6 address with the correct type.

## Part 2: Examine a Host IPv6 Network Interface and Address

• Check PC IPv6 network address settings.

### Part 3: Practice IPv6 Address Abbreviation

- Study and review the rules for IPv6 address abbreviation.
- Practice compressing and decompressing IPv6 addresses.

## **Background / Scenario**

With the depletion of the Internet Protocol version 4 (IPv4) network address space and the adoption and transition to IPv6, networking professionals must understand how both IPv4 and IPv6 networks function. Many devices and applications already support IPv6. This includes extensive Cisco device Internetwork Operating System (IOS) support and workstation/server operating system support, such as that found in Windows and Linux.

This lab focuses on IPv6 addresses and the components of the address. In Part 1, you will identify the IPv6 address types, and in Part 2, you will view the IPv6 settings on a PC. In Part 3, you will practice IPv6 address abbreviation.

## **Required Resources**

• 1 PC (Windows 7 or Vista with Internet access)

**Note:** The IPv6 protocol is enabled in Windows 7 and Vista by default. The Windows XP operating system does not enable IPv6 by default and is not recommended for use with this lab. This lab uses Windows 7 PC hosts.

## Part 1: Identify the Different Types of IPv6 Addresses

In Part 1, you will review the characteristics of IPv6 addresses to identify the different types of IPv6 addresses.
#### Step 1: Review the different types of IPv6 addresses.

An IPv6 address is 128 bits long. It is most often presented as 32 hexadecimal characters. Each hexadecimal character is the equivalent of 4 bits ( $4 \times 32 = 128$ ). A non-abbreviated IPv6 host address is shown here:

#### 2001:0DB8:0001:0000:0000:0000:0000:0001

A hextet is the hexadecimal, IPv6 version of an IPv4 octet. An IPv4 address is 4 octets long, separated by dots. An IPv6 address is 8 hextets long, separated by colons.

An IPv4 address is 4 octets and is commonly written or displayed in decimal notation.

#### 255.255.255.255

An IPv6 address is 8 hextets and is commonly written or displayed in hexadecimal notation.

#### FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

In an IPv4 address, each individual octet is 8 binary digits (bits). Four octets equals one 32-bit IPv4 address.

#### 11111111 = 255

#### 

In an IPv6 address, each individual hextet is 16 bits long. Eight hextets equals one 128-bit IPv6 address.

#### 1111111111111111 = FFFF

#### 

If we read an IPv6 address starting from the left, the first (or far left) hextet identifies the IPv6 address type. For example, if the IPv6 address has all zeros in the far left hextet, then the address is possibly a loopback address.

**0000**:0000:0000:0000:0000:0000:0001 = loopback address

::1 = loopback address abbreviated

As another example, if the IPv6 address has FE80 in the first hextet, then the address is a link-local address.

**FE80**:0000:0000:C5B7:CB51:3C00:D6CE = link-local address

FE80::C5B7:CB51:3C00:D6CE = link-local address abbreviated

Study the chart below to help you identify the different types of IPv6 address based on the numbers in the first hextet.

First Hextet (Far Left)	Type of IPv6 Address
0000 to 00FF	Loopback address, any address, unspecified address, or IPv4- compatible
2000 to 3FFF	Global unicast address (a routable address in a range of addresses that is currently being handed out by the Internet Assigned Numbers Authority [IANA])
FE80 to FEBF	Link-local (a unicast address which identifies the host computer on the local network)
FC00 to FCFF	Unique-local (a unicast address which can be assigned to a host to identify it as being part of a specific subnet on the local network)
FF00 to FFFF	Multicast address

There are other IPv6 address types that are either not yet widely implemented, or have already become deprecated, and are no longer supported. For instance, an **anycast address** is new to IPv6 and can be used by routers to facilitate load sharing and provide alternate path flexibility if a router becomes unavailable. Only routers should respond to an anycast address. Alternatively, **site-local addresses** have been deprecated and replaced by unique-local addresses. Site-local addresses were identified by the numbers FEC0 in the initial hextet.

In IPv6 networks, there are no network (wire) addresses or broadcast addresses as there are in IPv4 networks.

#### Step 2: Match the IPv6 address to its type.

Match the IPv6 addresses to their corresponding address type. Notice that the addresses have been compressed to their abbreviated notation and that the slash network prefix number is not shown. Some answer choices must be used more than once.

IPv6 Address	Answer
2001:0DB8:1:ACAD::FE55:6789:B210	1
::1	2
FC00:22:A:2::CD4:23E4:76FA	3
2033:DB8:1:1:22:A33D:259A:21FE	4
FE80::3201:CC01:65B1	5
FF00::	6
FF00::DB7:4322:A231:67C	7
FF02::2	8

#### **Answer Choices**

- a. Loopback address
- b. Global unicast address
- c. Link-local address
- d. Unique-local address
- e. Multicast address

# Part 2: Examine a Host IPv6 Network Interface and Address

In Part 2, you will check the IPv6 network settings of your PC to identify your network interface IPv6 address.

#### Step 1: Check your PC IPv6 network address settings.

a. Verify that the IPv6 protocol is installed and active on your PC-A (check your Local Area Connection settings).

- b. Click the Windows Start button and then Control Panel and change View by: Category to View by: Small icons.
- c. Click the Network and Sharing Center icon.
- d. On the left side of the window, click Change adapter settings. You should now see icons representing your installed network adapters. Right-click your active network interface (it may be a Local Area Connection or a Wireless Network Connection), and then click Properties.
- e. You should now see your Network Connection Properties window. Scroll through the list of items to determine whether IPv6 is present, which indicates that it is installed, and if it is also check marked, which indicates that it is active.

onomig	2		
Connect using:			
Intel(R) Centrin	o(R) Advanced-N 6200	AGN	-
1 10 10	65858	Carl	
This second bins	the fallence areas	Configure	;
Inis connection uses	the following items:		
Deterministic	Network Enhancer		*
QoS Packet	Scheduler	22200 (120	
File and Print	ter Sharing for Microsoft	Networks	-
💶 🗹 🦾 Internet Prote	ocol Version 6 (TCP/IP)	(6)	
		101	
Internet Prot	ocol Version 4 (TCP/IP	(4)	=
<ul> <li>Internet Prote</li> <li>Internet Prote</li> <li>Internet Prote</li> <li>Internet Prote</li> </ul>	ocol Version 4 (TCP/IP opology Discovery Map	v4) per I/O Driver	=
<ul> <li>✓ Internet Prot</li> <li>✓ Link-Layer T</li> <li>✓ Link-Layer T</li> </ul>	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Res	/4) per I/O Driver ponder	= <u>↓</u>
Internet Prote     Internet Prote     Ink-Layer T     Ink-Layer T	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Res III	/4) per I/O Driver ponder	+
A Internet Prote     A Link-Layer T     A Link-Layer T     Install	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Resp III Uninstall	r4) per I/O Driver ponder Properties	
A Internet Prote     A Link-Layer T     A Link-Layer T     Install  Description	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Res III Uninstall	r4) per I/O Driver ponder Properties	
A Internet Prote     A Link-Layer T     A Link-Layer T     Install      Description     Allows your comput	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Res III Uninstall	on a Microsoft	
Internet Prote     Ink-Layer T     Ink-Layer T     Install      Description     Allows your compute     network.	ocol Version 4 (TCP/IP opology Discovery Map opology Discovery Res III Uninstall ter to access resources	on a Microsoft	
Internet Prote     Ink-Layer T     Ink-Layer T     Install      Description     Allows your compute     network.	ocol Version 4 (TCP/IP) iopology Discovery Map iopology Discovery Res III Uninstall ter to access resources	v4) per I/O Driver ponder Properties on a Microsoft	
Internet Prote     Ink-Layer T     Ink-Layer T     Install      Description     Allows your compute     network.	ocol Version 4 (TCP/IP iopology Discovery Map iopology Discovery Res III Uninstall ter to access resources	v4) per I/O Driver ponder Properties on a Microsoft	

f. Select the item Internet Protocol Version 6 (TCP/IPv6) and click Properties. You should see the IPv6 settings for your network interface. Your IPv6 properties window is likely set to Obtain an IPv6 address automatically. This does not mean that IPv6 relies on the Dynamic Host Configuration Protocol (DHCP). Instead of using DHCP, IPv6 looks to the local router for IPv6 network information and then auto-configures its own IPv6 addresses. To manually configure IPv6, you must provide the IPv6 address, the subnet prefix length, and the default gateway.

**Note**: The local router can refer host requests for IPv6 information, especially Domain Name System (DNS) information, to a DHCPv6 server on the network.

heral		
ou can get IPv6 settings assig therwise, you need to ask you	ned automatically if your n ur network administrator fo	network supports this capability. or the appropriate IPv6 settings.
Obtain an IPv6 address au	utomatically	
O Use the following IPv6 add	dre <mark>s</mark> s:	
IPv6 address:		
Subnet prefix length:		
Default gateway:		
Obtain DNS server addres	s automatically	
O Use the following DNS serv	ver addresses:	
Preferred DNS server:		
Alternate DNS server:		
Validate settings upon ex	it	Advanced

- g. After you have verified that IPv6 is installed and active on your PC, you should check your IPv6 address information. To do this, click the **Start** button, type **cmd** in the *Search programs and files* form box, and press Enter. This opens a Windows command prompt window.
- h. Type **ipconfig /all** and press Enter. Your output should look similar to this:

```
C:\Users\user> ipconfig /all
Windows IP Configuration
<output omitted>
Wireless LAN adapter Wireless Network Connection:
  Connection-specific DNS Suffix . :
  Description . . . . . . . . . . . . . Intel(R) Centrino(R) Advanced-N 6200 AGN
  DHCP Enabled. . . . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
  Link-local IPv6 Address . . . . : fe80::8d4f:4f4d:3237:95e2%14 (Preferred)
  Lease Obtained. . . . . . . . . . . . . . . . Sunday, January 06, 2013 9:47:36 AM
  Lease Expires . . . . . . . . . . . Monday, January 07, 2013 9:47:38 AM
  Default Gateway . . . . . . . . : 192.168.2.1
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-14-57-84-B1-1C-C1-DE-91-C3-5D
```

#### 8.8.4.4

<output omitted>

- i. You can see from the output that the client PC has an IPv6 link-local address with a randomly generated interface ID. What does it indicate about the network regarding IPv6 global unicast address, IPv6 unique-local address, or IPv6 gateway address?
- j. What kind of IPv6 addresses did you find when using ipconfig /all?

# Part 3: Practice IPv6 Address Abbreviation

In Part 3, you will study and review rules for IPv6 address abbreviation to correctly compress and decompress IPv6 addresses.

#### Step 1: Study and review the rules for IPv6 address abbreviation.

Rule 1: In an IPv6 address, a string of four zeros (0s) in a hextet can be abbreviated as a single zero.

2001:0404:0001:1000:0000:0000:0EF0:BC00

2001:0404:0001:1000:0:0:0EF0:BC00 (abbreviated with single zeros)

Rule 2: In an IPv6 address, the leading zeros in each hextet can be omitted, trailing zeros cannot be omitted.

2001:**0**404:**000**1:1000:0000:0000:**0**EF0:BC00

2001:404:1:1000:0:0:EF0:BC00 (abbreviated with leading zeros omitted)

**Rule 3**: In an IPv6 address, a single continuous string of four or more zeros can be abbreviated as a double colon (::). The double colon abbreviation can only be used one time in an IP address.

2001:0404:0001:1000:0000:0EF0:BC00

2001:404:1:1000::EF0:BC00 (abbreviated with leading zeroes omitted and continuous zeros replaced with a double colon)

The image below illustrates these rules of IPv6 address abbreviation:



#### Step 2: Practice compressing and decompressing IPv6 addresses.

Using the rules of IPv6 address abbreviation, either compress or decompress the following addresses:

- 1) 2002:0EC0:0200:0001:0000:04EB:44CE:08A2
- 2) FE80:0000:0000:0001:0000:60BB:008E:7402
- 3) FE80::7042:B3D7:3DEC:84B8
- 4) FF00::
- 5) 2001:0030:0001:ACAD:0000:330E:10C2:32BF

#### Reflection

- 1. How do you think you must support IPv6 in the future?
- 2. Do you think IPv4 networks continue on, or will everyone eventually switch over to IPv6? How long do you think it will take?

# 8.2.5.5 Lab - Configuring IPv6 Addresses on Network Devices





# Addressing Table

Device	Interface	IPv6 Address	Prefix Length	Default Gateway
R1	G0/0	2001:DB8:ACAD:A::1	64	N/A
	G0/1	2001:DB8:ACAD:1::1	64	N/A
S1	VLAN 1	2001:DB8:ACAD:1::B	64	N/A
PC-A	NIC	2001:DB8:ACAD:1::3	64	FE80::1
PC-B	NIC	2001:DB8:ACAD:A::3	64	FE80::1

#### **Objectives**

Part 1: Set Up Topology and Configure Basic Router and Switch Settings

Part 2: Configure IPv6 Addresses Manually

Part 3: Verify End-to-End Connectivity

#### Background / Scenario

Knowledge of the Internet Protocol version 6 (IPv6) multicast groups can be helpful when assigning IPv6 addresses manually. Understanding how the all-router multicast group is assigned and how to control address assignments for the Solicited Nodes multicast group can prevent IPv6 routing issues and help ensure best practices are implemented.

In this lab, you will configure hosts and device interfaces with IPv6 addresses and explore how the all-router multicast group is assigned to a router. You will use **show** commands to view IPv6 unicast and multicast addresses. You will also verify end-to-end connectivity using the **ping** and **traceroute** commands.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 ISRs with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary table at the end of the lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS software, Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)

- 2 PCs (Windows 7 with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

**Note**: The Gigabit Ethernet interfaces on Cisco 1941 routers are autosensing and an Ethernet straightthrough cable may be used between the router and PC-B. If using another model Cisco router, it may be necessary to use an Ethernet crossover cable.

**Note**: The IPv6 protocol is enabled in Windows 7 and Vista by default. The Windows XP operating system does not enable IPv6 by default and is not recommended for use with this lab. This lab uses Windows 7 PC hosts.

# Part 1: Set Up Topology and Configure Basic Router and Switch Settings

- Step 1: Cable the network as shown in the topology.
- Step 2: Initialize and reload the router and switch.

#### Step 3: Verify that the PC interfaces are configured to use the IPv6 protocol.

Verify that the IPv6 protocol is active on both PCs by ensuring that the **Internet Protocol Version 6 (TCP/IPv6)** check box is selected in the Local Area Connection Properties window.

🖟 Local Area Connection Properties
Networking Sharing
Connect using:
Intel(R) 82577LM Gigabit Network Connection
Configure
This connection uses the following items:
VirtualBox Bridged Networking Driver
🗹 🜉 Deterministic Network Enhancer
Gos Packet Scheduler
File and Printer Sharing for Microsoft Networks
Image: A Internet Protocol Version 6 (TCP/IPV6)
Internet Hotocol Version 4 (FCF / II V4)
<
Install Uninstall Properties
Description
Allows your computer to access resources on a Microsoft network.
OK Cancel

#### Step 4: Configure the router.

- a. Console into the router and enable privileged EXEC mode.
- b. Assign the device name to the router.

- c. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were hostnames.
- d. Assign **class** as the privileged EXEC encrypted password.
- e. Assign cisco as the console password and enable login.
- f. Assign cisco as the VTY password and enable login.
- g. Encrypt the clear text passwords.
- h. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- i. Save the running configuration to the startup configuration file.

#### Step 5: Configure the switch.

- a. Console into the switch and enable privileged EXEC mode.
- b. Assign the device name to the switch.
- c. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were hostnames.
- d. Assign class as the privileged EXEC encrypted password.
- e. Assign cisco as the console password and enable login.
- f. Assign cisco as the VTY password and enable login.
- g. Encrypt the clear text passwords.
- h. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- i. Save the running configuration to the startup configuration file.

# Part 2: Configure IPv6 Addresses Manually

#### Step 1: Assign the IPv6 addresses to Ethernet interfaces on R1.

 Assign the IPv6 global unicast addresses, listed in the Addressing Table, to both Ethernet interfaces on R1.

```
R1 (config) # interface g0/0
R1 (config-if) # ipv6 address 2001:db8:acad:a::1/64
R1 (config-if) # no shutdown
R1 (config-if) # interface g0/1
R1 (config-if) # ipv6 address 2001:db8:acad:1::1/64
R1 (config-if) # no shutdown
R1 (config-if) # end
R1#
```

b. Issue the **show ipv6 interface brief** command to verify that the correct IPv6 unicast address is assigned to each interface.

```
R1# show ipv6 interface brief
Em0/0 [administratively down/down]
unassigned
GigabitEthernet0/0 [up/up]
FE80::D68C:B5FF:FECE:A0C0
2001:DB8:ACAD:A::1
```

```
GigabitEthernet0/1 [up/up]
  FE80::D68C:B5FF:FECE:A0C1
  2001:DB8:ACAD:1::1
Serial0/0/0 [administratively down/down]
  unassigned
Serial0/0/1 [administratively down/down]
  unassigned
R1#
```

c. Issue the show ipv6 interface g0/0 command. Notice that the interface is listing two Solicited Nodes multicast groups, because the IPv6 link-local (FE80) Interface ID was not manually configured to match the IPv6 unicast Interface ID.

**Note**: The link-local address displayed is based on EUI-64 addressing, which automatically uses the interface Media Access Control (MAC) address to create a 128-bit IPv6 link-local address.

```
R1# show ipv6 interface q0/0
GigabitEthernet0/0 is up, line protocol is up
 IPv6 is enabled, link-local address is FE80::D68C:B5FF:FECE:A0C0
 No Virtual link-local address(es):
 Global unicast address(es):
    2001:DB8:ACAD:A::1, subnet is 2001:DB8:ACAD:A::/64
 Joined group address(es):
   FF02::1
   FF02::1:FF00:1
   FF02::1:FFCE:A0C0
 MTU is 1500 bytes
 ICMP error messages limited to one every 100 milliseconds
 ICMP redirects are enabled
 ICMP unreachables are sent
 ND DAD is enabled, number of DAD attempts: 1
 ND reachable time is 30000 milliseconds (using 30000)
 ND advertised reachable time is 0 (unspecified)
 ND advertised retransmit interval is 0 (unspecified)
 ND router advertisements are sent every 200 seconds
 ND router advertisements live for 1800 seconds
 ND advertised default router preference is Medium
 Hosts use stateless autoconfig for addresses.
```

R1#

d. To get the link-local address to match the unicast address on the interface, manually enter the link-local addresses on each of the Ethernet interfaces on R1.

```
R1# config t
Enter configuration commands, one per line. End with CNTL/Z.
R1(config)# interface g0/0
R1(config-if)# ipv6 address fe80::1 link-local
R1(config-if)# interface g0/1
R1(config-if)# ipv6 address fe80::1 link-local
R1(config-if)# end
R1#
```

**Note**: Each router interface belongs to a separate network. Packets with a link-local address never leave the local network; therefore, you can use the same link-local address on both interfaces.

e. Re-issue the **show ipv6 interface g0/0** command. Notice that the link-local address has been changed to **FE80::1** and that there is only one Solicited Nodes multicast group listed.

```
R1# show ipv6 interface g0/0
GigabitEthernet0/0 is up, line protocol is up
 IPv6 is enabled, link-local address is FE80::1
 No Virtual link-local address(es):
 Global unicast address(es):
    2001:DB8:ACAD:A::1, subnet is 2001:DB8:ACAD:A::/64
 Joined group address(es):
   FF02::1
   FF02::1:FF00:1
 MTU is 1500 bytes
 ICMP error messages limited to one every 100 milliseconds
 ICMP redirects are enabled
 ICMP unreachables are sent
 ND DAD is enabled, number of DAD attempts: 1
 ND reachable time is 30000 milliseconds (using 30000)
 ND advertised reachable time is 0 (unspecified)
 ND advertised retransmit interval is 0 (unspecified)
 ND router advertisements are sent every 200 seconds
 ND router advertisements live for 1800 seconds
 ND advertised default router preference is Medium
 Hosts use stateless autoconfig for addresses.
R1#
```

What multicast groups have been assigned to interface G0/0?

#### Step 2: Enable IPv6 routing on R1.

 On a PC-B command prompt, enter the ipconfig command to examine IPv6 address information assigned to the PC interface.

Has an IPv6 unicast address been assigned to the network interface card (NIC) on PC-B? \_\_\_\_\_

b. Enable IPv6 routing on R1 using the IPv6 unicast-routing command.

```
R1 # configure terminal
R1 (config) # ipv6 unicast-routing
R1 (config) # exit
R1#
*Dec 17 18:29:07.415: %SYS-5-CONFIG I: Configured from console by console
```

c. Use the **show ipv6 interface g0/0** command to see what multicast groups are assigned to interface G0/0. Notice that the all-router multicast group (FF02::2) now appears in the group list for interface G0/0.

**Note**: This will allow the PCs to obtain their IP address and default gateway information automatically using Stateless Address Autoconfiguration (SLAAC).

```
R1# show ipv6 interface g0/0
GigabitEthernet0/0 is up, line protocol is up
 IPv6 is enabled, link-local address is FE80::1
 No Virtual link-local address(es):
 Global unicast address(es):
    2001:DB8:ACAD:A::1, subnet is 2001:DB8:ACAD:A::/64 [EUI]
 Joined group address(es):
   FF02::1
   FF02::2
   FF02::1:FF00:1
 MTU is 1500 bytes
 ICMP error messages limited to one every 100 milliseconds
 ICMP redirects are enabled
 ICMP unreachables are sent
 ND DAD is enabled, number of DAD attempts: 1
 ND reachable time is 30000 milliseconds (using 30000)
 ND advertised reachable time is 0 (unspecified)
 ND advertised retransmit interval is 0 (unspecified)
 ND router advertisements are sent every 200 seconds
 ND router advertisements live for 1800 seconds
 ND advertised default router preference is Medium
 Hosts use stateless autoconfig for addresses.
R1#
```

d. Now that R1 is part of the all-router multicast group, re-issue the **ipconfig** command on PC-B. Examine the IPv6 address information.

Why did PC-B receive the Global Routing Prefix and Subnet ID that you configured on R1?

#### Step 3: Assign IPv6 addresses to the management interface (SVI) on S1.

- a. Assign the IPv6 address listed in the Addressing Table to the management interface (VLAN 1) on S1. Also assign a link-local address for this interface. IPv6 command syntax is the same as on the router.
- b. Verify that the IPv6 addresses are properly assigned to the management interface using the **show ipv6** interface vlan1 command.

**Note:** The default 2960 Switch Database Manager (SDM) template does not support IPv6. It may be necessary to issue the command **sdm prefer dual-ipv4-and-ipv6 default** to enable IPv6 addressing before applying an IPv6 address to the VLAN 1 SVI.

#### Step 4: Assign static IPv6 addresses to the PCs.

 a. Open the Local Area Connection Properties window on PC-A. Select Internet Protocol Version 6 (TCP/IPv6) and click Properties.

📮 Local Area Connection Properties 📃 💌
Networking
Connect using:
Intel(R) PRO/1000 MT Network Connection
Configure
This connection uses the following items:
<ul> <li>Client for Microsoft Networks</li> <li>Client for Microsoft Network Enhancer</li> <li>QoS Packet Scheduler</li> <li>File and Printer Sharing for Microsoft Networks</li> <li>Internet Protocol Version 6 (TCP/IPv6)</li> <li>Internet Protocol Version 4 (TCP/IPv4)</li> <li>Internet Protocol Version 9 (TCP/IPv4)</li> <li>Internet Protocol Version 9 (TCP/IPv4)</li> </ul>
Install Uninstall Properties Description TCP/IP version 6. The latest version of the internet protocol that provides communication across diverse interconnected networks.
OK Cancel

b. Click the Use the following IPv6 address radio button. Refer to the Addressing Table and enter the IPv6 address, Subnet prefix length, and Default gateway information. Click OK.

nternet Protocol Version 6 (TCP/IP)	(6) Properties		<u>? ×</u>
General			
You can get IPv6 settings assigned aut Otherwise, you need to ask your netw	comatically if your network supports ork administrator for the appropriat	this capability. IPv6 settings.	
🔿 Obtain an IPv6 address automati	cally		
□ Use the following IPv6 address:-			
IPv6 address:	2001:db8:acad:1::3		
Subnet prefix length:	64		
Default gateway:	fe80::1		
C Obtain DN5 server address autor	natically		
• Use the following DNS server add	resses:		
Preferred DNS server:			
Alternate DNS server:			
Validate settings upon exit		Advand	ced
		ОК	Cancel

c. Click **Close** to close the Local Area Connection Properties window.

- d. Repeat Steps 4a to c to enter the static IPv6 information on PC-B. For the correct IPv6 address information, refer to the Addressing Table.
- e. Issue the **ipconfig** command from the command line on PC-B to verify the IPv6 address information.

## Part 3: Verify End-to-End Connectivity

a. From PC-A, ping FE80::1. This is the link-local address assigned to G0/1 on R1.

```
C:\>ping fe80::1

Pinging fe80::1 with 32 bytes of data:

Reply from fe80::1: time<1ms

Reply from fe80::1: time<1ms

Reply from fe80::1: time<1ms

Ping statistics for fe80::1:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>
```

Note: You can also test connectivity by using the global unicast address, instead of the link-local address.

b. Ping the S1 management interface from PC-A.

```
C:\>ping 2001:db8:acad:1::b
Pinging 2001:db8:acad:1::b with 32 bytes of data:
Reply from 2001:db8:acad:1::b: time=14ms
Reply from 2001:db8:acad:1::b: time=2ms
Reply from 2001:db8:acad:1::b: time=2ms
Reply from 2001:db8:acad:1::b: time=3ms
Ping statistics for 2001:db8:acad:1::b:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 2ms, Maximum = 14ms, Average = 5ms
C:\>_
```

c. Use the tracert command on PC-A to verify that you have end-to-end connectivity to PC-B.

C:\>tracert 2001:db8:acad:a::3 Tracing route to 2001:db8:acad:a::3 over a maximum of 30 hops 1 <1 ms <1 ms <1 ms 2001:db8:acad:1::1 2 5 ms <1 ms <1 ms 2001:db8:acad:a::3 Trace complete. C:\>

d. From PC-B, ping PC-A.

```
C:\>ping 2001:db8:acad:1::3

Pinging 2001:db8:acad:1::3 with 32 bytes of data:

Reply from 2001:db8:acad:1::3: time<1ms

Reply from 2001:db8:acad:1::3: time<1ms

Reply from 2001:db8:acad:1::3: time<1ms

Ping statistics for 2001:db8:acad:1::3:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>
```

e. From PC-B, ping the link-local address for G0/0 on R1.

```
C:\>ping fe80::1

Pinging fe80::1 with 32 bytes of data:

Reply from fe80::1: time<1ms

Reply from fe80::1: time<1ms

Reply from fe80::1: time<1ms

Ping statistics for fe80::1:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>_
```

**Note**: If end-to-end connectivity is not established, troubleshoot your IPv6 address assignments to verify that you entered the addresses correctly on all devices.

#### Reflection

- 1. Why can the same link-local address, FE80::1, be assigned to both Ethernet interfaces on R1?
- 2. What is the Subnet ID of the IPv6 unicast address 2001:db8:acad::aaaa:1234/64?

Router Interface Summary				
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/0/0)	Serial 0/1/1 (S0/0/1)
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)

#### **Router Interface Summary Table**

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 8.3.2.7 Lab – Testing Network Connectivity with Ping and Traceroute

Topology



#### **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
LOCAL	G0/1	192.168.1.1	255.255.255.0	N/A
	S0/0/0 (DCE)	10.1.1.1	255.255.255.252	N/A
ISP	S0/0/0	10.1.1.2	255.255.255.252	N/A
	S0/0/1 (DCE)	10.2.2.2	255.255.255.252	N/A
REMOTE	G0/1	192.168.3.1	255.255.255.0	N/A
	S0/0/1	10.2.2.1	255.255.255.252	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
S3	VLAN 1	192.168.3.11	255.255.255.0	192.168.3.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-C	NIC	192.168.3.3	255.255.255.0	192.168.3.1

#### Objectives

#### Part 1: Build and Configure the Network

- Cable the network.
- Configure the PCs.
- Configure the routers.
- Configure the switches.

#### Part 2: Use Ping Command for Basic Network Testing

- Use ping from a PC.
- Use ping from Cisco devices.

#### Part 3: Use Tracert and Traceroute Commands for Basic Network Testing

- Use tracert from a PC.
- Use traceroute from Cisco devices.

#### Part 4: Troubleshoot the Topology

#### **Background / Scenario**

Ping and traceroute are two tools that are indispensable when testing TCP/IP network connectivity. Ping is a network administration utility used to test the reachability of a device on an IP network. This utility also measures the round-trip time for messages sent from the originating host to a destination computer. The ping utility is available on Windows, Unix-like operating systems (OS), and the Cisco Internetwork Operating System (IOS).

The traceroute utility is a network diagnostic tool for displaying the route and measuring the transit delays of packets travelling an IP network. The tracert utility is available on Windows, and a similar utility, traceroute, is available on Unix-like OS and Cisco IOS.

In this lab, the **ping** and **traceroute** commands are examined and command options are explored to modify the command behavior. Cisco devices and PCs are used in this lab for command exploration. Cisco routers

will use Enhanced Interior Gateway Routing Protocol (EIGRP) to route packets between networks. The necessary Cisco device configurations are provided in this lab.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 3 Routers (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 2 Switches (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet and serial cables as shown in the topology

# Part 1: Build and Configure the Network

In Part 1, you will set up the network in the topology and configure the PCs and Cisco devices. The initial configurations for the routers and switches are provided for your reference. In this topology, EIGRP is used to route packets between networks.

- Step 1: Cable the network as shown in the topology.
- Step 2: Erase the configurations on the routers and switches, and reload the devices.
- Step 3: Configure PC IP addresses and default gateways according to the Addressing Table.

# Step 4: Configure the LOCAL, ISP, and REMOTE routers using the initial configurations provided below.

At the switch or router global config mode prompt, copy and paste the configuration for each device. Save the configuration to startup-config.

#### Initial configurations for the LOCAL router:

```
hostname LOCAL
no ip domain-lookup
interface s0/0/0
ip address 10.1.1.1 255.255.255.252
clock rate 56000
no shutdown
interface g0/1
ip add 192.168.1.1 255.255.255.0
no shutdown
router eigrp 1
network 10.1.1.0 0.0.0.3
```

```
network 192.168.1.0 0.0.0.255
no auto-summary
Initial configurations for ISP:
hostname ISP
no ip domain-lookup
interface s0/0/0
ip address 10.1.1.2 255.255.255.252
no shutdown
interface s0/0/1
ip add 10.2.2.2 255.255.255.252
 clock rate 56000
no shutdown
router eigrp 1
 network 10.1.1.0 0.0.0.3
network 10.2.2.0 0.0.0.3
no auto-summary
end
```

# Initial configurations for REMOTE:

```
hostname REMOTE
no ip domain-lookup
interface s0/0/1
ip address 10.2.2.1 255.255.255.252
no shutdown
interface g0/1
ip add 192.168.3.1 255.255.255.0
no shutdown
router eigrp 1
network 10.2.2.0 0.0.0.3
network 192.168.3.0 0.0.0.255
no auto-summary
end
```

#### Step 5: Configure the S1 and S3 switches with the initial configurations.

#### Initial configurations for S1:

```
hostname S1
no ip domain-lookup
interface vlan 1
  ip add 192.168.1.11 255.255.255.0
  no shutdown
  exit
  ip default-gateway 192.168.1.1
end
Initial configurations for S3:
```

```
hostname S3
no ip domain-lookup
interface vlan 1
  ip add 192.168.3.11 255.255.255.0
  no shutdown
  exit
  ip default-gateway 192.168.3.1
end
```

#### Step 6: Configure an IP host table on the LOCAL router.

The IP host table allows you to use a hostname to connect to a remote device rather than an IP address. The host table provides name resolution for the device with the following configurations. Copy and paste the following configurations for the LOCAL router. The configurations will allow you to use the hostnames for **ping** and **traceroute** commands on the LOCAL router.

```
ip host REMOTE 10.2.2.1 192.168.3.1
ip host ISP 10.1.1.2 10.2.2.2
ip host LOCAL 192.168.1.1 10.1.1.1
ip host PC-C 192.168.3.3
ip host PC-A 192.168.1.3
ip host S1 192.168.1.11
ip host S3 192.168.3.11
end
```

# Part 2: Use Ping Command for Basic Network Testing

In Part 2 of this lab, use the **ping** command to verify end-to-end connectivity. Ping operates by sending Internet Control Message Protocol (ICMP) echo request packets to the target host and then waiting for an ICMP response. It can record the round trip time and any packet loss.

You will examine the results with the **ping** command and the additional ping options that are available on Windows-based PCs and Cisco devices.

#### Step 1: Test network connectivity from the LOCAL network using PC-A.

All the pings from PC-A to other devices in the topology should be successful. If they are not, check the topology and the cabling, as well as the configuration of the Cisco devices and the PCs.

a. Ping from PC-A to its default gateway (LOCAL's GigabitEthernet 0/1 interface).

```
C:\Users\User1> ping 192.168.1.1
Pinging 192.168.1.1 with 32 bytes of data:
Reply from 192.168.1.1: bytes=32 time<1ms TTL=255
Reply from 192.168.1.1: bytes=32 time<1ms TTL=255
Reply from 192.168.1.1: bytes=32 time<1ms TTL=255
Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = Oms, Maximum = Oms, Average = Oms</pre>
```

In this example, four (4) ICMP requests, 32 bytes each, were sent and the responses were received in less than one millisecond with no packet loss. The transmission and reply time increases as the ICMP requests and responses are processed by more devices during the journey to and from the final destination.

b. From PC-A, ping the addresses listed in the following table and record the average round trip time and Time to Live (TTL).

Destination	Average Round Trip Time (ms)	TTL
192.168.1.1 (LOCAL)		
192.168.1.11 (S1)		
10.1.1.1 (LOCAL)		
10.1.1.2 (ISP)		
10.2.2.2 (ISP)		
10.2.2.1 (REMOTE)		
192.168.3.1 (REMOTE)		
192.168.3.11 (S3)		
192.168.3.3 (PC-C)		

Notice the average round trip time to 192.168.3.3 (PC-C). The time increased because the ICMP requests were processed by three routers before PC-A received the reply from PC-C.

```
C:\Users\User1> ping 192.168.3.3
Pinging 192.168.3.3 with 32 bytes of data:
Reply from 192.168.3.3: bytes=32 time=41ms TTL=125
Reply from 192.168.3.3: bytes=32 time=41ms TTL=125
Reply from 192.168.3.3: bytes=32 time=41ms TTL=125
Ping statistics for 192.168.3.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 40ms, Maximum = 41ms, Average = 40ms
```

#### Step 2: Use extended ping commands on a PC.

The default **ping** command sends four requests at 32 bytes each. It waits 4,000 milliseconds (4 seconds) for each response to be returned before displaying the "Request timed out" message. The **ping** command can be fine tuned for troubleshooting a network.

a. At the command prompt, type **ping** and press Enter.

```
C:\Users\User1> ping
Usage: ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL] [-v TOS]
            [-r count] [-s count] [[-j host-list]] | [-k host-list]]
            [-w timeout] [-R] [-S srcaddr] [-4] [-6] target_name
Options:
            -t Ping the specified host until stopped.
```

		To see statistics and continue - type Control-Break;
		To stop - type Control-C.
-a		Resolve addresses to hostnames.
-n	count	Number of echo requests to send.
-1	size	Send buffer size.
-f		Set Don't Fragment flag in packet (IPv4-only).
-i	TTL	Time To Live.
-v	TOS	Type Of Service (IPv4-only. This setting has been deprecated
		and has no effect on the type of service field in the IP Header).
-r	count	Record route for count hops (IPv4-only).
-s	count	Timestamp for count hops (IPv4-only).
-j	host-list	Loose source route along host-list (IPv4-only).
-k	host-list	Strict source route along host-list (IPv4-only).
-w	timeout	Timeout in milliseconds to wait for each reply.
-R		Use routing header to test reverse route also (IPv6-only).
-S	srcaddr	Source address to use.
-4		Force using IPv4.
-6		Force using IPv6.

b. Using the -t option, ping PC-C to verify that PC-C is reachable.

C:\Users\User1> ping -t 192.168.3.3

Reply from 192.168.3.3: bytes=32 time=41ms TTL=125 Reply from 192.168.3.3: bytes=32 time=40ms TTL=125

To illustrate the results when a host is unreachable, disconnect the cable between the REMOTE router and the S3 switch, or shut down the GigabitEthernet 0/1 interface on the REMOTE router.

Reply from 192.168.3.3: bytes=32 time=41ms TTL=125 Reply from 192.168.1.3: Destination host unreachable. Reply from 192.168.1.3: Destination host unreachable.

While the network is functioning correctly, the **ping** command can determine whether the destination responded and how long it took to receive a reply from the destination. If a network connectivity problem exists, the **ping** command displays an error message.

c. Reconnect the Ethernet cable or enable the GigabitEthernet interface on the REMOTE router (using the **no shutdown** command) before moving onto the next step. After about 30 seconds, the ping should be successful again.

Request timed out. Request timed out. Request timed out. Request timed out. Reply from 192.168.3.3: bytes=32 time=41ms TTL=125 Reply from 192.168.3.3: bytes=32 time=40ms TTL=125

d. Press Ctrl+C to stop the ping command.

#### Step 3: Test network connectivity from the LOCAL network using Cisco devices.

The **ping** command is also available on Cisco devices. In this step, the **ping** command is examined using the LOCAL router and the S1 switch.

a. Ping PC-C on the REMOTE network using the IP address of 192.168.3.3 from the LOCAL router.

LOCAL# ping 192.168.3.3

Type escape sequence to abort. Sending 5, 100-byte ICMP Echos to 192.168.3.3, timeout is 2 seconds: !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 60/64/68 ms

The exclamation point (!) indicates that the ping was successful from the LOCAL router to PC-C. The round trip takes an average of 64 ms with no packet loss, as indicated by a 100% success rate.

b. Because a local host table was configured on the LOCAL router, you can ping PC-C on the REMOTE network using the hostname configured from the LOCAL router.

```
LOCAL# ping PC-C
```

```
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.3.3, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 60/63/64 ms
```

c. There are more options available for the **ping** command. At the CLI, type **ping** and press Enter. Input **192.168.3.3** or **PC-C** for the Target IP address. Press Enter to accept the default value for other options.

```
LOCAL# ping
Protocol [ip]:
Target IP address: PC-C
Repeat count [5]:
Datagram size [100]:
Timeout in seconds [2]:
Extended commands [n]:
Sweep range of sizes [n]:
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.3.3, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 60/63/64 ms
```

d. You can use an extended ping to observe when there is a network issue. Start the **ping** command to 192.168.3.3 with a repeat a count of 500. Then, disconnect the cable between the REMOTE router and the S3 switch or shut down the GigabitEthernet 0/1 interface on the REMOTE router.

Reconnect the Ethernet cable or enable the GigabitEthernet interface on the REMOTE router after the exclamation points (!) have replaced by the letter U and periods (.). After about 30 seconds, the ping should be successful again. Press **Ctrl+Shift+6** to stop the **ping** command if desired.

The letter U in the results indicates that a destination is unreachable. An error protocol data unit (PDU) was received by the LOCAL router. Each period (.) in the output indicates that the ping timed out while waiting for a reply from PC-C. In this example, 5% of the packets were lost during the simulated network outage.

Note: You can also use the following command for the same results:

LOCAL# ping 192.168.3.3 repeat 500 or LOCAL# ping PC-C repeat 500

e. You can also test network connectivity with a switch. In this example, the S1 switch pings the S3 switch on the REMOTE network.

```
S1# ping 192.168.3.11
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.3.11, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 67/67/68 ms
```

The **ping** command is extremely useful when troubleshooting network connectivity. However, ping cannot indicate the location of problem when a ping is not successful. The **tracert** (or **traceroute**) command can display network latency and path information.

# Part 3: Use Tracert and Traceroute Commands for Basic Network Testing

The commands for tracing routes can be found on PCs and network devices. For a Windows-based PC, the **tracert** command uses ICMP messages to trace the path to the final destination. The **traceroute** command utilizes the User Datagram Protocol (UDP) datagrams for tracing routes to the final destination for Cisco devices and other Unix-like PCs.

In Part 3, you will examine the traceroute commands and determine the path that a packet travels to its final destination. You will use the **tracert** command from the Windows PCs and the **traceroute** command from the Cisco devices. You will also examine the options that are available for fine tuning the traceroute results.

#### Step 1: Use the tracert command from PC-A to PC-C.

a. At the command prompt, type tracert 192.168.3.3.

```
C:\Users\User1> tracert 192.168.3.3
Tracing route to PC-C [192.168.3.3]
Over a maximum of 30 hops:
 1
      <1 ms
              <1 ms
                       <1 ms
                               192.168.1.1
 2
      24 ms
              24 ms 24 ms
                               10.1.1.2
  3
      48 ms
              48 ms
                      48 ms
                               10.2.2.1
      59 ms 59 ms 59 ms PC-C [192.168.3.3]
  4
Trace complete.
```

The tracert results indicates the path from PC-A to PC-C is from PC-A to LOCAL to ISP to REMOTE to PC-C. The path to PC-C traveled through three router hops to the final destination of PC-C.

#### **Step 2:** Explore additional options for the tracert command.

a. At the command prompt, type tracert and press Enter.

```
C:\Users\User1> tracert
```

```
Usage: tracert [-d] [-h maximum_hops] [-j host-list] [-w timeout]
[-R] [-S srcaddr] [-4] [-6] target_name
```

Options:

-d	Do not resolve addresses to hostnames.
-h maximum_hops	Maximum number of hops to search for target.
-j host-list	Loose source route along host-list (IPv4-only).
-w timeout	Wait timeout milliseconds for each reply.
-R	Trace round-trip path (IPv6-only).
-S srcaddr	Source address to use (IPv6-only).
-4	Force using IPv4.
-6	Force using IPv6.

b. Use the -d option. Notice that the IP address of 192.168.3.3 is not resolved as PC-C.

```
C:\Users\User1> tracert -d 192.168.3.3
```

```
Tracing route to 192.168.3.3 over a maximum of 30 hops:
```

1	<1	ms	<1	ms	<1	ms	192.168.1.1
2	24	ms	24	ms	24	ms	10.1.1.2
3	48	ms	48	ms	48	ms	10.2.2.1
4	59	ms	59	ms	59	ms	192.168.3.3

Trace complete.

#### Step 3: Use the traceroute command from the LOCAL router to PC-C.

a. At the command prompt, type **traceroute 192.168.3.3** or **traceroute PC-C** on the LOCAL router. The hostnames are resolved because a local IP host table was configured on the LOCAL router.

```
LOCAL# traceroute 192.168.3.3
```

```
Type escape sequence to abort.
Tracing the route to PC-C (192.168.3.3)
VRF info: (vrf in name/id, vrf out name/id)
1 ISP (10.1.1.2) 16 msec 16 msec 16 msec
2 REMOTE (10.2.2.1) 28 msec 32 msec 28 msec
3 PC-C (192.168.3.3) 32 msec 28 msec 32 msec
```

#### LOCAL# traceroute PC-C

Type escape sequence to abort. Tracing the route to PC-C (192.168.3.3) VRF info: (vrf in name/id, vrf out name/id) 1 ISP (10.1.1.2) 16 msec 16 msec 16 msec 2 REMOTE (10.2.2.1) 28 msec 32 msec 28 msec 3 PC-C (192.168.3.3) 32 msec 32 msec 28 msec

#### Step 4: Use the traceroute command from the S1 switch to PC-C.

a. On the S1 switch, type **traceroute 192.168.3.3**. The hostnames are not displayed in the traceroute results because a local IP host table was not configured on this switch.

```
S1# traceroute 192.168.3.3
Type escape sequence to abort.
Tracing the route to 192.168.3.3
VRF info: (vrf in name/id, vrf out name/id)
    1 192.168.1.1 1007 msec 0 msec 0 msec
    2 10.1.1.2 17 msec 17 msec 16 msec
    3 10.2.2.1 34 msec 33 msec 26 msec
    4 192.168.3.3 33 msec 34 msec 33 msec
```

The **traceroute** command has additional options. You can use the **?** or just press Enter after typing **traceroute** at the prompt to explore these options.

The following link provides more information regarding the **ping** and **traceroute** commands for a Cisco device:

http://www.cisco.com/en/US/products/sw/iosswrel/ps1831/products\_tech\_note09186a00800a6057.shtml

## Part 4: Troubleshoot the Topology

- Step 1: Erase the configurations on the REMOTE router.
- Step 2: Reload the REMOTE router.
- Step 3: Copy and paste the following configuration into the REMOTE router.

```
hostname REMOTE
no ip domain-lookup
interface s0/0/1
ip address 10.2.2.1 255.255.255.252
no shutdown
interface g0/1
ip add 192.168.8.1 255.255.255.0
no shutdown
router eigrp 1
network 10.2.2.0 0.0.0.3
network 192.168.3.0 0.0.0.255
no auto-summary
end
```

- Step 4: From the LOCAL network, use ping and tracert or traceroute commands to troubleshoot and correct the problem on the REMOTE network.
  - a. Use the ping and tracert commands from PC-A.

You can use the **tracert** command to determine end-to-end network connectivity. This tracert result indicates that PC-A can reach its default gateway of 192.168.1.1, but PC-A does not have network connectivity with PC-C.

```
C:\Users\User1> tracert 192.168.3.3
Tracing route to 192.168.3.3 over a maximum of 30 hops
1 <1 ms <1 ms <1 ms 192.168.1.1
2 192.168.1.1 reports: Destination host unreachable.</pre>
```

Trace complete.

One way to locate the network issue is to ping each hop in the network to PC-C. First determine if PC-A can reach the ISP router Serial 0/0/1 interface with an IP address of 10.2.2.2.

```
C:\Users\Utraser1> ping 10.2.2.2
Pinging 10.2.2.2 with 32 bytes of data:
Reply from 10.2.2.2: bytes=32 time=41ms TTL=254
Reply from 10.2.2.2: bytes=32 time=41ms TTL=254
Reply from 10.2.2.2: bytes=32 time=41ms TTL=254
Ping statistics for 10.2.2.2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 20ms, Maximum = 21ms, Average = 20ms
```

The ping was successful to the ISP router. The next hop in the network is the REMOTE router. Ping the REMOTE router Serial 0/0/1 interface with an IP address of 10.2.2.1.

```
C:\Users\User1> ping 10.2.2.1

Pinging 10.2.2.1 with 32 bytes of data:

Reply from 10.2.2.1: bytes=32 time=41ms TTL=253

Reply from 10.2.2.1: bytes=32 time=41ms TTL=253

Reply from 10.2.2.1: bytes=32 time=41ms TTL=253

Reply from 10.2.2.1: bytes=32 time=41ms TTL=253
```

```
Ping statistics for 10.2.2.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 40ms, Maximum = 41ms, Average = 40ms
```

PC-A can reach the REMOTE router. Based on the successful ping results from PC-A to the REMOTE router, the network connectivity issue is with 192.168.3.0/24 network. Ping the default gateway to PC-C, which is the GigabitEthernet 0/1 interface of the REMOTE router.

```
C:\Users\User1> ping 192.168.3.1
```

Pinging 192.168.3.1 with 32 bytes of data: Reply from 192.168.1.1: Destination host unreachable. Reply from 192.168.1.1: Destination host unreachable. Reply from 192.168.1.1: Destination host unreachable.

```
Reply from 192.168.1.1: Destination host unreachable.
Ping statistics for 192.168.3.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
```

PC-A cannot reach the GigabitEthernet 0/1 interface of the REMOTE router, as displayed by the results from the **ping** command.

The S3 switch can also be pinged from PC-A to verify the location of the networking connectivity issue by typing **ping 192.168.3.11** at the command prompt. Because PC-A cannot reach GigabitEthernet 0/1 of the REMOTE router, PC-A probably cannot ping the S3 switch successfully, as indicated by the results below.

```
C:\Users\User1> ping 192.168.3.11
```

```
Pinging 192.168.3.11 with 32 bytes of data:
Reply from 192.168.1.1: Destination host unreachable.
Ping statistics for 192.168.3.11:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
```

The tracert and ping results conclude that PC-A can reach the LOCAL, ISP, and REMOTE routers, but not PC-C or the S3 switch, nor the default gateway for PC-C.

b. Use the **show** commands to examine the running configurations for the the REMOTE router.

REMOTE#	show	ip	interface	brief	
---------	------	----	-----------	-------	--

Interface	IP-Address	OK?	Method	Status		Protocol
Embedded-Service-Engine0/0	unassigned	YES	unset	administratively do	wn	down
GigabitEthernet0/0	unassigned	YES	unset	administratively do	wn	down
GigabitEthernet0/1	192.168.8.1	YES	manual	up		up
Serial0/0/0	unassigned	YES	unset	administratively do	wn	down
Serial0/0/1	10.2.2.1	YES	manual	up		up

#### REMOTE# show run

<output omitted=""></output>
interface GigabitEthernet0/0
no ip address
shutdown
duplex auto
speed auto
!
interface GigabitEthernet0/1
ip address 192.168.8.1 255.255.255.0
duplex auto
speed auto
!
interface Serial0/0/0
no ip address
shutdown

```
clock rate 2000000
!
interface Serial0/0/1
ip address 10.2.2.1 255.255.255
<output omitted>
```

The outputs of the **show run** and **show ip interface brief** commands indicate that the GigabitEthernet 0/1 interface is up/up, but was configured with an incorrect IP address.

c. Correct the IP address for GigabitEthernet 0/1.

```
REMOTE# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
REMOTE(config)# interface GigabitEthernet 0/1
REMOTE(config-if)# ip address 192.168.3.1 255.255.255.0
```

d. Verify that PC-A can ping and tracert to PC-C.

```
C:\Users\User1> ping 192.168.3.3

Pinging 192.168.3.3 with 32 bytes of data:

Reply from 192.168.3.3: bytes=32 time=44ms TTL=125

Reply from 192.168.3.3: bytes=32 time=41ms TTL=125

Reply from 192.168.3.3: bytes=32 time=40ms TTL=125

Reply from 192.168.3.3: bytes=32 time=41ms TTL=125
```

```
Ping statistics for 192.168.3.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 40ms, Maximum = 44ms, Average = 41ms
```

C:\Users\User1> tracert 192.168.3.3

```
Tracing route to PC-C [192.168.3.3]
Over a maximum of 30 hops:
```

1	<1	ms	<1	ms	<1	ms	192.168.1.1
2	24	ms	24	ms	24	ms	10.1.1.2
3	48	ms	48	ms	48	ms	10.2.2.1
4	59	ms	59	ms	59	ms	PC-C [192.168.3.3]

Trace complete.

**Note**: This can also be accomplished using **ping** and **traceroute** commands from the CLI on the the LOCAL router and the S1 switch after verifying that there are no network connectivity issues on the 192.168.1.0/24 network.

#### Reflection

1. What could prevent ping or traceroute responses from reaching the originating device beside network connectivity issues?

- 2. If you ping a non-existent address on the remote network, such as 192.168.3.4, what is the message displayed by the **ping** command? What does this mean? If you ping a valid host address and receive this response, what should you check?
- 3. If you ping an address that does not exist in any network in your topology, such as 192.168.5.3, from a Windows-based PC, what is the message displayed by the **ping** command? What does this message indicate?

#### **Router Interface Summary Table**

Router Interface Summary						
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2		
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)		
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 8.4.1.1 The Internet of Everything...Naturally!

#### **Objectives**

#### Explain the need for IPv6 network addresses.

This is an application-based activity. You will develop a plan to show how IoE subnets, unicasts, and multicasts could be used in our daily lives to affect data communication.

#### Background/Scenario

**Note:** This activity may be completed individually or in small/large groups.

This chapter discussed the ways in which small to medium-sized businesses are connected to networks in groups. The IoE was introduced in the activity at the beginning of this chapter.

Choose one of the following:

- Online banking
- World news
- Weather forecasting/climate
- Traffic conditions

Devise an IPv6 addressing scheme for the area you have chosen. Your addressing scheme should include how you would plan for:

- Subnetting
- Unicasts
- Multicasts

Keep a copy of your scheme to share with the class or learning community. Be prepared to explain:

- How subnetting, unicasts, and multicasts could be incorporated
- Where your addressing scheme could be used
- How small to medium-size businesses would be affected by using your plan

#### **Required Resources**

- Paper, pens, pencils, or tablets
- Packet Tracer (if you would like to display how your network would physically look)
- Hard- or soft-copy of the final network topology with IPv6 addressing indicated for sharing with the class.

#### Reflection

1. What was the hardest part of designing this network model? Explain your answer.

# 9.0.1.2 Call me!

#### **Objectives**

#### Explain why routing is necessary for hosts on different subnets to communicate.

In this activity, you will:

- Recognize that data is delivered quicker if group addressing identifiers are used.
- Visualize how communication is facilitated through providing large groups and then splitting those groups into more manageable parts. After reflecting on how your smartphone or landline telephone numbers are divided, you can draw inferences to how networking employs the same practices.

#### Background/Scenario

In this chapter, you will learn how devices can be grouped into subnets, or smaller network groups, from a large network.

In this modeling activity, you are asked to think about a number you probably use every day, a number such as your telephone number. As you complete the activity, think about how your telephone number compares to strategies that network administrators might use to identify hosts for efficient data communication.

Complete the two sections listed below and record your answers. Save the two sections in either hard- or soft-copy format to use later for class discussion purposes.

- Explain how your smartphone or landline telephone number is divided into identifying groups of numbers. Does your telephone number use an area code? An Internet service provider (ISP) identifier? A city, state, or country code?
- In what ways does separating your telephone number into managed parts assist in contacting or communicating with others?

#### **Required Resources**

Recording capabilities (paper, tablet, etc.) for reflective comments to be shared with the class

#### Reflection

1. Why do you think ISPs need your telephone number when setting up your account parameters?

# 9.1.4.8 Lab – Calculating IPv4 Subnets

#### **Objectives**

#### Part 1: Determine IPv4 Address Subnetting

- Determine the network address.
- Determine the broadcast address.
- Determine the number of hosts.

#### Part 2: Calculate IPv4 Address Subnetting

- Determine the number of subnets created.
- Determine number of hosts per subnet.
- Determine the subnet address.
- Determine the host range for the subnet.
- Determine the broadcast address for the subnet.

#### **Background / Scenario**

The ability to work with IPv4 subnets and determine network and host information based on a given IP address and subnet mask is critical to understanding how IPv4 networks operate. The first part is designed to reinforce how to compute network IP address information from a given IP address and subnet mask. When given an IP address and subnet mask, you will be able to determine other information about the subnet such as:

- Network address
- Broadcast address
- Total number of host bits
- Number of hosts per subnet

In the second part of the lab, for a given IP address and subnet mask, you will determine such information as follows:

- Network address of this subnet
- Broadcast address of this subnet
- Range of host addresses for this subnet
- Number of subnets created
- Number of hosts for each subnet

#### **Required Resources**

- 1 PC (Windows 7, Vista, or XP with Internet access)
- Optional: IPv4 address calculator

# Part 1: Determine IPv4 Address Subnetting

In Part 1, you will determine the network and broadcast addresses, as well as the number of hosts, given an IPv4 address and subnet mask.

**REVIEW**: To determine the network address, perform binary ANDing on the IPv4 address using the subnet mask provided. The result will be the network address. Hint: If the subnet mask has decimal value 255 in an octet, the result will ALWAYS be the original value of that octet. If the subnet mask has decimal value 0 in an octet, the result will ALWAYS be 0 for that octet.

Example:

IP Address	192.168.10.10
Subnet Mask	255.255.255.0
	=========
Result (Network)	192.168.10.0

Knowing this, you may only have to perform binary ANDing on an octet that does not have 255 or 0 in its subnet mask portion.

Example:

IP Address	172.30.239.145
Subnet Mask	255.255.192.0

Analyzing this example, you can see that you only have to perform binary ANDing on the third octet. The first two octets will result in 172.30 due to the subnet mask. The fourth octet will result in 0 due to the subnet mask.

IP Address	172.30.239.145
Subnet Mask	255.255.192.0
	=========
Result (Network)	172.30. <b>?</b> .0

Perform binary ANDing on the third octet.

	Decimal	Binary
	239	11101111
	192	11000000
		======
Result	192	11000000
ing this c	womple oggi	n nroducco the

Analyzing this example again produces the following result:

IP Address	172.30.239.145
Subnet Mask	255.255.192.0
	=========
Result (Network)	172.30.192.0

Continuing with this example, determining the number of hosts per network can be calculated by analyzing the subnet mask. The subnet mask will be represented in dotted decimal format, such as 255.255.192.0, or in network prefix format, such as /18. An IPv4 address always has 32 bits. Subtracting the number of bits used for the network portion (as represented by the subnet mask) gives you the number of bits used for hosts.

Using our example above, the subnet mask 255.255.192.0 is equivalent to /18 in prefix notation. Subtracting 18 network bits from 32 bits results in 14 bits left for the host portion. From there, it is a simple calculation:

 $2^{(number of host bits)} - 2 = Number of hosts$ 

 $2^{14} = 16,384 - 2 = 16,382$  hosts
Determine the network and broadcast addresses and number of host bits and hosts for the given IPv4 addresses and prefixes in the following table.

IPv4 Address/Prefix	Network Address	Broadcast Address	Total Number of Host Bits	Total Number of Hosts
192.168.100.25/28				
172.30.10.130/30				
10.1.113.75/19				
198.133.219.250/24				
128.107.14.191/22				
172.16.104.99/27				

# Part 2: Calculate IPv4 Address Subnetting

When given an IPv4 address, the original subnet mask and the new subnet mask, you will be able to determine:

- Network address of this subnet
- Broadcast address of this subnet
- Range of host addresses of this subnet
- Number of subnets created
- Number of hosts per subnet

The following example shows a sample problem along with the solution for solving this problem:

Given:				
Host IP Address:	172.16.77.120			
Original Subnet Mask	255.255.0.0			
New Subnet Mask:	255.255.240.0			
Find:				
Number of Subnet Bits	4			
Number of Subnets Created	16			
Number of Host Bits per Subnet	12			
Number of Hosts per Subnet	4,094			
Network Address of this Subnet	172.16.64.0			
IPv4 Address of First Host on this Subnet	172.16.64.1			
IPv4 Address of Last Host on this Subnet	172.16.79.254			
IPv4 Broadcast Address on this Subnet	172.16.79.255			

Let's analyze how this table was completed.

The original subnet mask was 255.255.0.0 or /16. The new subnet mask is 255.255.240.0 or /20. The resulting difference is 4 bits. Because 4 bits were borrowed, we can determine that 16 subnets were created because  $2^4 = 16$ .

The new mask of 255.255.240.0 or /20 leaves 12 bits for hosts. With 12 bits left for hosts, we use the following formula:  $2^{12} = 4,096 - 2 = 4,094$  hosts per subnet.

Binary ANDing will help you determine the subnet for this problem, which results in the network 172.16.64.0.

Finally, you need to determine the first host, last host, and broadcast address for each subnet. One method to determine the host range is to use binary math for the host portion of the address. In our example, the last 12 bits of the address is the host portion. The first host would have all significant bits set to zero and the least significant bit set to 1. The last host would have all significant bits set to 1 and the least significant bit set to 0. In this example, the host portion of the address resides in the 3<sup>rd</sup> and 4<sup>th</sup> octets.

Description	1 <sup>st</sup> Octet	2 <sup>nd</sup> Octet	3 <sup>rd</sup> Octet	4 <sup>th</sup> Octet	Description
Network/Host	nnnnnnn	nnnnnnn	<b>nnnn</b> hhhh	hhhhhhh	Subnet Mask
Binary	10101100	00010000	<b>0100</b> 0000	00000001	First Host
Decimal	172	16	64	1	First Host
Binary	10101100	00010000	<b>0100</b> 1111	1111110	Last Host
Decimal	172	16	79	254	Last Host
Binary	10101100	00010000	<b>0100</b> 1111	11111111	Broadcast
Decimal	172	16	79	255	Broadcast

# Step 1: Fill out the tables below with appropriate answers given the IPv4 address, original subnet mask, and new subnet mask.

a. Problem 1:

Given:	
Host IP Address:	192.168.200.139
Original Subnet Mask	255.255.255.0
New Subnet Mask:	255.255.255.224
Find:	
Number of Subnet Bits	
Number of Subnets Created	
Number of Host Bits per Subnet	
Number of Hosts per Subnet	
Network Address of this Subnet	
IPv4 Address of First Host on this Subnet	
IPv4 Address of Last Host on this Subnet	
IPv4 Broadcast Address on this Subnet	

b. Problem 2:

Given:			
Host IP Address:	10.101.99.228		
Original Subnet Mask	255.0.0.0		
New Subnet Mask:	255.255.128.0		
Find:			
Number of Subnet Bits			
Number of Subnets Created			
Number of Host Bits per Subnet			
Number of Hosts per Subnet			
Network Address of this Subnet			
IPv4 Address of First Host on this Subnet			
IPv4 Address of Last Host on this Subnet			
IPv4 Broadcast Address on this Subnet			

c. Problem 3:

Given:			
Host IP Address:	172.22.32.12		
Original Subnet Mask	255.255.0.0		
New Subnet Mask:	255.255.224.0		
Find:			
Number of Subnet Bits			
Number of Subnets Created			
Number of Host Bits per Subnet			
Number of Hosts per Subnet			
Network Address of this Subnet			
IPv4 Address of First Host on this Subnet			
IPv4 Address of Last Host on this Subnet			
IPv4 Broadcast Address on this Subnet			

d. Problem 4:

Given:			
Host IP Address:	192.168.1.245		
Original Subnet Mask	255.255.255.0		
New Subnet Mask:	255.255.255.252		
Find:			
Number of Subnet Bits			
Number of Subnets Created			
Number of Host Bits per Subnet			
Number of Hosts per Subnet			
Network Address of this Subnet			
IPv4 Address of First Host on this Subnet			
IPv4 Address of Last Host on this Subnet			
IPv4 Broadcast Address on this Subnet			

e. Problem 5:

Given:			
Host IP Address:	128.107.0.55		
Original Subnet Mask	255.255.0.0		
New Subnet Mask:	255.255.255.0		
Find:			
Number of Subnet Bits			
Number of Subnets Created			
Number of Host Bits per Subnet			
Number of Hosts per Subnet			
Network Address of this Subnet			
IPv4 Address of First Host on this Subnet			
IPv4 Address of Last Host on this Subnet			
IPv4 Broadcast Address on this Subnet			

f. Problem 6:

Given:			
Host IP Address:	192.135.250.180		
Original Subnet Mask	255.255.255.0		
New Subnet Mask:	255.255.255.248		
Find:			
Number of Subnet Bits			
Number of Subnets Created			
Number of Host Bits per Subnet			
Number of Hosts per Subnet			
Network Address of this Subnet			
IPv4 Address of First Host on this Subnet			
IPv4 Address of Last Host on this Subnet			
IPv4 Broadcast Address on this Subnet			

#### Reflection

Why is the subnet mask so important when analyzing an IPv4 address?

# 9.1.4.9 Lab – Subnetting Network Topologies

#### Objectives

#### Parts 1 to 5, for each network topology:

- Determine the number of subnets.
- Design an appropriate addressing scheme.
- Assign addresses and subnet mask pairs to device interfaces.
- Examine the use of the available network address space and future growth potential.

#### **Background / Scenario**

When given a network topology, it is important to be able to determine the number of subnets required. In this lab, several scenario topologies will be provided, along with a base network address and mask. You will subnet the network address and provide an IP addressing scheme that will accommodate the number of subnets displayed in the topology diagram. You must determine the number of bits to borrow, the number of hosts per subnet, and potential for growth as specified by the instructions.

# Part 1: Network Topology A

In Part 1, you have been given the 192.168.10.0/24 network address to subnet, with the following topology. Determine the number of networks needed and then design an appropriate addressing scheme.



#### Step 1: Determine the number of subnets in Network Topology A.

- a. How many subnets are there? \_\_\_\_\_
- b. How many bits should you borrow to create the required number of subnets? \_\_\_\_\_
- c. How many usable host addresses per subnet are in this addressing scheme? \_\_\_\_\_
- d. What is the new subnet mask in dotted decimal format?
- e. How many subnets are available for future use? \_\_\_\_\_

Fill in the following table with the subnet information:

Subnet Number	Subnet Address	First Usable Host Address	Last Usable Host Address	Broadcast Address
0				
1				
2				
3				
4				
5				

# Part 2: Network Topology B

The network topology from Part 1 has expanded to accommodate the addition of router R3 and its accompanying network, as illustrated in the following topology. Use the 192.168.10.0/24 network address to provide addresses to the network devices, and then design a new addressing scheme to support the additional network requirement.



#### Step 1: Determine the number of subnets in Network Topology B.

- a. How many subnets are there? \_\_\_\_\_
- b. How many bits should you borrow to create the required number of subnets? \_\_\_\_\_
- c. How many usable host addresses per subnet are in this addressing scheme? \_\_\_\_\_
- d. What is the new subnet mask in dotted decimal format?
- e. How many subnets are available for future use? \_\_\_\_\_

Subnet Number	Subnet Address	First Usable Host Address	Last Usable Host Address	Broadcast Address
0				
1				
2				
3				
4				
5				
6				
7				

#### Part 3: Network Topology C

The topology has changed again with a new LAN added to R2 and a redundant link between R1 and R3. Use the 192.168.10.0/24 network address to provide addresses to the network devices. Also provide an IP address scheme that will accommodate these additional devices. For this topology, assign a subnet to each network.



#### Step 1: Determine the number of subnets in Network Topology C.

- a. How many subnets are there?
- b. How many bits should you borrow to create the required number of subnets? \_\_\_\_\_
- c. How many usable host addresses per subnet are in this addressing scheme? \_\_\_\_\_
- d. What is the new subnet mask in dotted decimal format?
- e. How many subnets are available for future use? \_\_\_\_\_

Fill in the follo	owing table with the su	bnet information:		
Subnet Number	Subnet Address	First Usable Host Address	Last Usable Host Address	Broadcast Address
0				
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				

Fill in the following table with the subnet information:

#### Step 3: Assign addresses to network devices in the subnets.

a. Fill in the following table with IP addresses and subnet masks for the router interfaces:

Device	Interface	IP Address	Subnet Mask
R1	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		
R2	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		
R3	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		

b. Fill in the following table with the IP addresses and subnet masks for devices in the LAN as displayed in topology.

Device	Interface	IP Address	Subnet Mask	Default Gateway
PC-A	NIC			
PC-B	NIC			
S1	VLAN 1			
PC-C	NIC			
PC-D	NIC			
S2	VLAN 1			
PC-E	NIC			
PC-F	NIC			
S3	VLAN 1			

# Part 4: Network Topology D

The network was modified to accommodate changes in the organization. The 192.168.10.0/24 network address is used to provide the addresses in the network.



#### Step 1: Determine the number of subnets in Network Topology D.

- a. How many subnets are there? \_\_\_\_\_
- b. How many bits should you borrow to create the required number of subnets?
- c. How many usable host addresses per subnet are in this addressing scheme? \_\_\_\_\_
- d. What is the new subnet mask in dotted decimal format?
- e. How many subnets are available for future use? \_\_\_\_\_

#### Step 2: Record the subnet information.

Fill in the following table with the subnet information.

Subnet Number	Subnet Address	First Usable Host Address	Last Usable Host Address	Broadcast Address
0				
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				

# Part 5: Network Topology E

The organization has a network address of 172.16.128.0/17 to be divided as illustrated in the following topology. You must choose an addressing scheme that can accommodate the number of networks and hosts in the topology.



#### Step 1: Determine the number of subnets in Network Topology E.

- a. How many subnets are there? \_\_\_\_\_
- b. How many bits should you borrow to create the required number of subnets?
- c. How many usable host addresses per subnet are in this addressing scheme? \_\_\_\_\_
- d. What is the new subnet mask in dotted decimal format?
- e. How many subnets are available for future use? \_\_\_\_\_

Fill in the following table with the subnet information:

Subnet Number	Subnet Address	First Usable Host Address	Last Usable Host Address	Broadcast Address
0				
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				

#### Step 3: Assign addresses to network devices in the subnets.

a. Fill in the following table with IP addresses and subnet masks for the router interfaces:

Device	Interface	IP Address	Subnet Mask
R1	GigabitEthernet 0/0		
	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		
R2	GigabitEthernet 0/0		
	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		
R3	GigabitEthernet 0/0		
	GigabitEthernet 0/1		
	Serial 0/0/0		
	Serial 0/0/1		

#### Reflection

- 1. What information is needed when determining an appropriate addressing scheme for a network?
- 2. After the subnets are assigned, will all the host addresses be utilized in each subnet?

# 9.4.1.10 Lab – Researching Subnet Calculators

#### **Objectives**

#### Part 1: Review Available Subnet Calculators

#### Part 2: Perform Network Calculations Using a Subnet Calculator

#### **Background / Scenario**

While it is important to understand how to convert a decimal IP address to its binary format and apply the bitwise ANDing operation to determine the network address, it is also a tedious and mistake-prone process. To assist with these calculations, many network administrators make use of an IP subnet calculator utility program. A number of these types of programs have been developed that can be downloaded or run directly from the Internet.

In this lab, you will be introduced to a few of the free IP subnet calculators that are available. You will use a web-based IP subnet calculator to perform the network operations in this lab.

#### **Required Resources**

Device with Internet access

### Part 1: Review Available Subnet Calculators

In Part 1, you are introduced to two types of subnet calculators: client-based (programs that are downloaded and installed) and web-based (utilities that are run from a browser).

#### Step 1: Review client-based subnet calculators.

Solarwinds provides a free subnet calculator that can be downloaded and installed on a PC running a Windows operating system. You will be required to provide personal information (Name, Company, Location, Email Address, and Phone number) to be able to download this program. You can download and install the Solarwinds Subnet Calculator at <a href="http://www.solarwinds.com">www.solarwinds.com</a>.

If you have a PC running Linux, it is recommended that you use the **ipcalc** utility (available with most Linux distributions). Use the **apt-get install ipcalc** command to install ipcalc on a PC running Linux.

#### Step 2: Use a web-based subnet calculator.

Web-based subnet calculators do not require installation, but you do need Internet access to use them. The following web-based subnet calculator is accessible from any device that has Internet access, including smartphones and tablets.

a. From your browser, go to <u>www.ipcalc.org</u> and click the **IP Subnet Calculator** link.

**Note**: Several other useful utilities are also listed on the menu, such as MAC vendor lookup, whois lookup, and DNS lookup.

**Note**: At the time of this writing, a page formatting issue was encountered when viewing the <u>www.ipcalc.org</u> website using Internet Explorer (Version 9). While the site functioned correctly, you may want to consider using another browser (Firefox or Chrome) when accessing this site.



b. On the IP Subnet Calculator screen, enter an IP address and subnet mask or an IP address and CIDR prefix notation. Examples of how to enter each of these are shown in the Introduction area.

IP Subnet Calculator				
y visible subdivision of subnetting.	an IP network. The practice of	of dividing a network into		
Ip you to compute inform	nation about IP subnetting. It's	easy to use.		
ou can enter differents a	address format:			
Description Format				
IP & CIDR Netmask	10.0.0.1/22	1		
IP & Netmask	10.0.0.1 255.255.252.0	1		
IP & Wildcard Mask	10.0.0.1 0.0.3.255	1		
IP & Windcard Mask       IP 0.0.1 0.0.3.233         The behavior of this application is the same that the <i>ipcalc</i> binary of GNU/Linux system's !         Application:         Enter IP & Mask or CIDR here !         Calc1				
	y visible subdivision of subnetting. up you to compute inform you can enter differents a <u>Description</u> IP & CIDR Netmask IP & Netmask IP & Wildcard Mask pplication is the same the <u>Enter IP &amp; Mask</u>	IP Subnet Calculator ::         y visible subdivision of an IP network. The practice of subnetting.         subnetting.         sup you to compute information about IP subnetting. It's you can enter differents address format:         Description         Format         IP & CIDR Netmask         10.0.0.1/22         IP & Wildcard Mask         10.0.0.1 0.0.3.255         pplication is the same that the <i>ipcalc</i> binary of GNU/Linu         Enter IP & Mask or CIDR here !         Calc !		

c. In the Application field, enter **192.168.50.50/27** and click **Calc!**. The next screen displays a table with network information in both decimal and binary formats.

#### Application:

192.168.50.50/		27 Calc!	
Description	Value		Extra
Address	192.168.50.50	11000000.10101000.00110010.00110010	
Netmask	255.255.255.224	11111111.11111111.11111111.11100000	/27
Network	192.168.50.32	11000000.10101000.00110010.00100000	
Broadcast	192.168.50.63		
Host min	192.168.50.33	11000000.10101000.00110010.00100001	
Host max	192.168.50.62	11000000.10101000.00110010.00111110	
Host/net	30	Class C, Private Internet	

d. Using the information provided in the example above, answer the following questions.

_

# Part 2: Perform Network Calculations Using a Subnet Calculator

In Part 2, use the <u>www.ipcalc.org</u> web-based subnet calculator to fill in the tables provided.

#### Step 1: Fill in the following table for address 10.223.23.136/10:

Description	Decimal	Binary
Address	10.223.23.136	
Subnet mask		
Network address		
Broadcast address		
First host address		
Last host address		
Number of hosts available		N/A

What type of address, public, or private? \_\_\_\_\_

# Step 2: Fill in the following table for the 172.18.255.92 address with a subnet mask of 255.255.224.0:

Description	Decimal	Binary
Address	172.18.255.92	
Subnet mask	255.255.224.0	
Network address		
Broadcast address		
First host address		
Last host address		
Number of hosts available		N/A

What is the CIDR prefix notation for this network?

What type of address, public, or private? \_\_\_\_\_

# Step 3: Fill in the following table using the 192.168.184.78 address with a subnet mask of 255.255.255.252:

Description	Decimal	Binary	
Address	192.168.184.78		
Subnet mask			
Network address			
Broadcast address			
First host address			
Last host address			
Number of hosts available		N/A	
What is the CIDR prefix notation for this network?			

What type of address, public, or private? \_\_\_\_\_

Where would you most likely find a network like this being used?

#### Step 4: Fill in the following table for the 209.165.200.225/27 address:

Description	Decimal	Binary
Address	209.165.200.225	
Subnet mask		
Network address		
Broadcast address		
First host address		
Last host address		
Number of hosts available		N/A

What type of address, public, or private? \_\_\_\_\_

#### Step 5: Fill in the following table for address 64.104.110.7/20:

Description	Decimal	Binary
Address	64.104.110.7	
Subnet mask		
Network address		
Broadcast address		
First host address		
Last host address		
Number of hosts available		N/A

What type of address, public, or private? \_\_\_\_\_

#### Reflection

- 1. What is an advantage of using a client-based subnet calculator?
- 2. What is an advantage of using a web-based subnet calculator?

# 9.2.1.3 Lab - Designing and Implementing a Subnetted IPv4 Addressing Scheme

Topology



#### Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/0			N/A
	G0/1			N/A
	Lo0			N/A
	Lo1			N/A
S1	VLAN 1	N/A	N/A	N/A
PC-A	NIC			
PC-B	NIC			

#### **Objectives**

#### Part 1: Design a Network Subnetting Scheme

- Create a subnetting scheme that meets the required number of subnets and host addresses.
- Complete the diagram, showing where the host IP addresses will be applied.

#### Part 2: Configure the Devices

- Assign an IP address, subnet mask, and default gateway to the PCs.
- Configure the router Gigabit Ethernet interfaces with an IP address and subnet mask.
- Create two loopback interfaces on the router, and configure each with an IP address and subnet mask.

#### Part 3: Test and Troubleshoot the Network

• Verify and troubleshoot network connectivity using ping.

#### **Background / Scenario**

In this lab, starting from a single network address and network mask, you will subnet the network into multiple subnets. The subnet scheme should be based on the number of host computers required in each subnet, as well as other network considerations, like future network host expansion.

After you have created a subnetting scheme and completed the network diagram by filling in the host and interface IP addresses, you will configure the host PCs and router interfaces, including loopback interfaces. The loopback interfaces are created to simulate additional LANs attached to router R1.

After the network devices and host PCs have been configured, you will use the **ping** command to test for network connectivity.

This lab provides minimal assistance with the actual commands necessary to configure the router. However, the required commands are provided in Appendix A. Test your knowledge by trying to configure the devices without referring to the appendix.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at this end of the lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 2 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

**Note**: The Gigabit Ethernet interfaces on Cisco 1941 routers are autosensing. An Ethernet straight-through cable may be used between the router and PC-B. If using another Cisco router model, it may be necessary to use an Ethernet crossover cable.

# Part 1: Design a Network Subnetting Scheme

# Step 1: Create a subnetting scheme that meets the required number of subnets and required number of host addresses.

In this scenario, you are a network administrator for a small subdivision within a larger company. You must create multiple subnets out of the 192.168.0.0/24 network address space to meet the following requirements:

- The first subnet is the employee network. You need a minimum of 25 host IP addresses.
- The second subnet is the administration network. You need a minimum of 10 IP addresses.
- The third and fourth subnets are reserved as virtual networks on virtual router interfaces, loopback 0 and loopback 1. These virtual router interfaces simulate LANs attached to R1.
- You also need two additional unused subnets for future network expansion.

Note: Variable length subnet masks will not be used. All of the device subnet masks will be the same length.

Answer the following questions to help create a subnetting scheme that meets the stated network requirements:

- 1) How many host addresses are needed in the largest required subnet?
- 2) What is the minimum number of subnets required?

- 3) The network that you are tasked to subnet is 192.168.0.0/24. What is the /24 subnet mask in binary?
- 4) The subnet mask is made up of two portions, the network portion, and the host portion. This is represented in the binary by the ones and the zeros in the subnet mask.

In the network mask, what do the ones represent? \_\_\_\_\_\_

In the network mask, what do the zeros represent?

5) To subnet a network, bits from the host portion of the original network mask are changed into subnet bits. The number of subnet bits defines the number of subnets. Given each of the possible subnet masks depicted in the following binary format, how many subnets and how many hosts are created in each example?

**Hint**: Remember that the number of host bits (to the power of 2) defines the number of hosts per subnet (minus 2), and the number of subnet bits (to the power of two) defines the number of subnets. The subnet bits (depicted in bold type face) are the bits that have been borrowed beyond the original network mask of /24. The /24 is the slash prefix notation and corresponds to a dotted decimal mask of 255.255.255.0.

#### 

Dotted decimal subnet mask equivalent: \_\_\_\_\_

Number of subnets? \_\_\_\_\_\_, Number of hosts? \_\_\_\_\_\_

Dotted decimal subnet mask equivalent: \_\_\_\_\_

Number of subnets? \_\_\_\_\_\_, Number of hosts? \_\_\_\_\_

#### 

Dotted decimal subnet mask equivalent: \_\_\_\_\_

Number of subnets? \_\_\_\_\_ Number of hosts? \_\_\_\_\_

Dotted decimal subnet mask equivalent:

Number of subnets? \_\_\_\_\_ Number of hosts? \_\_\_\_\_

#### 

Dotted decimal subnet mask equivalent: \_\_\_\_\_

Number of subnets? \_\_\_\_\_ Number of hosts? \_\_\_\_\_

Dotted decimal subnet mask equivalent: \_\_\_\_\_

Number of subnets? \_\_\_\_\_ Number of hosts? \_\_\_\_\_

- 6) Considering your answers, which subnet masks meet the required number of minimum host addresses?
- 7) Considering your answers, which subnet masks meets the minimum number of subnets required?

- 8) Considering your answers, which subnet mask meets both the required minimum number of hosts and the minimum number of subnets required?
- 9) When you have determined which subnet mask meets all of the stated network requirements, you will derive each of the subnets starting from the original network address. List the subnets from first to last below. Remember that the first subnet is 192.168.0.0 with the newly acquired subnet mask.

Subnet Address	1	Prefix	Subnet Mask (dotted decimal)
	/		
	1		
	,		
	/		
	/		
	/		
	/		
	1		
	,		
	/		
	/		

#### Step 2: Complete the diagram showing where the host IP addresses will be applied.

On the following lines provided, fill in the IP addresses and subnets masks in slash prefix notation. On the router, use the first usable address in each subnet for each of the interfaces, Gigabit Ethernet 0/0, Gigabit Ethernet 0/1, loopback 0, and loopback 1. Fill in an IP address for both PC-A and PC-B. Also enter this information into the Addressing Table on Page 1.



# Part 2: Configure the Devices

In Part 2, set up the network topology and configure basic settings on the PCs and router, such as the router Gigabit Ethernet interface IP addresses, and the PC's IP addresses, subnet masks, and default gateways. Refer to the Addressing Table for device names and address information.

**Note**: Appendix A provides configuration details for the steps in Part 2. You should attempt to complete Part 2 prior to reviewing Appendix A.

#### Step 1: Configure the router.

- a. Enter into privileged EXEC mode and then global config mode.
- b. Assign the R1 as the hostname for the router.
- c. Configure both the G0/0 and G0/1 interfaces with IP addresses and subnet masks, and then enable them.
- d. Loopback interfaces are created to simulate additional LANs on R1 router. Configure the loopback interfaces with IP addresses and subnet masks. After they are created, loopback interfaces are enabled, by default. (To create the loopback addresses, enter the command interface loopback 0 at the global config mode)

Note: You can create additional loopbacks for testing with different addressing schemes, if desired.

e. Save the running configuration to the startup configuration file.

#### Step 2: Configure the PC interfaces.

- a. Configure the IP address, subnet mask, and default gateway settings on PC-A.
- b. Configure the IP address, subnet mask, and default gateway settings on PC-B.

#### Part 3: Test and Troubleshoot the Network

In Part 3, you will use the **ping** command to test network connectivity.

- a. Test to see if PC-A can communicate with its default gateway. From PC-A, open a command prompt and ping the IP address of the router Gigabit Ethernet 0/1 interface. Do you get a reply?
- b. Test to see if PC-B can communicate with its default gateway. From PC-B, open a command prompt and ping the IP address of the router Gigabit Ethernet 0/0 interface. Do you get a reply?
- c. Test to see if PC-A can communicate with PC-B. From PC-A, open a command prompt and ping the IP address of PC-B. Do you get a reply?
- d. If you answered "no" to any of the preceding questions, then you should go back and check all of your IP address and subnet mask configurations, and ensure that the default gateways have been correctly configured on PC-A and PC-B.
- e. If you verify that all of the settings are correct, and you can still not ping successfully, then there are a few additional factors that can block ICMP pings. On PC-A and PC-B within Windows, make sure that the Windows Firewall is turned off for the Work, Home, and Public networks.
- f. Experiment by purposely misconfiguring the gateway address on PC-A to 10.0.0.1. What happens when you try and ping from PC-B to PC-A? Do you receive a reply?

#### Reflection

- 1. Subnetting one larger network into multiple smaller subnetworks allows for greater flexibility and security in network design. However, what do you think some of the drawbacks are when the subnets are limited to being the same size?
- 2. Why do you think the gateway/router IP address is usually the first usable IP address in the network?

#### **Router Interface Summary Table**

Router Interface Summary					
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2	
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)	
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

#### **Appendix A: Configuration Details for Steps in Part 2**

#### Step 1: Configure the router.

a. Console into the router and enable privileged EXEC mode.

Router> **enable** Router#

b. Enter into configuration mode.

```
Router# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

c. Assign a device name to the router.

```
Router(config) # hostname R1
R1(config) #
```

d. Configure both the G0/0 and G0/1 interfaces with IP addresses and subnet masks, and enable them.

```
R1(config) # interface g0/0
R1(config-if) # ip address <ip address> <subnet mask>
R1(config-if) # no shutdown
R1(config-if) # interface g0/1
R1(config-if) # ip address <ip address> <subnet mask>
R1(config-if) # no shutdown
```

e. Loopback interfaces are created to simulate additional LANs off of router R1. Configure the loopback interfaces with IP addresses and subnet masks. When they are created, loopback interfaces are enabled, by default.

```
R1(config)# interface loopback 0
R1(config-if)# ip address <ip address> <subnet mask>
R1(config-if)# interface loopback 1
R1(config-if)# ip address <ip address> <subnet mask>
R1(config-if)# end
```

f. Save the running configuration to the startup configuration file.

```
R1# copy running-config startup-config
```

#### Step 2: Configure the PC interfaces.

a. Configure the IP address, subnet mask, and default gateway settings on PC-A.

eneral	
You can get IP settings assigr this capability. Otherwise, you for the appropriate IP setting	ned automatically if your network supports u need to ask your network administrator s.
Obtain an IP address au	tomatically
<ul> <li>Obtain an IP address au</li> <li>Ouse the following IP add</li> </ul>	tomatically ress:
<ul> <li>Obtain an IP address au</li> <li>Use the following IP add</li> <li>IP address:</li> </ul>	tomatically ress: 192 . 168 . 0 . 34
<ul> <li>Obtain an IP address au</li> <li>Ouse the following IP add IP address:</li> <li>Subnet mask:</li> </ul>	tomatically ress: 192 . 168 . 0 . 34 255 . 255 . 255 . 224

b. Configure the IP address, subnet mask, and default gateway settings on PC-B.



# 9.2.1.4 Lab – Designing and Implementing a VLSM Addressing Scheme

Topology



#### Objectives

- Part 1: Examine Network Requirements
- Part 2: Design the VLSM Address Scheme
- Part 3: Cable and Configure the IPv4 Network

#### Background / Scenario

Variable Length Subnet Mask (VLSM) was designed to avoid wasting IP addresses. With VLSM, a network is subnetted and then re-subnetted. This process can be repeated multiple times to create subnets of various sizes based on the number of hosts required in each subnet. Effective use of VLSM requires address planning.

In this lab, use the 172.16.128.0/17 network address to develop an address scheme for the network displayed in the topology diagram. VLSM is used to meet the IPv4 addressing requirements. After you have designed the VLSM address scheme, you will configure the interfaces on the routers with the appropriate IP address information.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). Other routers and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 3 routers (Cisco 1941 with Cisco IOS software, Release 15.2(4)M3 universal image or comparable)
- 1 PC (with terminal emulation program, such as Tera Term, to configure routers)

- Console cable to configure the Cisco IOS devices via the console ports
- Ethernet (optional) and serial cables, as shown in the topology
- Windows Calculator (optional)

## Part 1: Examine Network Requirements

In Part 1, you will examine the network requirements to develop a VLSM address scheme for the network displayed in the topology diagram using the 172.16.128.0/17 network address.

**Note**: You can use the Windows Calculator application and the <u>www.ipcalc.org</u> IP subnet calculator to help with your calculations.

#### Step 1: Determine how many host addresses and subnets are available.

How many host addresses are available in a /17 network? \_\_\_\_\_

What is the total number of host addresses needed in the topology diagram?

How many subnets are needed in the network topology? \_\_\_\_\_

#### Step 2: Determine the largest subnet.

What is the subnet description (e.g. BR1 G0/1 LAN or BR1-HQ WAN link)? \_\_\_\_\_

How many IP addresses are required in the largest subnet?

What subnet mask can support that many host addresses?

How many total host addresses can that subnet mask support? \_\_\_\_\_

Can you subnet the 172.16.128.0/17 network address to support this subnet? \_\_\_\_\_

What are the two network addresses that would result from this subnetting?

\_\_\_\_\_

Use the first network address for this subnet.

#### Step 3: Determine the second largest subnet.

What is the subnet description?

How many IP addresses are required for the second largest subnet?

What subnet mask can support that many host addresses?

How many total host addresses can that subnet mask support? \_\_\_\_\_ Can you subnet the remaining subnet again and still support this subnet? \_\_\_\_\_ What are the two network addresses that would result from this subnetting?

Use the first network address for this subnet.

\_\_\_\_\_

#### Step 4: Determine the next largest subnet.

What is the subnet description?

What subnet mask can support that many host addresses? How many total host addresses can that subnet mask support? Can you subnet the remaining subnet again and still support this subnet? What are the two network addresses that would result from this subnetting? Use the first network address for this subnet. Step 5: Determine the next largest subnet. What is the subnet description? \_\_\_\_ How many IP addresses are required for the next largest subnet? What subnet mask can support that many host addresses? How many total host addresses can that subnet mask support? \_\_\_\_ Can you subnet the remaining subnet again and still support this subnet? What are the two network addresses that would result from this subnetting? Use the first network address for this subnet. Step 6: Determine the next largest subnet. What is the subnet description? How many IP addresses are required for the next largest subnet? What subnet mask can support that many host addresses? How many total host addresses can that subnet mask support? Can you subnet the remaining subnet again and still support this subnet? \_\_\_\_ What are the two network addresses that would result from this subnetting? Use the first network address for this subnet. Step 7: Determine the next largest subnet. What is the subnet description? \_\_\_\_\_

How many IP addresses are required for the next largest subnet?

What subnet mask can support that many host addresses?

How many total host addresses can that subnet mask support? \_\_\_\_\_

Can you subnet the remaining subnet again and still support this subnet? \_\_\_\_

What are the two network addresses that would result from this subnetting?

\_\_\_\_\_

Use the first network address for this subnet.

#### Step 8: Determine the subnets needed to support the serial links.

How many host addresses are required for each serial subnet link? \_\_\_\_\_\_ What subnet mask can support that many host addresses?

- a. Continue subnetting the first subnet of each new subnet until you have four /30 subnets. Write the first three network addresses of these /30 subnets below.
- b. Enter the subnet descriptions for these three subnets below.

# Part 2: Design the VLSM Address Scheme

#### Step 1: Calculate the subnet information.

Use the information that you obtained in Part 1 to fill in the following table.

Subnet Description	Number of Hosts Needed	Network Address /CIDR	First Host Address	Broadcast Address
HQ G0/0	16,000			
HQ G0/1	8,000			
BR1 G0/1	4,000			
BR1 G0/0	2,000			
BR2 G0/1	1,000			
BR2 G0/0	500			
HQ S0/0/0 – BR1 S0/0/0	2			
HQ S0/0/1 – BR2 S0/0/1	2			
BR1 S0/0/1 – BR2 S0/0/0	2			

#### Step 2: Complete the device interface address table.

Assign the first host address in the subnet to the Ethernet interfaces. HQ should be given the first host address on the Serial links to BR1 and BR2. BR1 should be given the first host address for the serial link to BR2.

Device	Interface	IP Address	Subnet Mask	Device Interface
HQ	G0/0			16,000 Host LAN
	G0/1			8,000 Host LAN
	S0/0/0			BR1 S0/0/0
	S0/0/1			BR2 S0/0/1
BR1	G0/0			2,000 Host LAN
	G0/1			4,000 Host LAN
	S0/0/0			HQ S0/0/0
	S0/0/1			BR2 S0/0/0
	G0/0			500 Host LAN
BR2	G0/1			1,000 Host LAN
	S0/0/0			BR1 S0/0/1
	S0/0/1			HQ S0/0/1

# Part 3: Cable and Configure the IPv4 Network

In Part 3, you will cable the network topology and configure the three routers using the VLSM address scheme that you developed in Part 2.

#### Step 1: Cable the network as shown in the topology.

#### Step 2: Configure basic settings on each router.

- a. Assign the device name to the router.
- b. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were hostnames.
- c. Assign **class** as the privileged EXEC encrypted password.
- d. Assign **cisco** as the console password and enable login.
- e. Assign cisco as the VTY password and enable login.
- f. Encrypt the clear text passwords.
- g. Create a banner that will warn anyone accessing the device that unauthorized access is prohibited.

#### Step 3: Configure the interfaces on each router.

- a. Assign an IP address and subnet mask to each interface using the table that you completed in Part 2.
- b. Configure an interface description for each interface.
- c. Set the clocking rate on all DCE serial interfaces to 128000.
  - HQ(config-if) # clock rate 128000
- d. Activate the interfaces.

#### Step 4: Save the configuration on all devices.

#### Step 5: Test Connectivity.

- a. From HQ, ping BR1's S0/0/0 interface address.
- b. From HQ, ping BR2's S0/0/1 interface address.
- c. From BR1, ping BR2's S0/0/0 interface address.
- d. Troubleshoot connectivity issues if pings were not successful.

**Note:** Pings to the GigabitEthernet interfaces on other routers will not be successful. The LANs defined for the GigabitEthernet interfaces are simulated. Because no devices are attached to these LANs they will be in down/down state. A routing protocol needs to be in place for other devices to be aware of those subnets. The GigabitEthernet interfaces also need to be in an up/up state before a routing protocol can add the subnets to the routing table. These interfaces will remain in a down/down state until a device is connected to the other end of the Ethernet interface cable. The focus of this lab is on VLSM and configuring the interfaces.

#### Reflection

Can you think of a shortcut for calculating the network addresses of consecutive /30 subnets?

Router Interface Summary					
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2	
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)	
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)	

#### **Router Interface Summary Table**

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 9.4.1.1 Can you call me now?

#### **Objectives**

#### Calculate the necessary subnet mask to accommodate a given number of hosts.

Subnetting is hierarchical and can help deliver network traffic more easily if small groups of IP addresses are designed to serve network needs.

#### Background/Scenario

**Note:** This activity may be completed individually or in small or large groups using Packet Tracer software.

- You are setting up a dedicated, computer addressing scheme for patient rooms in a hospital. The switch will be centrally located in the nurses' station, as each of the five rooms will be wired so that patients can just connect to an RJ45 port built into the wall of their room. Devise a physical and logical topology for only one of the six floors using the following addressing scheme requirements: There are six floors with five patient rooms on each floor for a total of 30 connections. Each room needs a network connection.
- Subnetting must be incorporated into your scheme.
- Use one router, one switch, and five host stations for addressing purposes.
- Validate that all PCs can connect to the hospital's in-house services.

Keep a copy of your scheme to share later with the class or learning community. Be prepared to explain how subnetting, unicasts, multicasts, and broadcasts would be incorporated, and where your addressing scheme could be used.

#### **Required Resources**

Packet Tracer software

#### Reflection

1. How would you change your addressing scheme if you were going to add an additional network connection to the hospital rooms with a total of 10 connections per floor or 2 ports per room?

# 10.0.1.2 What would happen if...

#### **Objectives**

#### Explain the operation of the application layer in providing support to end-user applications.

In this activity, you will envision what it would be like not to have network applications available to use in the workplace. You may also estimate what it would cost to not be able to use networked applications for a short period of time.

#### Background/Scenario

It is the beginning of your work week. Your employer has decided to have IP telephones installed in your workplace resulting in the network being inoperable until next week. Your work, however, must continue. You have emails to send and quotes to write for your manager's approval. Because of possible security issues, you are not allowed to use personal or external computer systems, equipment, or offsite equipment and systems, to complete your corporate workload.

Your instructor may ask you to complete the questions from both scenarios below, or to choose one scenario (A. Emails or B. Quote for Manager's Approval). Answer the questions fully for the scenarios. Be prepared to discuss your answers in class.

#### A. Emails

- What methods can you use to send email communication?
- How could you send the same email to multiple recipients?
- How would you get a large attachment to multiple recipients, if necessary?
- Do they violate any security policies of your corporation? \_\_\_\_\_\_

#### B. Quote for Manager's Approval

- You have a desktop application software package installed on your computer. Will it be relatively easy to produce the quote your manager needs for the new contract due by the end of the week? What limitations will be experienced while trying to complete the quote?
- How will you present the quote to your manager for approval? How do you think your manager will send the quote to the client for approval?
- Are these methods cost effective to your corporation? Justify your answer.
## Reflection

1. What steps did you identify as important to communicating without network applications available to you for a week in your workplace? Which steps were not important? Justify your answer.

© 2013 Cisco and/or its affiliates. All rights reserved. This document is Cisco Public.

## 10.1.2.4 Lab - Researching Peer-to-Peer File Sharing

## **Objectives**

Part 1: Identify P2P Networks, File Sharing Protocols, and Applications

Part 2: Research P2P File Sharing Issues

Part 3: Research P2P Copyright Litigations

## **Background / Scenario**

Peer-to-peer (P2P) computing is a powerful technology that has many uses. P2P networks can be used to share and exchange music, movies, software, and other electronic materials.

The use of P2P networks to upload, download, or share copyrighted material, such as movies, music, and software, can violate the rights of copyright owners. In the P2P file-sharing context, infringement may occur, for example, when one person purchases an authorized copy and then uploads it to a P2P network to share with others. Both the individual who makes the file available and those making copies may be found to have infringed the rights of the copyright owners and may be violating copyright law.

Another problem with P2P file sharing is that very little protection is in place to ensure that the files exchanged in these networks are not malicious. P2P networks are an ideal medium for spreading malware (computer viruses, worms, Trojan horses, spyware, adware, and other malicious programs). In 2010, Cisco reported increases in P2P activity, coupled with recent P2P malware developments, suggesting that P2P file shares are becoming increasingly favored by users and malware attackers alike.

In this lab, you will research available P2P file sharing software and identify some issues that can arise from the use of this technology.

## **Required Resources**

Device with Internet access

## Part 1: Identify P2P Networks, File Sharing Protocols, and Applications

In Part 1, you will research P2P networks and identify some popular P2P protocols and applications.

#### Step 1: Define P2P networking.

- a. What is a P2P network?
- b. What are some advantages that P2P provides over client-server architecture?

c. What are some disadvantages of P2P networks?

Step 2: Identify P2P file sharing protocols and applications.

a. Identify some P2P file sharing protocols used today.

b. What are some popular P2P file sharing applications available today?

c. What P2P file sharing protocol is attributed to producing the most P2P traffic on the Internet today?

## Part 2: Research P2P File Sharing Issues

In Part 2, you will research P2P copyright infringement and identify other issues that can occur with P2P file sharing.

#### Step 1: Research P2P copyright infringement.

- a. What does the acronym DMCA stand for and what is it?
- b. Name two associations that actively pursue P2P copyright infringement?
- c. What are the penalties for copyright infringement?
- d. What are the file sharing copyright laws in your area? Are they more strict or less strict than those in other areas of the world? How aggressively do enforcement agencies in your area pursue those who share copyrighted material?

#### Step 2: Research other P2P issues.

- a. What types of malware can be transported through P2P file sharing?
- b. What is Torrent Poisoning?

c. How could identity theft occur through the use of P2P file sharing?

## Part 3: Research P2P Copyright Litigations

In Part 3, you will research and identify some historical legal actions that have occurred, as a result of P2P copyright infringement.

- a. What was the first well-known P2P application that specialized in MP3 file sharing and was shut down by court order?
- b. What was one of the largest P2P file sharing lawsuits ever?

### Reflection

1. How can you be sure that the files you are downloading from P2P networks are not copyrighted and are safe from malware?

## 10.2.2.9 Lab - Observing DNS Resolution

## **Objectives**

Part 1: Observe the DNS Conversion of a URL to an IP Address

Part 2: Observe DNS Lookup Using the Nslookup Command on a Web Site

Part 3: Observe DNS Lookup Using the Nslookup Command on Mail Servers

### **Background / Scenario**

The Domain Name System (DNS) is invoked when you type a Uniform Resource Locator (URL), such as <u>http://www.cisco.com</u>, into a web browser. The first part of the URL describes which protocol is used. Common protocols are Hypertext Transfer Protocol (HTTP), Hypertext Transfer Protocol over Secure Socket Layer (HTTPS), and File Transfer Protocol (FTP).

DNS uses the second part of the URL, which in this example is www.cisco.com. DNS translates the domain name (www.cisco.com) to an IP address to allow the source host to reach the destination host. In this lab, you will observe DNS in action and use the **nslookup** (name server lookup) command to obtain additional DNS information. Work with a partner to complete this lab.

### **Required Resources**

1 PC (Windows 7, Vista, or XP with Internet and command prompt access)

## Part 1: Observe the DNS Conversion of a URL to an IP Address

- a. Click the **Windows Start** button, type **cmd** into the search field, and press Enter. The command prompt window appears.
- b. At the command prompt, ping the URL for the Internet Corporation for Assigned Names and Numbers (ICANN) at www.icann.org. ICANN coordinates the DNS, IP addresses, top-level domain name system management, and root server system management functions. The computer must translate www.icann.org into an IP address to know where to send the Internet Control Message Protocol (ICMP) packets.
- c. The first line of the output displays www.icann.org converted to an IP address by DNS. You should be able to see the effect of DNS, even if your institution has a firewall that prevents pinging, or if the destination server has prevented you from pinging its web server.

C:\>ping www.icann.org Pinging www.vip.icann.org [192.0.32.7] with 32 bytes of data: Reply from 192.0.32.7: bytes=32 time=23ms TTL=246 Reply from 192.0.32.7: bytes=32 time=24ms TTL=246 Reply from 192.0.32.7: bytes=32 time=24ms TTL=246 Reply from 192.0.32.7: bytes=32 time=28ms TTL=246 Ping statistics for 192.0.32.7: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 23ms, Maximum = 28ms, Average = 24ms

Record the IP address of www.icann.org.

d. Type IP address from **step c** into a web browser, instead of the URL. Click **Continue to this website** (not recommended). to proceed.

	Arrow Certificate Error: Navigatio ×
8	There is a problem with this website's security certificate.
	The security certificate presented by this website was issued for a different website's address.
	Security certificate problems may indicate an attempt to fool you or intercept any data you send to the
	server.
	We recommend that you close this webpage and do not continue to this website.
	Click here to close this webpage.
	Scontinue to this website (not recommended).

e. Notice that the ICANN home web page is displayed.



Most humans find it easier to remember words, rather than numbers. If you tell someone to go to **www.icann.org**, they can probably remember that. If you told them to go to 192.0.32.7, they would have a difficult time remembering an IP address. Computers process in numbers. DNS is the process of translating words into numbers. There is a second translation that takes place. Humans think in Base 10 numbers. Computers process in Base 2 numbers. The Base 10 IP address 192.0.32.7 in Base 2 numbers is 11000000.0000000.00100000.00000111. What happens if you cut and paste these Base 2 numbers into a browser?

f. Now type ping <u>www.cisco.com</u>.

```
C:\>ping www.cisco.com
Pinging e144.dscb.akamaiedge.net [23.1.144.170] with 32 bytes of data:
Reply from 23.1.144.170: bytes=32 time=51ms TTL=58
Reply from 23.1.144.170: bytes=32 time=50ms TTL=58
Reply from 23.1.144.170: bytes=32 time=50ms TTL=58
Reply from 23.1.144.170: bytes=32 time=50ms TTL=58
Ping statistics for 23.1.144.170:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 50ms, Maximum = 51ms, Average = 50ms
```

- g. When you ping www.cisco.com, do you get the same IP address as the example, or a different IP address, and why?
- h. Type the IP address that you obtained when you pinged www.cisco.com into a browser. Does the web site dlsplay? Explain.

## Part 2: Observe DNS Lookup Using the Nslookup Command on a Web Site

a. At the command prompt, type the **nslookup** command.

```
C:\>nslookup
Default Server: dslrouter.westell.com
Address: 192.168.1.1
>
```

What is the default DNS server used? \_\_\_\_\_

Notice how the command prompt changed to a greater than (>) symbol. This is the **nslookup** prompt. From this prompt, you can enter commands related to DNS.

At the prompt, type ? to see a list of all the available commands that you can use in **nslookup** mode.

b. At the **nslookup** prompt, type **www.cisco.com**.

```
> www.cisco.com
Server: dslrouter.westell.com
Address: 192.168.1.1
Non-authoritative answer:
Name: e144.dscb.akamaiedge.net
Addresses: 2600:1408:7:1:9300::90
2600:1408:7:1:8000::90
2600:1408:7:1:9800::90
23.1.144.170
Aliases: www.cisco.com
www.cisco.com.akadns.net
wwwds.cisco.com.edgekey.net
wwwds.cisco.com.edgekey.net.globalredir.akadns.net
```

What is the translated IP address? \_\_\_\_\_

Is it the same as the IP address shown with the ping command? \_\_\_\_

Under addresses, in addition to the 23.1.144.170 IP address, there are the following numbers: 2600:1408:7:1:9300::90, 2600:1408:7:1:8000::90, 2600:1408:7:1:9800::90. What are these?

c. At the prompt, type the IP address of the Cisco web server that you just found. You can use **nslookup** to get the domain name of an IP address if you do not know the URL.

```
> 23.1.144.170
Server: dslrouter.westell.com
Address: 192.168.1.1
Name: a23-1-144-170.deploy.akamaitechnologies.com
Address: 23.1.144.170
```

You can use the **nslookup** tool to translate domain names into IP addresses. You can also use it to translate IP addresses into domain names.

Using the nslookup tool, record the IP addresses associated with www.google.com.

```
> www.google.com
Server: dslrouter.westell.com
Address: 192.168.1.1
Non-authoritative answer:
Name: www.google.com
Addresses: 2607:f8b0:400c:c01::93
173.194.75.147
173.194.75.105
173.194.75.99
173.194.75.103
173.194.75.106
173.194.75.104
```

# Part 3: Observe DNS Lookup Using the Nslookup Command on Mail Servers

a. At the prompt, type **set type=mx** to use **nslookup** to identify mail servers.

> set type=mx

b. At the prompt, type **cisco.com**.

```
cisco.com
Server: dslrouter.westell.com
Address: 192.168.1.1
Non-authoritative answer:
                MX preference = 10, mail exchanger = rcdn-mx-01.cisco.com
cisco.com
cisco.com
               MX preference = 15, mail exchanger = alln-mx-01.cisco.com
cisco.com
               MX preference = 15, mail exchanger = ams-mx-01.cisco.com
cisco.com
               MX preference = 15, mail exchanger = rtp-mx-01.cisco.com
                        internet address = 64.103.36.169
ams-mx-01.cisco.com
cdn-mx-01.cisco.com
                        internet address = 72.163.7.166
```

A fundamental principle of network design is redundancy (more than one mail server is configured). In this way, if one of the mail servers is unreachable, then the computer making the query tries the second mail server. Email administrators determine which mail server is contacted first using **MX preference** (see above image). The mail server with the lowest **MX preference** is contacted first. Based upon the output above, which mail server will be contacted first when email is being sent to cisco.com?

- c. At the nslookup prompt, type exit to return to the regular PC command prompt.
- d. At the PC command prompt, type **ipconfig /all**.
- e. Write the IP addresses of all the DNS servers that your school uses.

#### Reflection

What is the fundamental purpose of DNS?

## 10.2.3.3 Lab - Exploring FTP

## **Objectives**

Part 1: Use FTP from a Command Prompt

Part 2: Download an FTP File Using WS\_FTP LE

Part 3: Use FTP in a Browser

### **Background / Scenario**

The File Transfer Protocol (FTP) is part of the TCP/IP suite. FTP is used to transfer files from one network device to another network device. Windows includes an FTP client application that you can execute from the command prompt. There are also free graphical user interface (GUI) versions of FTP that you can download. The GUI versions are easier to use than typing from a command prompt. FTP is frequently used for the transfer of files that may be too large for attachment with an email.

When using FTP, one computer is normally the server and the other computer is the client. When accessing the server from the client, you need to provide a username and password. Some FTP servers have a user named **anonymous**. You can access these types of sites by simply typing "anonymous" for the user, without a password. Usually, the site administrator has files that can be copied but does not allow files to be posted with the anonymous user.

In this lab, you will learn how to use anonymous FTP from the Windows command-line C:\> prompt. You will also use the GUI-based FTP program, WS\_FTP LE. Finally, you will use an anonymous FTP in a browser.

#### **Required Resources**

1 PC (Windows 7, Vista, or XP with access to the command prompt and Internet access and WS\_FTP LE installed)

## Part 1: Use FTP from a Command Prompt

- a. Click the **Windows Start** button, type **cmd** in the search field, and press Enter to open a command window.
- b. At the C:\> prompt type ftp ftp.cdc.gov. At the prompt that says User (ftp.cdc.gov:(none)): type anonymous. For the password, do not type anything. Press Enter to be logged in as an anonymous user.

```
Microsoft Windows [Version 6.1.7600]
Copyright <c> 2009 Microsoft Corporation. All rights reserved.
C:\Users\User1>ftp ftp.cdc.gov
Connected to ftp.cdc.gov.
220 Microsoft FTP Service
User <ftp.cdc.gov:<none>>: anonymous
331 Anonymous access allowed, send identity <e-mail name> as password.
Password:
230 Anonymous user logged in.
ftp>______
```

Notice that the  $c: \$  prompt has been replaced with the ftp> prompt. Type **Is** to list the files and directories. At the time that this lab was authored, there was a Readme file.

ftp> ls			
200 PORT command successful.			
150 Opening ASCII mode data connection .	for	file	list.
aspnet_client			
քսե			
Readme			

c. At the prompt, type **get Readme**. This downloads the file to your local computer from the anonymous FTP server that the Center for Disease Control has setup. The file will be copied into the directory shown in the C:\> prompt (C:\Users\User1 in this case).



d. Type quit to leave FTP and return to the C:\> prompt. Type more Readme to see the contents of the document.

ftp) guit
221
C:\Users\User1>more Readme
Welcome to the Centers for Disease Control and Prevention and Agency for Toxic Substances and Disease Registry FTP server. Information maintained on this server is in the public domain and is available at anytime for your use. CDC/ATSDR requests that you provide a valid e-mail address when responding to the FTP server's password prompt.
FTP POLICY
CDC/ATSDR's file structure is designed to make information easily accessible for faster response. All FTP directories and sub-directories should contain the following files:
README.TXT Contains general information and Disclaimer text. (ASCII)

e. What is a drawback of using the FTP from the command line?

## Part 2: Download an FTP File Using WS\_FTP LE

In Part 2, you will download a file using WS\_FTP LE (a free FTP transfer tool).

a. Start **WS\_FTP LE**. If the Ipswitch WS\_FTP LE window displays, click **Next** to continue and skip to step c. Otherwise, click the **Open a Remote Connection** link.



b. Click Create Site....

🕒 Site Manager 🗾 💌		
🕌 Sites	<u>C</u> onnect	
	Create Site	
	Create <u>F</u> older	
	<u>E</u> dit	
	<u>R</u> ename	
	Delete	
	Close	
	Help	
, Sites		

c. In the Site Name field, type Center for Disease Control and click Next to continue.

Connection Wizard		
	Site Name The Site Name is a label that helps you identify this site in the future. For Example: • My Auction Site • My Personal Web Site This name will appear when you click Connect at the top left.	
	< Back Next > Cancel	

d. Click the **Connection Type** drop-down list, select **FTP** (the default connection type), and click **Next**.

Connection Wizard		×
FTP	Connection Type WS_FTP allows you to connect to different types of servers. NOTE: If the information provided by your ISP or server administrator does not mention the server type, select FTP. More About Connection Types	*
	Connection Type: FTP	
	< Back Next > Cance	el 📄

e. In the Server Address field, type <u>ftp.cdc.gov</u>, and click Next.

Connection Wizard		<b>-X</b>
	Server Address	^
	Every FTP server has a unique address known as the Server Address or Host Address.	
	For Example: • mywebpages.comcast.net • ftp.hometown.aol.com	
	Enter the server address provided by your Internet Service Provider (ISP) or your FTP server administrator.	-
	J Server Address:	
	np.cdc.gov	
	< <u>B</u> ack <u>N</u> ext > Canc	el

f. In the User Name field, type anonymous, and leave the password field blank. Click Next.

🧬 Connection Wizard 📃 🔀		
	User Name and Password FTP servers require a user name and password. Enter the user name and password provided by your Internet Service Provider (ISP) or the FTP server administrator. NOTE: Entering a password below is not required. If you choose to enter a password, WS_FTP will safely save that password for future connections to this site.	
	User Name: anonymous	
	Password:	
	< <u>B</u> ack <u>N</u> ext > Cancel	

g. Click Finish.



h. When the Login Information Missing dialog box displays, click **OK**. Do not type a password in the **Password** field.

🔐 Login	×		
Login Information Missing         WS_FTP needs login information in order to start the connection process. Enter the missing login information below.         Enable the Save login information option to update and save your site login information.			
, ∐serName			
anonymous			
Password			
✓ Save login information			
OK Cancel			

i. You are now anonymously connected to the Center for Disease Control FTP site.



- j. On the WS\_FTP LE toolbar menu under My Computer, click **New Folder** to create a folder on your local **C:\** drive.
- k. In the Make Directory dialog box name the folder as CDC and click OK.

**Note:** If the folder already exists, you can use the same folder or create another folder with a different name. If using the same CDC folder, you can replace the existing Readme file with the downloaded Readme file.

G Make directory	×
Create Directory	*
Enter a name for the new directory.	
	÷
CDC	
OK Cancel Help	

I. After the directory is created, in the My Computer tab page, double-click the directory to open it.

Ipswitch WS_FTP LE					
<sup>:</sup> <u>C</u> onnections <u>V</u> iew <u>T</u> ools <u>H</u> elp					
Connect Disconnect Options Views	;				
Address ftp://ftp.cdc.gov/		anonymous <u>P</u> asswor	d ••••	••••	Connect to
My Computer 4 b ×		Center for Disease Contr	ol		4
↓ c:\ Up Folders ;		📴 / 🚽 🔮 Up	ැ Folders	Cancel	Transfer Mod
Browse New Folder View Edit Execute file Refresh ;		Browse New Folder Vie	w Edit	Execute	file Refresh
Name Size Type Modified		Name	Size	Type 1	Modified
File f         1/7/2011 9:45 AM         E           0 0cf87a29bbe07         File f         1/26/2011 2:19           Apache-Subver         File f         12/6/2011 1:2	Ð	aspnet_client pub w3c		Folder 2 Folder 2 Folder 9	2/15/2012 9:4( 2/26/2013 10:1 5/19/2010 11:4
Apache-Subver File f 6/4/2012 2:06 PM		🔊 .change.dir	128	DIR 9	5/8/1995 11:0(
Apps     File f 12/14/2010 1:3		🛤 .message	107	MES 9	5/8/1995 11:00
Ele f		Siteinfo	1 NB 202	Binar S	571371999113 571371999113
cygwin File f 2/18/2011 12:1 ←		ing up.htm	0	Firef	5/17/2005 6:52

m. Drag the file **Readme** from the right side of the application (the remote CDC FTP server) into the CDC folder on to the local C:\ drive.

Ipswitch WS_FTP LE			
<sup>;</sup> <u>C</u> onnections <u>V</u> iew <u>T</u> ools <u>H</u> elp			
Connect Disconnect Options Views	rch 👳		
Address ftp://ftp.cdc.gov/		ID anonymous <u>P</u> assword ••••••• Connect to URL <del>,</del>	
My Computer 4	$\triangleright$ ×	Center for Disease Control	
🕞 c:\CDC 💽 🧐 🌍 Up Folde	ers 👳	Up Folders Cancel Transfer Mode	
Browse New Folder View Edit Execute file Refres	h ╤	Browse New Folder View Edit Execute file Refresh	
Name Size Type Modified	Att 🖉	Name Size Type Modified	
Readme 1 KB Binar 2/26/2013 3:01	. A 🔮	Jeaspnet_client         Folder         2/15/2012 9:40           µub         Folder         2/26/2013 10:1           ₩3c         Folder         5/19/2010 11:4           ▲.change.dir         128         DIR         5/8/1995 11:00           ▲.message         107         MES         5/8/1995 11:00           ■.message         107         MES         5/13/1999 11:50           ■.message         1 KB         Binar         5/13/1999 11:5	
		up.htm 0 Firef 5/17/2005 6:52 👻	
	- F		
1 object(s) - 1 KB			

n. Double-click the **Readme** file in the C:\CDC folder on your local C:\ drive. If prompted for an application to open the document, choose any word processing software. You should see a message that looks something like this:

Welcome to the Centers for Disease Control and Prevention and Agency for Toxic Substances and Disease Registry FTP server. Information maintained on this server is in the public domain and is available at anytime for your use.

- Which was easier, using FTP from the cmd prompt, or using WS\_FTP LE? \_\_\_\_
- p. Click **Disconnect** to disconnect from the <u>ftp.cdc.gov</u> site when finished.
- q. The remote site will be removed from the saved list of FTP sites. In the Ipswitch WS\_FTP LE window, click the Open a Remote Connection link. Select the Center for Disease Control site, and click Delete to remove the FTP site. Click Yes to confirm the deletion. Click Close to exit the Site Manager.
- r. Remove the C:\CDC folder.

## Part 3: Use FTP in a Browser

It is possible to use a browser as an anonymous FTP client.

a. In a browser, type <u>ftp://ftp.cdc.gov/</u>.



b. Click the Readme file.



Welcome to the Centers for Disease Control and Prevention and Agency for Toxic Substances and Disease Registry FTP server. Information maintained on this server is in the public domain and is available at anytime for your use. CDC/ATSDR requests that you provide a valid e-mail address when responding to the FTP server's password prompt.

#### Reflection

- 1. Which FTP method was easiest to use?
- 2. Was there any advantage to using FTP from the command prompt or using WS\_FTP LE?

## 10.4.1.1 Make it happen!

## **Objectives**

#### Explain the operation of the application layer in providing support to end-user applications.

In this activity, you will apply new knowledge of application layer protocols and methods of the TCP/IP layer in streamlining data/network communication.

### Background/Scenario

Refer to the modeling activity from the beginning of this chapter as the basis for this activity.

Your IP telephones were installed in a half day vs. the full week originally anticipated. Your network has been restored to full capacity and network applications are available for your use. You have the same emails to answer and quotes to write for your manager's approval.

Use the same scenario you completed in the introduction modeling activity to answer the following questions:

#### A. Emails

- What methods can you use to send email correspondence now that the network is working?
- How can you now send the same message to multiple recipients?
- How can you send the large attachments to multiple recipients using network applications?
- Would using network applications prove to be a cost-effective communication method for your corporation?

#### B. Quote for Manager's Approval

- Because you have desktop application programs installed on your computer, will it be relatively easy to produce the quote your manager needs for the new contract due by the end of the week? Explain your answer.
- When you finish writing the quote, how will you present it to your manager for approval? How will your manager send the quote to the client for approval?
- Is using network applications a cost-effective way to complete business transactions? Justify your answer.
- Save a hard copy or an electronic copy of your answers. Be prepared to discuss your answers in class.

## Reflection

1. Having network applications and services available to you may increase production, decrease costs, and save time. Would this be true with the scenario you chose? Justify your answer.

© 2013 Cisco and/or its affiliates. All rights reserved. This document is Cisco Public.

## 11.0.1.2 Did you notice ...?

## **Objectives**

#### Explain how a small network of directly connected segments is created, configured and verified.

In this activity, you will note how networks differ, both in size and in function. You will identify how networks provide different networking solutions based upon their cost, speed, ports, expandability, and manageability, related to the needs of a small-to-medium-sized business.

## Topology



#### Background/Scenario

Using the two networks in the topology diagram as reference, answer the following questions and record your answers to share with the class.

- Visually compare and contrast Network A and Network B. How are the two networks the same?
- Make note of the devices used in <u>each</u> network design. Because the devices are labeled, you already know what types of end and intermediary devices they are. How are the two networks different? Is the number of devices present in one network the only differentiating factor? Justify your answer.
- Which network you would select if you owned a small-to-medium-sized business. Justify your selected network based on cost, speed, ports, expandability, and manageability.

#### **Required Resources**

Recording capabilities (paper, tablet, etc.) for reflective comments to be shared with the class.

### Reflection

1. Reflect upon your comparisons of the two network scenarios. What are some things you noted as points of interest?

Identify elements of the model that map to real-world content:

Cost, speed, ports, expandability, and manageability are all factors to consider when designing a small to medium-sized network.

## 11.2.2.6 Lab – Researching Network Security Threats

## **Objectives**

#### Part 1: Explore the SANS Website

• Navigate to the SANS website and identify resources.

#### Part 2: Identify Recent Network Security Threats

- Identify several recent network security threats using the SANS site.
- Identify sites beyond SANS that provide network security threat information.

#### Part 3: Detail a Specific Network Security Threat

- Select and detail a specific recent network threat.
- Present information to the class.

## **Background / Scenario**

To defend a network against attacks, an administrator must identify external threats that pose a danger to the network. Security websites can be used to identify emerging threats and provide mitigation options for defending a network.

One of the most popular and trusted sites for defending against computer and network security threats is SysAdmin, Audit, Network, Security (SANS). The SANS site provides multiple resources, including a list of the top 20 Critical Security Controls for Effective Cyber Defense and the weekly @Risk: The Consensus Security Alert newsletter. This newsletter details new network attacks and vulnerabilities.

In this lab, you will navigate to and explore the SANS site, use the SANS site to identify recent network security threats, research other websites that identify threats, and research and present the details about a specific network attack.

## **Required Resources**

- Device with Internet access
- Presentation computer with PowerPoint or other presentation software installed

## Part 1: Exploring the SANS Website

In Part 1, navigate to the SANS website and explore the available resources.

#### Step 1: Locate SANS resources.

Using a web browser, navigate to <u>www.SANS.org</u>. From the home page, highlight the **Resources** menu.

List three available resources.

## Step 2: Locate the Top 20 Critical Controls.

The **Twenty Critical Security Controls for Effective Cyber Defense** listed on the SANS website are the culmination of a public-private partnership involving the Department of Defense (DoD), National Security Association, Center for Internet Security (CIS), and the SANS Institute. The list was developed to prioritize the

cyber security controls and spending for DoD. It has become the centerpiece for effective security programs for the United States government. From the **Resources** menu, select **Top 20 Critical Controls**.

Select one of the 20 Critical Controls and list three of the implementation suggestions for this control.

#### Step 3: Locate the Newsletters menu.

Highlight the **Resources** menu, select **Newsletters**. Briefly describe each of the three newsletters available.

## Part 2: Identify Recent Network Security Threats

In Part 2, you will research recent network security threats using the SANS site and identify other sites containing security threat information.

#### Step 1: Locate the @Risk: Consensus Security Alert Newsletter Archive.

From the **Newsletters** page, select **Archive** for the @RISK: The Consensus Security Alert. Scroll down to **Archives Volumes** and select a recent weekly newsletter. Review the **Notable Recent Security Issues and Most Popular Malware Files** sections.

List some recent attacks. Browse multiple recent newsletters, if necessary.

#### Step 2: Identify sites providing recent security threat information.

Besides the SANS site, identify some other websites that provide recent security threat information.

List some of the recent security threats detailed on these websites.

## Part 3: Detail a Specific Network Security Attack

In Part 3, you will research a specific network attack that has occurred and create a presentation based on your findings. Complete the form below based on your findings.

#### Step 1: Complete the following form for the selected network attack.

Name of attack:	
Type of attack:	
Dates of attacks:	
Computers / Organizations affected:	
How it works and what it did:	
Mitigation options:	
Deferences and infe links	
References and info links:	

Step 2: Follow the instructor's guidelines to complete the presentation.

## Reflection

- 1. What steps can you take to protect your own computer?
- 2. What are some important steps that organizations can take to protect their resources?

## 11.2.4.5 Lab - Accessing Network Devices with SSH

## Topology



## Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## **Objectives**

Part 1: Configure Basic Device Settings

Part 2: Configure the Router for SSH Access

Part 3: Examine a Telnet Session with Wireshark

Part 4: Examine a SSH Session with Wireshark

Part 5: Configure the Switch for SSH Access

Part 6: SSH from the CLI on the Switch

## **Background / Scenario**

In the past, Telnet was the most common network protocol used to remotely configure network devices. However, protocols such as Telnet do not authenticate or encrypt the information between the client and server. This allows a network sniffer to intercept passwords and configuration information.

Secure Shell (SSH) is a network protocol that establishes a secure terminal emulation connection to a router or other networking device. SSH encrypts all information that passes over the network link and provides authentication of the remote computer. SSH is rapidly replacing Telnet as the remote login tool of choice for network professionals. SSH is most often used to log in to a remote device and execute commands; however, it can also transfer files using the associated Secure FTP (SFTP) or Secure Copy (SCP) protocols.

For SSH to function, the network devices communicating must be configured to support it. In this lab, you will enable the SSH server on a router and then connect to that router using a PC with an SSH client installed. On a local network, the connection is normally made using Ethernet and IP.

In this lab, you will configure a router to accept SSH connectivity, and use Wireshark to capture and view Telnet and SSH sessions. This will demonstrate the importance of encryption with SSH. You will also be challenged to configure a switch for SSH connectivity on your own.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary

from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

#### **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term, and Wireshark installed)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

## Part 1: Configure Basic Device Settings

In Part 1, you will set up the network topology and configure basic settings, such as the interface IP addresses, device access, and passwords on the router.

#### Step 1: Cable the network as shown in the topology.

#### Step 2: Initialize and reload the router and switch.

#### Step 3: Configure the router.

- a. Console into the router and enable privileged EXEC mode.
- b. Enter configuration mode.
- c. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were host names.
- d. Assign **class** as the privileged EXEC encrypted password.
- e. Assign cisco as the console password and enable login.
- f. Assign **cisco** as the vty password and enable login.
- g. Encrypt the plain text passwords.
- h. Create a banner that will warn anyone accessing the device that unauthorized access is prohibited.
- i. Configure and activate the G0/1 interface on the router using the information contained in the Addressing Table.
- j. Save the running configuration to the startup configuration file.

#### Step 4: Configure PC-A.

- a. Configure PC-A with an IP address and subnet mask.
- b. Configure a default gateway for PC-A.

#### Step 5: Verify network connectivity.

Ping R1 from PC-A. If the ping fails, troubleshoot the connection.

## Part 2: Configure the Router for SSH Access

Using Telnet to connect to a network device is a security risk, because all information is transmitted in a clear text format. SSH encrypts the session data and provides device authentication, which is why SSH is recommended for remote connections. In Part 2, you will configure the router to accept SSH connections over the VTY lines.

#### Step 1: Configure device authentication.

The device name and domain are used as part in the crypto key when it is generated. Therefore, these names must be entered prior to issuing the **crypto key** command.

a. Configure device name.

Router(config) # hostname R1

b. Configure the domain for the device.

R1(config) # ip domain-name ccna-lab.com

#### Step 2: Configure the encryption key method.

```
R1(config) # crypto key generate rsa modulus 1024
The name for the keys will be: R1.ccna-lab.com
```

```
% The key modulus size is 1024 bits
% Generating 1024 bit RSA keys, keys will be non-exportable...
[OK] (elapsed time was 1 seconds)
```

R1(config)# \*Jan 28 21:09:29.867: %SSH-5-ENABLED: SSH 1.99 has been enabled

#### Step 3: Configure a local database username.

```
R1(config)# username admin privilege 15 secret adminpass
R1(config)#
*Feb 6 23:24:43.971: End->Password:QHjxdsVkjtoP7VxKIcPsLdTiMIvyLkyjT1HbmYxZigc
R1(config)#
```

Note: A privilege level of 15 gives the user administrator rights.

#### Step 4: Enable SSH on the VTY lines.

a. Enable Telnet and SSH on the inbound VTY lines using the transport input command.

```
R1(config) # line vty 0 4
R1(config-line) # transport input telnet ssh
```

b. Change the login method to use the local database for user verification.

```
R1(config-line)# login local
R1(config-line)# end
R1#
```

#### Step 5: Save the running configuration to the startup configuration file.

```
R1# copy running-config startup-config
Destination filename [startup-config]?
```

```
Building configuration...
[OK]
R1#
```

## Part 3: Examine a Telnet Session with Wireshark

In Part 3, you will use Wireshark to capture and view the transmitted data of a Telnet session on the router. You will use Tera Term to telnet to R1, sign in, and then issue the show run command on the router.

**Note**: If a Telnet/SSH client software package is not installed on your PC, you must install one before continuing. Two popular freeware Telnet/SSH packages are Tera Term (<u>http://download.cnet.com/Tera-Term/3000-20432\_4-75766675.html</u>) and PuTTy (<u>www.putty.org</u>).

**Note**: Telnet is not available from the command prompt in Windows 7, by default. To enable Telnet for use in the command prompt window, click **Start > Control Panel > Programs > Programs and Features > Turn Windows features on or off**. Click the **Telnet Client** check box, and then click **OK**.

#### Step 1: Open Wireshark and start capturing data on the LAN interface.

**Note**: If you are unable to start the capture on the LAN interface, you may need to open Wireshark using the **Run as Administrator** option.

#### Step 2: Start a Telnet session to the router.

a. Open Tera Term and select the **Telnet** Service radio button and in the Host field, enter **192.168.1.1**.

Tera Term: New o	connection	83
TCP/IP	Host: 192.168.1.1	•
	V History Service Telnet TCP port#: 23	
	SSH SSH version: SSH2	-
	Other Protocol: UNSPEC	. •
Serial	Port:	-
	OK Cancel Help	

What is the default TCP port for Telnet sessions? \_\_\_\_

b. At the Username: prompt, enter **admin** and at the Password: prompt, enter **adminpass**. These prompts are generated because you configured the VTY lines to use the local database with the **login local** command.

🜉 192.168.1.1:23 - Tera Term VT	
File Edit Setup Control Window Help	
**************************************	
User Access Verification	
Username:	

c. Issue the **show run** command.

R1# show run

d. Enter exit to exit the Telnet session and out of Tera Term.

R1# **exit** 

Step 3: Stop the Wireshark capture.



Step 4: Apply a Telnet filter on the Wireshark capture data.



### Step 5: Use the Follow TCP Stream feature in Wireshark to view the Telnet session.

a. Right-click one of the **Telnet** lines in the **Packet list** section of Wireshark, and in the drop-down list, select **Follow TCP Stream**.

🗖 In	tel(F	R) PRO/	1000	MT Netwo	ork Conne	ction	[Wiresha	r <mark>k 1.</mark>	6.1 (SVI	I Rev 380	96 from	/trun	k-1	.6)]									_ 0	×
Eile	<u>E</u> dit	<u>V</u> iew	Go	<u>C</u> apture	<u>A</u> nalyze	<u>S</u> tatist	ics Telep	hony	Tools	<u>I</u> nternals	<u>H</u> elp													
	<u>i</u>	04 6	X 🕯	(  🖻	. *	2	8   0	. <	Þ 🔿	🥹 7	₽			Ð,	Q	0	]   🗃	( ¥	<b>7</b> 8	*				
Filter	: te	lnet								•	Express	ion	Cle	ar Apply	/									
No.		Time		Source			Dest	natio	n		Protoc	ol Le	ngth	Info										
	117	35.67	4982	2 192.	168.1.3	;	192	عدم	011			гт	-15	55 Teln	net	Data								
	118	35.67	6097	/ 192.3	168.1.1	_	192		Mark Pa	icket (togg			-	52 Teln	iet	Data								
	120	36.11	5021	L 192.	168.1.3	5	192	•	Ignore	Packet (tog	ggle)			55 Teln	iet	Data								
	121	36.11	.6029	9 192.3	168.1.1		192	. 🕓	Set Tim	e Referenc	e (toggle	)	4	9 Teln	iet	Data								
	124	37.78	84188	3 192.3	168.1.3	5	192	· —	Manual	v Decolve	Address			5 Teln	iet	Data								
	125	37.78	35632	2 192.3	168.1.1	-	192	·	Manual	y Resolve	Auuress		_ BC	09 Teln	iet	Data								
	128	39.17	3531	192.	168.1.3	5	192	•	Apply a	s Filter				5 Teln	net	Data								
	129	39.17	4312	2 192.3	168.1.1	-	192	•	Prepare	a Filter				0 Teln	iet	Data								
	130	39.36	52819	9 192.3	168.1.3	5	192	•	Conver	sation Filte	r			5 Teln	iet	Data								
	131	39.36	5331	5 192.3	168.1.1		192		Colorize	Conversa	tion			50 Teln	iet	Data								
	132	39.52	419	5 192.3	168.1.3	;	192		SCTP					5 Teln	iet	Data								
	133	39.52	4827	192.3	168.1.1	-	192	-	Follow 1	CP Stream			6	0 Teln	iet	Data	• • •							
	134	39.64	1074	192.3	168.1.3	5	192	-	Follow	IDP Stream	-			5 Teln	iet	Data	• • •							
	135	39.64	1667	192.	168.1.1	-	192	•	Follow	CI Stream			6	0 Teln	iet	Data								
	136	39.82	2087	192.3	168.1.3	5	192	·	I-OIOW -	ooc ou cam			- 15	6 Teln	iet	Data								
	137	39.82	2730	) 192.3	168.1.1		192		Сору					50 Teln	iet	Data								Ψ.
+ F	rame	117:	55	bytes	on wire	e (44)	0 bits)						ī	ts)										—
+ E	ther	net I	Ι, 5	Src: Vm	ware_b	e:6c:	89 (00:	48	Decode	As			9	:47:75	:c3	:e1 (†	Fc:99:	47:75	5:c	3:e1)				
+ I	nter	net P	roto	ocol Ve	rsion 4	4, Sr	c: 192.	: 🖴	Print				:	192.1	68.	1.1 (	192.16	58.1.1	1)					
E T	rans	missi	on c	ontrol	Proto	col, s	Src Por	1	Show P	acket in Ne	w Window	N	t	elnet	(23)	), Se	4: 55,	Ack	: 10	057, 1	Len: 1	L		
E T	elne	et						_	_		_	_	-											
L –																								

b. The Follow TCP Stream window displays the data for your Telnet session with the router. The entire session is displayed in clear text, including your password. Notice that the username and **show run** command that you entered are displayed with duplicate characters. This is caused by the echo setting in Telnet to allow you to view the characters that you type on the screen.

Follow TCP Stream	_ 🗆 >
tream Content	
******	<u> </u>
UNAUTNOFIZED ACCESS IS Pronibited! ************************************	
User Access Verification	
Username:	
Password: adminpass	
21#sshhooww rruunn	
Building configuration	
Current configuration : 1644 bytes !	
! Last configuration change at 23:26:03 UTC Wed Feb 6 2013 version 15.2	
service timestamps debug datetime msec service timestamps log datetime msec service password-encryption	
l hostname R1	
: boot-start-marker	
boot-end-marker	
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2	-
Entire conversation (2266 bytes)	-
Eind Save As Print O ASCII O EBCDIC O Hex Dump O C Arrays O	Raw
Help Filter Out This Stream	-

c. After you have finished reviewing your Telnet session in the Follow TCP Stream window, click Close.

## Part 4: Examine an SSH session with Wireshark

In Part 4, you will use the Tera Term software to establish an SSH session with the router. Wireshark will be used to capture and view the data of this SSH session.

#### Step 1: Open Wireshark and start capturing data on the LAN interface.

#### Step 2: Start an SSH session on the router.

a. Open Tera Term and enter the G0/1 interface IP address of R1 in the Host: field of the Tera Term: New Connection window. Ensure that the **SSH** radio button is selected and then click **OK** to connect to the router.



What is the default TCP port used for SSH sessions? \_

b. The first time you establish a SSH session to a device, a **SECURITY WARNING** is generated to let you know that you have not connected to this device before. This message is part of the authentication process. Read the security warning and then click **Continue**.

SECURITY WARNING	X
There is no entry for the server "192.168.1.1" in your list of known hosts. The machine you have contacted may be a hostile machine pretending to be the server.	
If you choose to add this machine to the known hosts list and continue, then you will not receive this warning again.	
The server's host key fingerprint is: f5:b1:e7:f8:c6:74:89:88:79:1c:24:8f:2c:6e:6e:39	
+[ RSA 1024]+	
. + + o . S + = o .	
Add this machine and its key to the known hosts list	
Continue Disconnect	

c. In the SSH Authentication window, enter **admin** for the username and **adminpass** for the passphrase. Click **OK** to sign into the router.

SSH Authentication
Logging in to 192.168.1.1
Authentication required.
User name: admin
Passphrase:
Remember password in memory
Forward agent
Use plain password to log in
Use RSA/DSA/ECDSA key to log in     Private key file:
C Use rhosts to log in (55H1) Local user name:
Host private key file;
O Use challenge/response to log in(keyboard-interactive)
C Use Pageant
OK Disconnect

d. You have established a SSH session on the router. The Tera Term software looks very similar to a command window. At the command prompt, issue the **show run** command.

👺 192.168.1.1:22 - Tera Term VT	
File Edit Setup Control Window Help	
**************************************	

e. Exit the SSH session and out of Tera Term by issuing the exit command.

R1# **exit** 

Step 3: Stop the Wireshark capture.



Step 4: Apply an SSH filter on the Wireshark Capture data.

#### Step 5: Use the Follow TCP Stream feature in Wireshark to view the Telnet session.

- a. Right-click one of the SSHv2 lines in the Packet list section of Wireshark, and in the drop-down list, select the Follow TCP Stream option.
- b. Examine the **Follow TCP Stream** window of your SSH session. The data has been encrypted and is unreadable. Compare the data in your SSH session to the data of your Telnet session.

Tollow TCP Stream
Tollow TCP Stream         SSH=2.0 - TTSSH/2.62 win32
Entire conversation (8602 bytes)
Eind Save As Print O ASCII O EBCDIC O Hex Dump O C Arrays • Raw
Help Filter Out This Stream

Why is SSH preferred over Telnet for remote connections?

- c. After examining your SSH session, click Close.
- d. Close Wireshark.

## Part 5: Configure the Switch for SSH Access

In Part 5, you are to configure the switch in the topology to accept SSH connections. Once the switch has been configured, establish a SSH session on it using Tera Term.

#### Step 1: Configure the basic settings on the switch.

#### Step 2: Configure the switch for SSH connectivity.

Use the same commands that you used to configure SSH on the router in Part 2 to configure SSH for the switch.

#### Step 3: Establish a SSH connection to the switch.

Start Tera Term from PC-A, and then SSH to the SVI interface on the S1.

#### Step 4: Troubleshoot as necessary.

Are you able to establish a SSH session with the switch?

## Part 6: SSH From the CLI on the Switch

The SSH client is built into the Cisco IOS and can be run from the CLI. In Part 6, you will SSH to the router from the CLI on the switch.

#### Step 1: View the parameters available for the Cisco IOS SSH client.

Use the question mark (?) to display the parameter options available with the ssh command.

```
S1# ssh ?
  -c Select encryption algorithm
  -l Log in using this user name
  -m Select HMAC algorithm
  -o Specify options
  -p Connect to this port
  -v Specify SSH Protocol Version
  -vrf Specify vrf name
  WORD IP address or hostname of a remote system
```

#### Step 2: SSH to router R1 from S1.

a. You must use the **–I admin** option when you SSH to R1. This allows you to log in as user **admin**. When prompted, enter **adminpass** for the password.

R1#

b. You can return to S1 without closing your SSH session to R1 by pressing **Ctrl+Shift+6**. Release the **Ctrl+Shift+6** keys and press **x**. You should see the switch privilege EXEC prompt display.

R1#

S1#

c. To return to the SSH session on R1, press Enter on a blank CLI line. You may need to press Enter a second time to see the router CLI prompt.

```
S1#
[Resuming connection 1 to 192.168.1.1 ... ]
```

R1#

d. To end the SSH session on R1, type exit at the router prompt.

```
R1# exit
```

[Connection to 192.168.1.1 closed by foreign host] S1#

What versions of SSH are supported from the CLI?

#### Reflection

How would you provide multiple users, each with their own username, access to a network device?

## **Router Interface Summary Table**

Router Interface Summary									
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2					
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)					
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)					

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.
# 11.2.4.6 Lab – Securing Network Devices

## Topology



## Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## Objectives

Part 1: Configure Basic Device Settings

Part 2: Configure Basic Security Measures on the Router

Part 3: Configure Basic Security Measures on the Switch

## **Background / Scenario**

It is recommended that all network devices be configured with, at least, a minimum set of best practice security commands. This includes end user devices, servers, and network devices, such as routers and switches.

In this lab, you will configure the network devices in the topology to accept SSH sessions for remote management. You will also use the IOS CLI to configure common, basic best practice security measures. You will then test the security measures to verify that they are properly implemented and working correctly.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

## Part 1: Configure Basic Device Settings

In Part 1, you will set up the network topology and configure basic settings, such as the interface IP addresses, device access, and passwords on the router.

#### Step 1: Cable the network as shown in the topology.

Attach the devices as shown in the topology and cable as necessary.

#### Step 2: Initialize and reload the router and switch.

#### Step 3: Configure the router.

Please refer to the previous lab for help with the commands needed for SSH.

- a. Console into the router and enable privileged EXEC mode.
- b. Enter configuration mode.
- c. Assign the name of the router as R1.
- d. Disable DNS lookup.
- e. Assign class as the privileged EXEC encrypted password.
- f. Assign **cisco** as the console password and enable login.
- g. Assign cisco as the vty password and enable login.
- h. Encrypt the plain text passwords.
- i. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- j. Configure and activate the G0/1 interface on the router using the information contained in the Addressing Table.
- k. Save the running configuration to the startup configuration file.

#### Step 4: Configure the switch.

- a. Console into the switch and enable privileged EXEC mode.
- b. Enter configuration mode.
- c. Assign the name of the switch as S1.
- d. Disable DNS lookup to prevent the router from attempting to translate incorrectly entered commands as though they were hostnames.
- e. Assign class as the privileged EXEC encrypted password.
- f. Assign **cisco** as the console password and enable login.
- g. Assign cisco as the vty password and enable login.
- h. Encrypt the plain text passwords.
- i. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- j. Configure the default SVI with the IP address information contained in the Addressing Table.
- k. Save the running configuration to the startup configuration file.

# Part 2: Configure Basic Security Measures on the Router

#### Step 1: Strengthen passwords.

An administrator should ensure that passwords meet the standard guidelines for strong passwords. These guidelines could include mixing letters, numbers, and special characters in the password and setting a minimum length.

**Note**: Best practice guidelines require the use of strong passwords, such as those shown here, in a production environment. However, the other labs in this course use the cisco and class passwords for ease in performing the labs.

a. Change the privileged EXEC encrypted password to meet guidelines.

```
R1(config)# enable secret Enablep@55
```

b. Require that a minimum of 10 characters be used for all passwords.

R1(config) # security passwords min-length 10

#### Step 2: Enable SSH connections.

a. Assign the domain name as **CCNA-lab.com**.

```
R1(config) # ip domain-name CCNA-lab.com
```

b. Create a local user database entry to use when connecting to the router via SSH. The password should meet strong password standards, and the user should have administrator-level access.

R1(config)# username admin privilege 15 secret Admin15p@55

c. Configure the transport input for the vty lines so that they accept SSH connections, but do not allow Telnet connections.

R1(config)# line vty 0 4
R1(config-line)# transport input ssh

d. The vty lines should use the local user database for authentication.

```
R1(config-line)# login local
R1(config-line)# exit
```

e. Generate a RSA crypto key using a modulus of 1024 bits.

R1(config) # crypto key generate rsa modulus 1024 The name for the keys will be: R1.CCNA-lab.com

% The key modulus size is 1024 bits % Generating 1024 bit RSA keys, keys will be non-exportable... [OK] (elapsed time was 2 seconds)

R1(config)# \*Jan 31 17:54:16.127: %SSH-5-ENABLED: SSH 1.99 has been enabled

#### Step 3: Secure the console and VTY lines.

a. You can set the router to log out of a connection that has been idle for a specified time. If a network administrator was logged into a networking device and was suddenly called away, this command automatically logs the user out after the specified time. The following commands cause the line to log out after five minutes of inactivity.

```
R1(config)# line console 0
R1(config-line)# exec-timeout 5 0
R1(config-line)# line vty 0 4
R1(config-line)# exec-timeout 5 0
R1(config-line)# exit
R1(config)#
```

b. The following command impedes brute force login attempts. The router blocks login attempts for 30 seconds if someone fails two attempts within 120 seconds. This timer is set especially low for the purpose of this lab.

```
R1(config) # login block-for 30 attempts 2 within 120
```

What does the 2 within 120 mean in the above command?

What does the block-for 30 mean in the above command?

#### Step 4: Verify that all unused ports are disabled.

Router ports are disabled, by default, but it is always prudent to verify that all unused ports are in an administratively down state. This can be quickly checked by issuing the **show ip interface brief** command. Any unused ports that are not in an administratively down state should be disabled using the **shutdown** command in interface configuration mode.

```
R1# show ip interface brief
```

```
IP-Address
Interface
                                      OK? Method Status
                                                                      Protocol
Embedded-Service-Engine0/0 unassigned
                                      YES NVRAM administratively down down
GigabitEthernet0/0
                        unassigned
                                      YES NVRAM administratively down down
                       192.168.1.1
GigabitEthernet0/1
                                      YES manual up
                                                                      up
                                     YES NVRAM administratively down down
Serial0/0/0
                        unassigned
Serial0/0/1
                        unassigned
                                      YES NVRAM administratively down down
R1#
```

Step 5: Verify that your security measures have been implemented correctly.

a. Use Tera Term to telnet to R1.

Does R1 accept the Telnet connection?

Why or why not?

b. Use Tera Term to SSH to R1.

Does R1 accept the SSH connection? \_\_\_\_\_

c. Intentionally mistype the user and password information to see if login access is blocked after two attempts.

What happened after you failed to login the second time?

d. From your console session on the router, issue the **show login** command to view the login status. In the example below, the **show login** command was issued within the 30 second login blocking period and shows that the router is in Quiet-Mode. The router will not accept any login attempts for 14 more seconds.

```
R1# show login
```

```
A default login delay of 1 second is applied.
No Quiet-Mode access list has been configured.
Router enabled to watch for login Attacks.
If more than 2 login failures occur in 120 seconds or less,
logins will be disabled for 30 seconds.
Router presently in Quiet-Mode.
Will remain in Quiet-Mode for 14 seconds.
Denying logins from all sources.
```

e. After the 30 seconds has expired, SSH to R1 again and login using the **admin** username and **Admin15p@55** for the password.

After you successfully logged in, what was displayed? \_\_

f. Enter privileged EXEC mode and use Enablep@55 for the password.

If you mistype this password, are you disconnected from your SSH session after two failed attempts within 120 seconds? \_\_\_\_\_

Why or why not?

g. Issue the **show running-config** command at the privileged EXEC prompt to view the security settings you have applied.

## Part 3: Configure Basic Security Measures on the Switch

#### Step 1: Strengthen Passwords on the switch.

Change the privileged EXEC encrypted password to meet strong password guidelines.

S1(config) # enable secret Enablep@55

Note: The security password min-length command is not available on the 2960 switch.

#### Step 2: Enable SSH Connections.

a. Assign the domain-name as CCNA-lab.com

S1(config) # ip domain-name CCNA-lab.com

b. Create a local user database entry for use when connecting to the router via SSH. The password should meet strong password standards, and the user should have administrative level access.

S1(config)# username admin privilege 15 secret Admin15p055

c. Configure the transport input for the vty lines to allow SSH connections but not allow Telnet connections.

S1(config)# line vty 0 15

S1(config-line)# transport input ssh

d. The vty lines should use the local user database for authentication.

```
S1(config-line)# login local
S1(config-line)# exit
```

e. Generate a RSA crypto key using a modulus of 1024 bits.

S1(config) # crypto key generate rsa modulus 1024

#### Step 3: Secure the console and VTY lines.

a. Have the switch log out a line that has been idle for 10 minutes.

```
S1(config)# line console 0
S1(config-line)# exec-timeout 10 0
S1(config-line)# line vty 0 15
S1(config-line)# exec-timeout 10 0
S1(config-line)# exit
S1(config)#
```

b. To impede brute force login attempts, configure the switch to block login access for 30 seconds if there are 2 failed attempts within 120 seconds. This timer is set especially low for the purpose of this lab.

S1(config)# login block-for 30 attempts 2 within 120
S1(config)# end

#### Step 4: Verify that all unused ports are disabled.

Switch ports are enabled, by default. Shut down all ports that are not in use on the switch.

a. You can verify the switch port status using the **show ip interface brief** command.

```
S1# show ip interface brief
Interface
                       IP-Address
                                      OK? Method Status
                                                                        Protocol
Vlan1
                       192.168.1.11
                                      YES manual up
                                                                        up
FastEthernet0/1
                       unassigned
                                     YES unset down
                                                                        down
FastEthernet0/2
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/3
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/4
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/5
                      unassigned
                                      YES unset
                                                 up
                                                                        up
FastEthernet0/6
                      unassigned
                                      YES unset
                                                 up
                                                                        up
FastEthernet0/7
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/8
                      unassigned
                                      YES unset
                                                 down
                                                                        down
FastEthernet0/9
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/10
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/11
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/12
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/13
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/14
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/15
                      unassigned
                                      YES unset down
                                                                        down
FastEthernet0/16
                       unassigned
                                      YES unset
                                                 down
                                                                        down
FastEthernet0/17
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/18
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/19
                       unassigned
                                      YES unset down
                                                                        down
FastEthernet0/20
                       unassigned
                                       YES unset down
                                                                        down
```

FastEthernet0/21	unassigned	YES unset	down	down
FastEthernet0/22	unassigned	YES unset	down	down
FastEthernet0/23	unassigned	YES unset	down	down
FastEthernet0/24	unassigned	YES unset	down	down
GigabitEthernet0/1	unassigned	YES unset	down	down
GigabitEthernet0/2	unassigned	YES unset	down	down
S1#				

b. Use the interface range command to shut down multiple interfaces at a time.

```
S1(config)# interface range f0/1-4 , f0/7-24 , g0/1-2
S1(config-if-range)# shutdown
S1(config-if-range)# end
S1#
```

c. Verify that all inactive interfaces have been administratively shut down.

```
S1# show ip interface brief
```

Interface	IP-Address	OK?	Method	Status		Protocol
Vlan1	192.168.1.11	YES	manual	up		up
FastEthernet0/1	unassigned	YES	unset	administratively	down	down
FastEthernet0/2	unassigned	YES	unset	administratively	down	down
FastEthernet0/3	unassigned	YES	unset	administratively	down	down
FastEthernet0/4	unassigned	YES	unset	administratively	down	down
FastEthernet0/5	unassigned	YES	unset	up		up
FastEthernet0/6	unassigned	YES	unset	up		up
FastEthernet0/7	unassigned	YES	unset	administratively	down	down
FastEthernet0/8	unassigned	YES	unset	administratively	down	down
FastEthernet0/9	unassigned	YES	unset	administratively	down	down
FastEthernet0/10	unassigned	YES	unset	administratively	down	down
FastEthernet0/11	unassigned	YES	unset	administratively	down	down
FastEthernet0/12	unassigned	YES	unset	administratively	down	down
FastEthernet0/13	unassigned	YES	unset	administratively	down	down
FastEthernet0/14	unassigned	YES	unset	administratively	down	down
FastEthernet0/15	unassigned	YES	unset	administratively	down	down
FastEthernet0/16	unassigned	YES	unset	administratively	down	down
FastEthernet0/17	unassigned	YES	unset	administratively	down	down
FastEthernet0/18	unassigned	YES	unset	administratively	down	down
FastEthernet0/19	unassigned	YES	unset	administratively	down	down
FastEthernet0/20	unassigned	YES	unset	administratively	down	down
FastEthernet0/21	unassigned	YES	unset	administratively	down	down
FastEthernet0/22	unassigned	YES	unset	administratively	down	down
FastEthernet0/23	unassigned	YES	unset	administratively	down	down
FastEthernet0/24	unassigned	YES	unset	administratively	down	down
GigabitEthernet0/1	unassigned	YES	unset	administratively	down	down
GigabitEthernet0/2	unassigned	YES	unset	administratively	down	down
S1#						

#### Step 5: Verify that your security measures have been implemented correctly.

a. Verify that Telnet has been disabled on the switch.

- b. SSH to the switch and intentionally mistype the user and password information to see if login access is blocked.
- c. After the 30 seconds has expired, SSH to S1 again and log in using the **admin** username and **Admin15p@55** for the password.

Did the banner appear after you successfully logged in?

- d. Enter privileged EXEC mode using **Enablep@55** as the password.
- e. Issue the **show running-config** command at the privileged EXEC prompt to view the security settings you have applied.

## Reflection

- 1. The **password cisco** command was entered for the console and vty lines in your basic configuration in Part 1. When is this password used after the best practice security measures have been applied?
- 2. Are preconfigured passwords, shorter than 10 characters, affected by the **security passwords min-length 10** command?

## **Router Interface Summary Table**

Router Interface Summary							
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2			
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)			
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 11.3.2.3 Lab - Testing Network Latency with Ping and Traceroute

## Topology



## Objectives

Part 1: Use Ping to Document Network Latency

## Part 2: Use Traceroute to Document Network Latency

## **Background / Scenario**

To obtain realistic network latency statistics, this activity must be performed on a live network. Be sure to check with your instructor for any local security restrictions against using the **ping** command on the network.

The purpose of this lab is to measure and evaluate network latency over time, and during different periods of the day to capture a representative sample of typical network activity. This will be accomplished by analyzing the return delay from a distant computer with the **ping** command. Return delay times, measured in milliseconds, will be summarized by computing the average latency (mean) and the range (maximum and minimum) of the delay times.

## **Required Resources**

• 1 PC (Windows 7, Vista, or XP with Internet access)

# Part 1: Use Ping to Document Network Latency

In Part 1, you will examine network latency to several websites in different parts of the globe. This process can be used in an enterprise production network to create a performance baseline.

## Step 1: Verify connectivity.

Ping the following Regional Internet Registry (RIR) websites to verify connectivity:

C:\Users\User1> ping www.arin.net C:\Users\User1> ping www.lacnic.net C:\Users\User1> ping www.afrinic.net C:\Users\User1> ping www.apnic.net

Note: Because www.ripe.net does not reply to ICMP requests, it cannot be used for this lab.



## Step 2: Collect network data.

You will collect a sufficient amount of data to compute statistics on the **ping** output by sending out 25 echo requests to each address listed in Step 1. Record the results for each website to text files.

a. At the command prompt, type **ping** to list the available options.

```
C:\Users\User1> ping
```

```
Usage: ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL] [-v TOS]
            [-r count] [-s count] [[-j host-list] | [-k host-list]]
            [-w timeout] [-R] [-S srcaddr] [-4] [-6] target name
Options:
    -t
                   Ping the specified host until stopped.
                   To see statistics and continue - type Control-Break;
                   To stop - type Control-C.
                   Resolve addresses to hostnames.
    -a
    -n count
                   Number of echo requests to send.
                   Send buffer size.
    -l size
    -f
                   Set Don't Fragment flag in packet (IPv4-only).
    -i TTL
                   Time To Live.
    -v TOS
                   Type Of Service (IPv4-only. This setting has been deprecated
```

- <output omitted>
- b. Using the **ping** command with the count option, you can send 25 echo requests to the destination as illustrated below. Furthermore, it will create a text file with filename of **arin.txt** in the current directory. This text file will contain the results of the echo requests.

```
C:\Users\User1> ping -n 25 www.arin.net > arin.txt
```

**Note**: The terminal remains blank until the command has finished, because the output has been redirected to a text file, **arin.txt**, in this example. The > symbol is used to redirect the screen output to the file and overwrite the file if it already exists. If appending more results to the file is desired, replace > with >> in the command.

c. Repeat the ping command for the other websites.

```
C:\Users\User1> ping -n 25 www.afrinic.net > afrinic.txt
C:\Users\User1> ping -n 25 www.apnic.net > apnic.txt
C:\Users\User1> ping -n 25 www.lacnic.net > lacnic.txt
```

#### Step 3: Verify data collection.

To see the results in the file created, use the **more** command at the command prompt.

```
C:\Users\User1> more arin.txt
```

```
Pinging www.arin.net [192.149.252.76] with 32 bytes of data:
Reply from 192.149.252.76: bytes=32 time=108ms TTL=45
Reply from 192.149.252.76: bytes=32 time=114ms TTL=45
<eutput from 192.149.252.76: bytes=32 time=112ms TTL=45
<output omitted>
Reply from 192.149.252.75: bytes=32 time=111ms TTL=45
Reply from 192.149.252.75: bytes=32 time=112ms TTL=45
Reply from 192.149.252.75: bytes=32 time=112ms TTL=45
Ping statistics for 192.149.252.75:
Packets: Sent = 25, Received = 25, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 107ms, Maximum = 121ms, Average = 111ms
```

Note: Press the Spacebar to display the rest of the file or press q to exit.

To verify that the files have been created, use the **dir** command to list the files in the directory. Also the wildcard \* can be used to filter only the text files.

```
C:\Users\User1> dir *.txt

Volume in drive C is OS

Volume Serial Number is 0A97-D265

Directory of C:\Users\User1

02/07/2013 12:59 PM 1,642 afrinic.txt

02/07/2013 01:00 PM 1,615 apnic.txt

02/07/2013 12:40 PM 1,641 arin.txt

02/07/2013 12:58 PM 1,589 lacnic.txt

4 File(s) 6,487 bytes

0 Dir(s) 34,391,453,696 bytes free
```

Record your results in the following table.

	Minimum	Maximum	Average
www.afrinic.net			
www.apnic.net			
www.arin.net			
www.lacnic.net			

Compare the delay results. How is delay affected by geographical location?

## Part 2: Use Traceroute to Document Network Latency

The routes traced may go through many hops and a number of different ISPs depending on the size of the ISPs and the location of the source and destination hosts. The **traceroute** commands can also be used to observe network latency. In Part 2, the **tracert** command is used to trace the path to the same destinations in Part 1.

The tracert command uses ICMP TTL Exceed packets and ICMP echo replies to trace the path.

#### Step 1: Use the tracert command and record the output to text files.

Copy the following commands to create the traceroute files:

```
C:\Users\User1> tracert www.arin.net > traceroute_arin.txt
C:\Users\User1> tracert www.lacnic.net > traceroute_lacnic.txt
C:\Users\User1> tracert www.afrinic.net > traceroute_afrinic.txt
C:\Users\User1> tracert www.apnic.net > traceroute_apnic.txt
```

#### Step 2: Use the more command to examine the traced path.

a. Use the more command to access the content of these files:

```
C:\Users\User1> more traceroute arin.txt
```

```
Tracing route to www.arin.net [192.149.252.75] over a maximum of 30 hops:
```

1	<1 ms	<1 ms	<1 ms	192.168.1.1
2	11 ms	12 ms	11 ms	10.39.0.1
3	10 ms	15 ms	11 ms	172.21.0.116
4	19 ms	10 ms	11 ms	70.169.73.90
5	13 ms	10 ms	11 ms	chnddsrj01-ae2.0.rd.ph.cox.net [70.169.76.229]
6	72 ms	71 ms	70 ms	mrfddsrj02-ae0.0.rd.dc.cox.net [68.1.1.7]
7	72 ms	71 ms	72 ms	68.100.0.146
8	74 ms	83 ms	73 ms	172.22.66.29
9	75 ms	71 ms	73 ms	172.22.66.29
10	74 ms	75 ms	73 ms	wsip-98-172-152-14.dc.dc.cox.net [98.172.152.14]
11	71 ms	71 ms	71 ms	host-252-131.arin.net [192.149.252.131]
12	73 ms	71 ms	71 ms	www.arin.net [192.149.252.75]

Trace complete.

In this example, it took less than 1 ms to receive a reply from the default gateway (192.168.1.1). In hop count 6, the round trip to 68.1.1.7 took an average of 71 ms. For the round trip to the final destination at www.arin.net took an average of 72 ms.

Between lines 5 and 6, there is more network delay as indicated by the round trip time increase from an average of 11 ms to 71 ms

b. Perform the same analysis with the rest of the tracert results.

What can you conclude regarding the relationship between the roundtrip time and geographical location?

## Reflection

- 1. The **tracert** and **ping** results can provide important network latency information. What do you need to do if you want an accurate baseline picture regarding network latency for your network?
- 2. How can you use the baseline information?

# 11.3.4.6 Lab – Using the CLI to Gather Network Device Information Topology



## Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
	Lo0	209.165.200.225	255.255.255.224	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## **Objectives**

## Part 1: Set Up Topology and Initialize Devices

- Set up equipment to match the network topology.
- Initialize and reload the router and switch.

## Part 2: Configure Devices and Verify Connectivity

- Assign a static IP address to PC-A NIC.
- Configure basic settings on R1.
- Configure basic settings on S1.
- Verify network connectivity.

## Part 3: Gather Network Device Information

- Gather information on R1 using IOS CLI commands.
- Gather information on S1 using IOS CLI commands.
- Gather information on PC-A using the command prompt CLI.

## **Background / Scenario**

Documenting a working network is one of the most important tasks a network professional can perform. Having proper documentation of IP addresses, model numbers, IOS versions, ports used, and testing security, can go a long way in helping to troubleshoot a network.

In this lab, you will build a small network, configure the devices, add some basic security, and then document the configurations by issuing various commands on the router, switch and PC to gather your information.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

## Part 1: Set Up the Topology and Initialize Devices

In Part 1, you will set up the network topology, clear any configurations if necessary, and configure basic settings on the router and switch.

#### Step 1: Cable the network as shown in the topology.

- a. Attach the devices as shown in the topology and cable as necessary.
- b. Power on all devices in the topology.

## Step 2: Initialize and reload the router and the switch.

## Part 2: Configure Devices and Verify Connectivity

In Part 2, you will set up the network topology and configure basic settings on the router and switch. Refer to the topology and Addressing Table at the beginning of this lab for device names and address information.

**Note**: Appendix A provides configuration details for the steps in Part 2. You should attempt to complete Part 2 prior to referencing this appendix.

#### Step 1: Configure the IPv4 address for the PC.

Configure the IPv4 address, subnet mask, and default gateway address for PC-A based on the Addressing Table.

#### Step 2: Configure the router.

If you need assistance for Step 2, refer to Appendix A for help.

- a. Console into the router and enter privileged EXEC mode.
- b. Set the correct time on the router.
- c. Enter global configuration mode.
  - 1) Assign a device name to the router based on the topology and Addressing Table.
  - 2) Disable DNS lookup.

- 3) Create a MOTD banner that warns anyone accessing the device that unauthorized access is prohibited.
- 4) Assign **class** as the privileged EXEC encrypted password.
- 5) Assign **cisco** as the console password and enable console login access.
- 6) Encrypt clear text passwords.
- 7) Create a domain name of **cisco.com** for SSH access.
- 8) Create a user named admin with a secret password of cisco for SSH access.
- 9) Generate a RSA modulus key. Use 1024 for the number of bits.
- d. Configure vty line access.
  - 1) Use the local database for authentication for SSH.
  - 2) Enable SSH only for login access.
- e. Return to global configuration mode.
  - 1) Create the Loopback 0 interface and assign the IP address based on the Addressing Table.
  - 2) Configure and activate interface G0/1 on the router.
  - 3) Configure interface descriptions for G0/1 and L0.
  - 4) Save the running configuration file to the startup configuration file.

#### Step 3: Configure the switch.

If you need assistance for Step 3, refer to Appendix A for help.

- a. Console into the switch and enter privileged EXEC mode.
- b. Set the correct time on the switch.
- c. Enter global configuration mode.
  - 1) Assign a device name on the switch based on the topology and Addressing Table.
  - 2) Disable DNS lookup.
  - Create a MOTD banner that warns anyone accessing the device that unauthorized access is prohibited.
  - 4) Assign **class** as the privileged EXEC encrypted password.
  - 5) Encrypt the clear text passwords.
  - 6) Create a domain name of **cisco.com** for SSH access.
  - 7) Create a user named **admin** with a secret password of **cisco** for SSH access.
  - 8) Generate an RSA modulus key. Use **1024** for the number of bits.
  - 9) Create and activate an IP address on the switch based on the topology and Addressing Table.
  - 10) Set the default gateway on the switch.
  - 11) Assign **cisco** as the console password and enable console login access.
- d. Configure vty line access.
  - 1) Use local database for authentication for SSH.
  - 2) Enable SSH only for login access.
  - 3) Enter proper mode to configure interface descriptions for F0/5 and F0/6.

4) Save the running configuration file to the startup configuration file.

#### Step 4: Verify network connectivity.

- a. From a command prompt on PC-A, ping the S1 VLAN 1 IP address. Troubleshoot your physical and logical configurations if the pings were not successful.
- b. From the PC-A command prompt, ping your default gateway IP address on R1. Troubleshoot your physical and logical configurations if the pings were not successful.
- c. From the PC-A command prompt, ping the loopback interface on R1. Troubleshoot your physical and logical configurations if the pings were not successful.
- d. Console back into the switch and ping the G0/1 IP address on R1. Troubleshoot your physical and logical configurations if the pings were not successful.

## Part 3: Gather Network Device Information

In Part 3, you will use a variety of commands to gather information about the devices on your network, as well as some performance characteristics. Network documentation is a very important component of managing your network. Documentation of both physical and logical topologies is important, as is verifying platform models and IOS versions of your network devices. Having knowledge of the proper commands to gather this information is essential for a network professional.

## Step 1: Gather information on R1 using IOS commands.

One of the most basic steps is to gather information on the physical device, as well as information on the operating system.

a. Issue the appropriate command to discover the following information:

Router Model:
IOS Version:
Total RAM:
Total NVRAM:
Total Flash Memory:
IOS Image File:
Configuration Register:
Technology Package:
What command did you issue to gather the information?

b. Issue the appropriate command to display a summary of important information about the router interfaces. Write down the command and record your results below.

Note: Only record interfaces that have IP addresses.

- c. Issue the appropriate command to display the routing table. Write down the command and record your results below. d. What command would you use to display the Layer 2 to Layer 3 mapping of addresses on the router? Write down the command and record your results below. e. What command would you use to see detailed information about all the interfaces on the router or about a specific interface? Write down the command below. Cisco has a very powerful protocol that operates at Layer 2 of the OSI model. This protocol can help you f. map out how Cisco devices are connected physically, as well as determining model numbers and even IOS versions and IP addressing. What command or commands would you use on router R1 to find out information about switch S1 to help you complete the table below? Local Remote **Device ID** Model # Port ID **IP Address IOS Version** Interface Capability
- g. A very elementary test of your network devices is to see if you can telnet into them. Remember, Telnet is not a secure protocol. It should not be enabled in most cases. Using a Telnet client, such as Tera Term or PuTTY, try to telnet to R1 using the default gateway IP address. Record your results below.
- h. From PC-A, test to ensure that SSH is working properly. Using an SSH client, such as Tera Term or PuTTY, SSH into R1 from PC-A. If you get a warning message regarding a different key, click **Continue**. Log in with the appropriate username and password you created in Part 2. Were you successful?

The various passwords configured on your router should be as strong and protected as possible.

**Note**: The passwords used for our lab (**cisco** and **class**) do not follow the best practices needed for strong passwords. These passwords are used merely for the convenience of performing the labs. By default, the console password and any vty passwords configured would display in clear text in your configuration file.

i. Verify that all of your passwords in the configuration file are encrypted. Write down the command and record your results below.

Command:	
Is the console password encrypted?	

Is the SSH password encrypted?

### Step 2: Gather information on S1 using IOS commands.

Many of the commands that you used on R1 can also be used with the switch. However, there are some differences with some of the commands.

a. Issue the appropriate command to discover the following information:

Switch Model:

IOS Version:

Total NVRAM:

IOS Image File: \_\_\_\_\_

What command did you issue to gather the information?

b. Issue the appropriate command to display a summary of key information about the switch interfaces. Write down the command and record your results below.

Note: Only record active interfaces.

c. Issue the appropriate command to display the switch MAC address table. Record the dynamic type MAC addresses only in the space below.

d. Verify that Telnet VTY access is disabled on S1. Using a Telnet client, such as Tera Term or PuTTY, try to telnet to S1 using the 192.168.1.11 address. Record your results below.

e. From PC-A, test to ensure that SSH is working properly. Using an SSH client, such as Tera Term or PuTTY, SSH into S1 from PC-A. If you get a warning message regarding a different key, click **Continue**. Log in with an appropriate username and password. Were you successful?

f. Complete the table below with information about router R1 using the appropriate command or commands necessary on S1.

Device Id	Local Interface	Capability	Model #	Remote Port ID	IP Address	IOS Version

g. Verify that all of your passwords in the configuration file are encrypted. Write down the command and record your results below.

Command: \_\_\_\_\_

Is the console password encrypted?

## Step 3: Gather information on PC-A.

Using various Windows utility commands, you will gather information on PC-A.

a. From the PC-A command prompt, issue the **ipconfig /all** command and record your answers below. What is the PC-A IP address?

What is the PC-A subnet mask?

What is the PC-A default gateway address?

What is the PC-A MAC address?

- b. Issue the appropriate command to test the TCP/IP protocol stack with the NIC. What command did you use?
- c. Ping the loopback interface of R1 from the PC-A command prompt. Was the ping successful?
- d. Issue the appropriate command on PC-A to trace the list of router hops for packets originating from PC-A to the loopback interface on R1. Record the command and output below. What command did you use?
- e. Issue the appropriate command on PC-A to find the Layer 2 to Layer 3 address mappings held on your NIC. Record your answers below. Only record answers for the 192.168.1.0/24 network. What command did you use?

## Reflection

Why is it important to document your network devices?

## **Router Interface Summary Table**

Router Interface Summary							
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2			
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)			
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)			

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

## Appendix A: Configuration Details for Steps in Part 2

## Step 1: Configure the IPv4 address for the PC.

Configure the IPv4 address, subnet mask, and default gateway address for PC-A based on the Addressing Table at the beginning of this lab.

General         You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.         Obtain an IP address automatically         Obtain an IP address:         IP address:         192.168.1.3         Subnet mask:         255.255.255.0	Internet Protocol Version 4 (TCP/IPv4) Properties							
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings. Obtain an IP address automatically Use the following IP address: IP address: IP address: Subnet mask: 192 . 168 . 1 . 3 255 . 255 . 0	General							
<ul> <li>Obtain an IP address automatically</li> <li>Use the following IP address:</li> <li>IP address:</li> <li>192 . 168 . 1 . 3</li> <li>Subnet mask:</li> <li>255 . 255 . 0</li> </ul>	You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.							
IP address:       192.168.1.3         Subnet mask:       255.255.255.0	<ul> <li>Obtain an IP address automatically</li> <li>Our of the following IP address:</li> </ul>							
Subnet mask: 255 . 255 . 255 . 0	IP address:	192.168.1.3						
	Subnet mask:	255.255.255.0						
Default gateway: 192 . 168 . 1 . 1	Default gateway:	192.168.1.1						

## Step 2: Configure the router.

a. Console into the router and enter privileged EXEC mode.

```
Router> enable
Router#
```

b. Set the correct time on the router.

```
Router# clock set 10:40:30 6 February 2013
Router#
```

c. Enter global configuration mode.

```
Router# config t
Router(config)#
```

1) Assign a hostname to the router. Use the topology and Addressing Table as guidelines.

```
Router(config) # hostname R1
```

- R1(config)#
- 2) Disable DNS lookup.
- R1(config) # no ip domain-lookup
- Create a MOTD banner that warns anyone accessing the device that unauthorized access is prohibited.
- R1(config) # banner motd #Warning! Unauthorized Access is prohibited.#
- 4) Assign **class** as the privileged EXEC encrypted password.
- R1(config) # enable secret class
- 5) Assign cisco as the console password and enable console login access.
- R1(config) # line con 0
- R1(config-line) # password cisco
- R1(config-line) # login
- 6) Encrypt clear text passwords.
- R1(config) # service password-encryption
- 7) Create a domain name of **cisco.com** for SSH access.

```
R1(config) # ip domain-name cisco.com
   Create a user named admin with a secret password of cisco for SSH access.
   R1(config) # username admin secret cisco
   9) Generate an RSA modulus key. Use 1024 for the number of bits.
   R1(config) # crypto key generate rsa modulus 1024
d. Configure vty line access.
   1) Use the local database for authentication for SSH.
   R1(config) # line vty 0 4
   R1(config-line) # login local
   Enable SSH only for login access.
   R1(config-line) # transport input ssh
e. Return to global configuration mode.
   R1(config-line) # exit
   1) Create the Loopback 0 interface and assign the IP address based on the Address Table.
   R1(config) # interface loopback 0
   R1(config-if)# ip address 209.165.200.225 255.255.255.224
   Configure and activate interface G0/1 on the router.
   R1(config-if) # int g0/1
   R1(config-if) # ip address 192.168.1.1 255.255.255.0
   R1(config-if) # no shut
   Configure interface descriptions for G0/1 and L0.
   R1(config-if) # description Connected to LAN
   R1(config-if) # int lo0
   R1(config-if) # description Emulate ISP Connection
   4) Save the running configuration file to the startup configuration file.
   R1(config-if)# end
   R1# copy run start
```

## Step 3: Configure the switch.

a. Console into the switch and enter privileged EXEC mode.

```
Switch> enable
Switch#
```

b. Set the correct time on the switch.

Switch# clock set 10:52:30 6 February 2013

c. Enter global configuration mode.

```
Switch# config t
```

1) Assign a hostname on the switch based on the topology and Addressing Table.

```
Switch(config) # hostname S1
```

2) Disable DNS lookup.

S1(config) # no ip domain-lookup

- Create a MOTD banner that warns anyone accessing the device that unauthorized access is prohibited.
- S1(config) # banner motd #Warning! Unauthorized access is prohibited.#
- 4) Assign **class** as the privileged EXEC encrypted password.
- S1(config) # enable secret class
- 5) Encrypt the clear text passwords.
- S1(config) # service password-encryption
- 6) Create a domain name of **cisco.com** for SSH access.
- S1(config) # ip domain-name cisco.com
- 7) Create a user named admin with a secret password of cisco for SSH access.
- S1(config) # username admin secret cisco
- 8) Generate an RSA modulus key. Use **1024** for the number of bits.

```
S1(config) # crypto key generate rsa modulus 1024
```

Create and activate an IP address on the switch based on the topology and Addressing Table.

```
S1(config) # interface vlan 1
```

- S1(config-if) # ip address 192.168.1.11 255.255.255.0
- S1(config-if)# no shut
- 10) Set the default gateway on the switch.
- S1(config) # ip default-gateway 192.168.1.1
- Assign cisco as the console password and enable console login access.
- S1(config-if) # line con 0
- S1(config-line) # password cisco
- S1(config-line)# login

#### d. Configure vty line access.

- 1) Use local database for authentication for SSH.
- S1(config-line)# line vty 0 15
- S1(config-line) # login local
- 2) Enable SSH only for login access.
- S1(config-line)# transport input ssh
- 3) Enter the appropriate configuration mode to configure interface descriptions for F0/5 and F0/6.

```
S1(config-line) # int f0/5
```

- S1(config-if) # description Connected to R1
- S1(config-if)# int f0/6
- S1(config-if) # description Connected to PC-A
- 4) Save the running configuration file to the startup configuration file.
- S1(config-if) # end
- S1# copy run start

# 11.4.2.6 Lab – Managing Router Configuration Files with Terminal Emulation Software

## Topology



## Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## **Objectives**

Part 1: Configure Basic Device Settings

## Part 2: Use Terminal Emulation Software to Create a Backup Configuration File

Part 3: Use a Backup Configuration File to Restore a Router

## **Background / Scenario**

It is a recommended best practice to maintain backup configuration files for routers and switches in the event that they need to be restored to a previous configuration. Terminal emulation software can be used to easily back up or restore a router or switch configuration file.

In this lab, you will use Tera Term to back up a router running configuration file, erase the router startup configuration file, reload the router, and then restore the missing router configuration from the backup configuration file.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports

• Ethernet cables as shown in the topology

# Part 1: Configure Basic Device Settings

In Part 1, you will set up the network topology and configure basic settings, such as the interface IP addresses, device access, and passwords on the router.

## Step 1: Cable the network as shown in the topology.

Attach the devices as shown in the topology and cable as necessary.

## Step 2: Configure the PC-A network settings according to the Addressing Table.

#### Step 3: Initialize and reload the router and switch.

#### Step 4: Configure the router.

- a. Console into the router and enter global configuration mode.
- b. Set the router name to R1.
- c. Disable DNS lookup.
- d. Assign class as the privileged EXEC encrypted password.
- e. Assign cisco as the console password and enable login.
- f. Assign **cisco** as the vty password and enable login.
- g. Encrypt the plain text passwords.
- h. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- i. Configure and activate the G0/1 interface on the router using the information contained in the Addressing Table.
- j. Save the running configuration to the startup configuration file.

## Step 5: Configure the switch.

- a. Console into the switch and enter into global configuration mode.
- b. Set the switch name to S1.
- c. Disable DNS lookup.
- d. Assign class as the privileged EXEC encrypted password.
- e. Assign cisco as the console password and enable login.
- f. Assign cisco as the vty password and enable login.
- g. Encrypt the plain text passwords.
- h. Create a banner that warns anyone accessing the device that unauthorized access is prohibited.
- i. Configure the default SVI management interface with the IP address information contained in the Addressing Table.
- j. Configure the switch default gateway.
- k. Save the running configuration to the startup configuration file.

# Part 2: Use Terminal Emulation Software to Create a Backup Configuration File

### Step 1: Establish a Tera Term console session to the router.

Launch the Tera Term Program, and in the New Connection window, select the **Serial** radio button and the appropriate communications port for your PC (i.e., COM1).

**Note**: If Tera Term is not installed, you can download the latest version from a number of Internet sites. Simply search for a Tera Term download.

- a. In Tera Term, press Enter to connect to the router.
- b. From the **File** menu, choose **Log**..., and save the **teraterm.log** file to the Desktop. Ensure that the **Append** and **Plain text** check boxes are enabled (checked).

Edit Setup Contr	ol Window	Help	
New connection	Alt+N	1	
Duplicate session	Alt+D		
Cygwin connection	Alt+G		
Log s			
Comment is Log			
View Log			
Show Log dialog			
Send file			

c. The Tera Term log file will create a record of every command issued and every output displayed.

**Note**: You can use this feature to capture the output from several commands in sequence and use it for network documentation purposes. For example, you could issue the **show version**, **show ip interface brief**, and **show running-config** commands to capture information about the router.

#### Step 2: Display the router running-configuration.

- a. Use the console password to log in to the router.
- b. Enter privileged EXEC mode.
- c. Enter the **show running-config** command.
- d. Continue pressing the space bar when --More-- is displayed until you see the router R1# prompt return.
- e. Click the Tera Term: Log icon on the Task bar. Click Close to end log session.

😃 Tera Term: Log	_				
Filename:	teraterm.log				
Fullpath:	C:\Users\User1\Desktop\teraterr				
Bytes trans	fered:	0			
Close	Pause Helj	)			

Note: You can also copy and paste the text from the Tera Term window directly into a text editor.

## Part 3: Use a Backup Configuration File to Restore a Router

#### Step 1: Erase the router startup-configuration and reload.

a. From privileged EXEC mode erase the startup configuration.

```
R1# erase startup-config
Erasing the nvram filesystem will remove all configuration files! Continue? [confirm]
[OK]
Erase of nvram: complete
```

b. Reload the router.

R1# **reload** Proceed with reload? [confirm]

c. At the System Configuration Dialog prompt, type **no**; a router prompt displays, indicating an unconfigured router.

--- System Configuration Dialog ---

Would you like to enter the initial configuration dialog? [yes/no]:

Press RETURN to get started!
<output omitted>
Router>

d. Enter privileged EXEC mode and enter a **show running-config** command to verify that all of the previous configurations were erased.

# Step 2: Edit the saved configuration backup file to prepare it for restoring the router configuration.

To restore the router configuration from a saved running configuration backup file, you must edit the text.

- a. Open the teraterm.log text file.
- b. Remove each instance of --More-- in the text file.

Note: The --More-- was generated by pressing the Spacebar when displaying the running configuration.

c. Delete the initial lines of the backup configuration file, so that the first line starts with the first configuration command as shown below.

service timestamps debug datetime msec service timestamps log datetime msec service password-encryption

d. Replace the encrypted secret password.

enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2

Change to:

enable secret class

e. In the lines for interface GigabitEthernet0/1, insert a new line to enable the interface.

```
interface GigabitEthernet0/1
ip address 192.168.1.1 255.255.255.0
duplex auto
speed auto
```

#### Change to:

```
interface GigabitEthernet0/1
ip address 192.168.1.1 255.255.255.0
duplex auto
speed auto
no shutdown
```

f. Change the message-of-the-day (MOTD) banner configuration to insert the delimiting characters as if you were entering the command at the command line.

banner motd ^C Unauthorized Access is Prohibited! ^C

Change to:

banner motd " Unauthorized Access is Prohibited! "

g. In line con 0 and vty 0 4 sections, replace the encrypted password.

```
line con 0
password 7 104D000A0618
line vty 0 4
password 7 104D000A0618
```

#### Change to:

line con 0
password cisco
line vty 0 4
password cisco

h. After you have made all of the edits to the backup configuration file, save your changes to filename, R1config-backup.

Note: When saving the file, an extension, such as .txt, may be added to the filename automatically.

#### Step 3: Restore the router configuration.

You can restore the edited running configuration directly to the console terminal in router global configuration mode, and the configurations are entered as if they were commands entered individually at the command prompt.

- a. From the Tera Term console connection to the router, enter global configuration mode.
- b. From the File menu, select Send file....
- c. Locate R1-config-backup and select Open.
- d. Save the running configuration to the startup configuration file.

#### R1# copy running-config startup-config

e. Verify the new running configuration.

#### Step 4: Back up and restore the switch.

Go back to the beginning of Part 2 and follow the same steps to backup and restore the switch configuration.

## Reflection

Why do you think it is important to use a text editor instead of a word processor to copy and save your command configurations?

## **Router Interface Summary Table**

Router Interface Summary						
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2		
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)		
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.

# 11.4.2.7 Lab – Managing Device Configuration Files Using TFTP, Flash, and USB

Topology



## **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/1	192.168.1.1	255.255.255.0	N/A
S1	VLAN 1	192.168.1.11	255.255.255.0	192.168.1.1
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1

## **Objectives**

Part 1: Build the Network and Configure Basic Device Settings

Part 2: (Optional) Download TFTP Server Software

Part 3: Use TFTP to Back Up and Restore the Switch Running Configuration

Part 4: Use TFTP to Back Up and Restore the Router Running Configuration

Part 5: Back Up and Restore Running Configurations Using Router Flash Memory

Part 6: (Optional) Use a USB Drive to Back Up and Restore the Running Configuration

## **Background / Scenario**

Cisco networking devices are often upgraded or swapped out for a number of reasons. It is important to maintain backups of the latest device configurations, as well as a history of configuration changes. A TFTP server is often used to backup configuration files and IOS images in production networks. A TFTP server is a centralized and secure method used to store the backup copies of the files and restore them as necessary. Using a centralized TFTP server, you can back up files from many different Cisco devices.

In addition to a TFTP server, most of the current Cisco routers can back up and restore files locally from CompactFlash (CF) memory or a USB flash drive. The CF is a removable memory module that has replaced the limited internal flash memory of earlier router models. The IOS image for the router resides in the CF memory, and the router uses this IOS Image for the boot process. With the larger size of the CF memory, additional files can be stored for backup purposes. A removable USB flash drive can also be used for backup purposes.

In this lab, you will use TFTP server software to back up the Cisco device running configuration to the TFTP server or flash memory. You can edit the file using a text editor and copy the new configuration back to a Cisco device.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). The switches used are Cisco Catalyst 2960s with Cisco IOS Release 15.0(2) (lanbasek9 image). Other routers, switches, and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers and switches have been erased and have no startup configurations. If you are unsure, contact your instructor.

## **Required Resources**

- 1 Router (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 1 Switch (Cisco 2960 with Cisco IOS Release 15.0(2) lanbasek9 image or comparable)
- 1 PC (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term, and a TFTP server)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology
- USB flash drive (Optional)

## Part 1: Build the Network and Configure Basic Device Settings

In Part 1, you will set up the network topology and configure basic settings, such as the interface IP addresses for router R1, switch S1 and PC-A.

#### Step 1: Cable the network as shown in the topology.

Attach the devices as shown in the topology diagram, and cable as necessary.

## Step 2: Initialize and reload the router and switch.

#### Step 3: Configure basic settings for each device.

- a. Configure basic device parameters as shown in the Addressing Table.
- b. To prevent the router and switch from attempting to translate incorrectly entered commands as though they were host names, disable DNS lookup.
- c. Assign **class** as the privileged EXEC encrypted password.
- d. Configure the passwords and allow login for console and vty lines using the cisco as the password.
- e. Configure the default gateway for the switch.
- f. Encrypt the clear text passwords.
- g. Configure the IP address, subnet mask, and default gateway for PC-A.

#### Step 4: Verify connectivity from PC-A.

- a. Ping from PC-A to S1.
- b. Ping from PC-A to R1.

If the pings are not successful, troubleshoot the basic device configurations before continuing.

# Part 2: (Optional) Download TFTP Server Software

A number of free TFTP servers are available on the Internet for download. The Tftpd32 server is used with this lab.

Note: Downloading a TFTP server from a website requires Internet access.

## Step 1: Verify availability of a TFTP server on PC-A.

- a. Click the Start menu and select All Programs.
- b. Search for a TFTP server on PC-A.
- c. If a TFTP server is not found, a TFTP server can be downloaded from the Internet.

#### Step 2: Download a TFTP server.

- a. Tftpd32 is used in this lab. This server can be downloaded from the following link: http://tftpd32.jounin.net/tftpd32\_download.html
- b. Choose the appropriate version for your system and install the server.

# Part 3: Use TFTP to Back Up and Restore the Switch Running Configuration

## Step 1: Verify connectivity to switch S1 from PC-A.

The TFTP application uses the UDP Layer 4 transport protocol, which is encapsulated in an IP packet. For TFTP file transfers to function, there must be Layer 1 and 2 (Ethernet, in this case) and Layer 3 (IP) connectivity between the TFTP client and the TFTP server. The LAN topology in this lab uses only Ethernet at Layers 1 and 2. However, TFTP transfers can also be accomplished over WAN links that use other Layer 1 physical links and Layer 2 protocols. As long as there is IP connectivity between the client and server, as demonstrated by ping, the TFTP transfer can take place. If the pings are not successful, troubleshoot the basic device configurations before continuing.

**Note**: A common misconception is that you can TFTP a file over the console connection. This is not the case because the console connection does not use IP. The TFTP transfer can be initiated from the client device (router or switch) using the console connection, but there must be IP connectivity between the client and server for the file transfer to take place.

## Step 2: Start the TFTP server.

- a. Click the Start menu and select All Programs.
- b. Find and select Tftpd32 or Tftpd64. The following window displays that the TFTP server is ready.

🎨 Tftpd32 by Ph. Jounin								
Current Directo Server interfac	Current Directory C:\Users\User1  Browse Browse Server interface 192.168.1.3 Show Dir							
Tftp Server	, Tftp Client ∣	DHCP server	Sys	log server	Log viewer			
peer		file		start time	progress			
•						•		
<u>A</u> bout		<u>S</u> ettin	gs		<u>H</u> elp			

c. Click **Browse** to choose a directory where you have write permission, such as C:\Users\User1, or the Desktop.

## Step 3: Explore the copy command on a Cisco device.

a. Console into switch S1 and, from the privileged EXEC mode prompt, enter copy ? to display the options for source or "from" location and other available copy options. You can specify flash: or flash0: as the source, however, if you simply provide a filename as the source, flash0: is assumed and is the default. Note that running-config is also an option for the source location.

S1# copy ?					
/erase	Erase destination file system.				
/error	Allow to copy error file.				
/noverify	Don't verify image signature before reload.				
/verify	Verify image signature before reload.				
archive:	Copy from archive: file system				
cns:	Copy from cns: file system				
flash0:	Copy from flash0: file system				
flash1:	Copy from flash1: file system				
flash:	Copy from flash: file system				
ftp:	Copy from ftp: file system				
http:	Copy from http: file system				
https:	Copy from https: file system				
null:	Copy from null: file system				
nvram:	Copy from nvram: file system				
rcp:	Copy from rcp: file system				
running-config	Copy from current system configuration				
scp:	Copy from scp: file system				
startup-config	Copy from startup configuration				
system:	Copy from system: file system				
tar:	Copy from tar: file system				

tftp:	Сору	from	tftp: f:	ile sy	ystem
tmpsys:	Сору	from	tmpsys:	file	system
xmodem:	Сору	from	<pre>xmodem:</pre>	file	system
ymodem:	Сору	from	ymodem:	file	system

b. Use the ? to display the destination options after a source file location is chosen. The **flash:** file system for S1 is the source file system in this example.

```
S1# copy flash: ?
```

```
archive:
             Copy to archive: file system
              Copy to flash0: file system
flash0:
flash1:
              Copy to flash1: file system
              Copy to flash: file system
flash:
ftp:
              Copy to ftp: file system
              Copy to http: file system
http:
              Copy to https: file system
https:
idconf
              Load an IDConf configuration file
null:
              Copy to null: file system
              Copy to nvram: file system
nvram:
              Copy to rcp: file system
rcp:
running-config Update (merge with) current system configuration
               Copy to scp: file system
scp:
startup-config Copy to startup configuration
syslog:
              Copy to syslog: file system
              Copy to system: file system
system:
tftp:
              Copy to tftp: file system
tmpsys:
               Copy to tmpsys: file system
               Copy to xmodem: file system
xmodem:
ymodem:
               Copy to ymodem: file system
```

## Step 4: Transfer the running-config file from switch S1 to TFTP server on PC-A.

a. From the privileged EXEC mode on the switch, enter the copy running-config tftp: command. Provide the remote host address of the TFTP server (PC-A), 192.168.1.3. Press Enter to accept default destination filename (s1-confg) or provide your own filename. The exclamation marks (!!) indicate the transfer process is in progress and is successful.

S1# copy running-config tftp: Address or name of remote host []? 192.168.1.3 Destination filename [s1-confg]? !! 1465 bytes copied in 0.663 secs (2210 bytes/sec) S1#

The TFTP server also displays the progress during the transfer.

ą	🔖 Tftpd32 by Ph. Jouni	n				×
	Current Directory C:\Use Server interface 192.16	ers\User1 68.1.3			<ul> <li>■</li> <li>■</li></ul>	owse ow Dir
	Tftp Server Tftp Client	DHCP server	Sys	log server	Log viewer	1
	peer	file		start time	progress	
	192.168.1.11:52051	.s1-confg>		11:18:55	100%	
	•		_			
	About	<u>S</u> ettin	gs		<u>H</u> elp	

**Note**: If you do not have permission to write to the current directory that is used by the TFTP server, the following error message displays:

S1# copy running-config tftp:
Address or name of remote host []? 192.168.1.3
Destination filename [s1-confg]?
<pre>%Error opening tftp://192.168.1.3/s1-confg (Permission denied)</pre>

You can change the current directory in TFTP server by clicking Browse and choosing a different folder.

**Note**: Other issues, such as a firewall blocking TFTP traffic, can prevent the TFTP transfer. Please check with your instructor for further assistance.

b. In the Tftpd32 server window, click **Show Dir** to verify that the **s1-confg** file has been transferred to your current directory. Click **Close** when finished.

ų	Tftpd32: directory		<b>—</b>
	NTUSER.DAT ntuser.dat.LOG1 ntuser.dat.LOG2 NTUSER.DAT{016883 NTUSER.DAT{016883 NTUSER.DAT{016883 ntuser.ini Readme s1-confg	12/12/2012 12/12/2012 12/12/2012 3bd-6c6f-11de-8d1d-001 3bd-6c6f-11de-8d1d-001 3bd-6c6f-11de-8d1d-001 12/12/2012 12/15/2012 2/5/2013 1465	1048576 262144 0 Ie0bcde3ec}.T Ie0bcde3ec}.T Ie0bcde3ec}.T 20 1428
	Close	Сору	Explorer
### Step 5: Create a modified switch running configuration file.

The saved running configuration file, **s1-confg**, can also be restored to the switch by using the **copy** command from the switch. The original or a modified version of the file can be copied to the flash file system of the switch.

- a. Navigate to the TFTP directory on PC-A by using the file system of PC-A, and then locate the **s1-confg** file. Open this file using a text editor program, such as WordPad.
- b. With the file open, locate the hostname S1 line. Replace S1 with Switch1. Delete all the self-generated crypto keys, as necessary. A sample of the keys is displayed below. These keys are not exportable and can cause errors while updating the running configuration.

```
crypto pki trustpoint TP-self-signed-1566151040
enrollment selfsigned
subject-name cn=IOS-Self-Signed-Certificate-1566151040
revocation-check none
rsakeypair TP-self-signed-1566151040
T
I
crypto pki certificate chain TP-self-signed-1566151040
certificate self-signed 01
 3082022B 30820194 A0030201 02020101 300D0609 2A864886 F70D0101 05050030
 31312F30 2D060355 04031326 494F532D 53656C66 2D536967 6E65642D 43657274
<output omitted>
 E99574A6 D945014F B6FE22F3 642EE29A 767EABF7 403930CA D2C59E23 102EC12E
 02F9C933 B3296D9E 095EBDAF 343D17F6 AF2831C7 6DA6DFE3 35B38D90 E6F07CD4
  40D96970 A0D12080 07A1C169 30B9D889 A6E2189C 75B988B9 0AF27EDC 6D6FA0E5
 CCFA6B29 729C1E0B 9DADACD0 3D7381
      quit
```

c. Save this file as a plain text file with a new filename, **Switch1-confg.txt**, in this example.

Note: When saving the file, an extension, such as .txt, may be added to the filename automatically.

d. In the Tftpd32 server window, click **Show Dir** to verify that the **Switch1-confg.txt** file is located in the current directory.

### Step 6: Upload running configuration file from TFTP server to switch S1.

a. From the privileged EXEC mode on the switch, enter the copy tftp running-config command. Provide the remote host address of the TFTP server, 192.168.1.3. Enter the new filename, Switch1-confg.txt. The exclamation mark (!) indicates the transfer process is in progress and is successful.

```
S1# copy tftp: running-config
Address or name of remote host []? 192.168.1.3
Source filename []? Switch1-confg.txt
Destination filename [running-config]?
Accessing tftp://192.168.1.3/Switch1-confg.txt...
Loading Switch1-confg.txt from 192.168.1.3 (via Vlan1): !
[OK - 1580 bytes]
[OK]
1580 bytes copied in 9.118 secs (173 bytes/sec)
*Mar 1 00:21:16.242: %PKI-4-NOAUTOSAVE: Configuration was modified. Issue "write
memory" to save new certificate
```

\*Mar 1 00:21:16.251: %SYS-5-CONFIG\_I: Configured from tftp://192.168.1.3/Switch1confg.txt by console Switch1#

After the transfer has completed, the prompt has changed from S1 to Switch1, because the running configuration is updated with the **hostname Switch1** command in the modified running configuration.

b. Enter the show running-config command to examine running configuration file.

```
Switch1# show running-config
Building configuration...
Current configuration : 3062 bytes
T
! Last configuration change at 00:09:34 UTC Mon Mar 1 1993
1
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
Т
hostname Switch1
1
boot-start-marker
boot-end-marker
<output omitted>
```

**Note**: This procedure merges the running-config from the TFTP server with the current running-config in the switch or router. If changes were made to the current running-config, the commands in the TFTP copy are added. Alternatively, if the same command is issued, it updates the corresponding command in the switch or router current running-config.

If you want to completely replace the current running-config with the one from the TFTP server, you must erase the switch startup-config and reload the device. You will then need to configure the VLAN 1 management address, so there is IP connectivity between the TFTP server and the switch.

# Part 4: Use TFTP to Back Up and Restore the Router Running Configuration

The backup and restore procedure from Part 3 can also be performed with a router. In Part 4, the running configuration file will be backed up and restored using a TFTP server.

### Step 1: Verify connectivity to router R1 from PC-A.

If the pings are not successful, troubleshoot the basic device configurations before continuing.

## Step 2: Transfer the running configuration from router R1 to TFTP server on PC-A.

- a. From the privileged EXEC mode on R1, enter the **copy running-config tftp** command. Provide the remote host address of the TFTP server, 192.168.1.3, and accept the default filename.
- b. Verify that the file has been transferred to the TFTP server.

### Step 3: Restore the running configuration file to the router.

- a. Erase the startup-config file on the router.
- b. Reload the router.
- c. Configure the G0/1 interface on the router with an IP address 192.168.1.1.
- d. Verify connectivity between the router and PC-A.
- e. Use the **copy** command to transfer the running-config file from the TFTP server to the router. Use **running-config** as the destination.
- f. Verify the router has updated the running-config.

# Part 5: Back Up and Restore Configurations Using Router Flash Memory

For the 1941 and other newer Cisco routers, there is no internal flash memory. The flash memory for these routers uses CompactFlash (CF) memory. The use of CF memory allows for more available flash memory and easier upgrades without the need to open the router case. Besides storing the necessary files, such as IOS images, the CF memory can store other files, such as a copy of the running configuration. In Part 5, you will create a backup copy of the running configuration file and save it on the CF memory on the router.

**Note**: If the router does not use CF, the router may not have enough flash memory for storing the backup copy of running configuration file. You should still read through the instructions and become familiar with the commands.

### Step 1: Display the router file systems.

The **show file systems** command displays the available file systems on the router. The **flash0**: file system is the default file system on this router as indicated by the asterisk (\*) symbol (at the beginning of the line). The hash (#) sign (at the end of the highlighted line) indicates that it is a bootable disk. The **flash0**: file system can also be referenced using the name **flash**:. The total size of the **flash0**: is 256 MB with 62 MB available. Currently the **flash1**: slot is empty as indicated by the — under the headings, Size (b) and Free (b). Currently **flash0**: and **nvram**: are the only available file systems.

#### R1# show file systems

```
File Systems:
```

	Size(b)	Free(b)	Туре	Flags	Prefixes	
	-	-	opaque	rw	archive	:
	-	-	opaque	rw	system:	
	-	-	opaque	rw	tmpsys:	
	-	-	opaque	rw	null:	
	-	-	network	rw	tftp:	
*	260153344	64499712	disk	rw	flash0:	<pre>flash:#</pre>
	-	-	disk	rw	flash1:	
	262136	242776	nvram	rw	nvram:	
	-	-	opaque	WO	syslog:	
	-	-	opaque	rw	xmodem:	
	-	-	opaque	rw	ymodem:	
	_	-	network	rw	rcp:	
	-	-	network	rw	http:	
	-	-	network	rw	ftp:	
	-	-	network	rw	scp:	
	-	-	opaque	ro	tar:	

- - network rw https: - - opaque ro cns:

Where is the startup-config file located? \_\_\_\_

**Note**: Verify there is at least 1 MB (1,048,576 bytes) of free space. If there is not enough space in the flash memory, please contact your instructor for further instructions. You can determine the size of flash memory and space available using the **show flash** or **dir flash**: command at the privileged EXEC prompt.

# Step 2: Copy the router running configuration to flash.

A file can be copied to flash by using the **copy** command at the privileged EXEC prompt. In this example, the file is copied into **flash0**:, because there is only one flash drive available as displayed in the previous step, and it is also the default file system. The **R1-running-config-backup** file is used as the filename for the backup running configuration file.

Note: Remember that filenames are case-sensitive in the IOS file system.

a. Copy the running configuration to flash memory.

```
R1# copy running-config flash:
Destination filename [running-config]? R1-running-config-backup
2169 bytes copied in 0.968 secs (2241 bytes/sec)
```

b. Use **dir** command to verify the running-config has been copied to flash.

```
R1# dir flash:
Directory of flash0:/
```

```
1 drw- 0 Nov 15 2011 14:59:04 +00:00 ipsdir
<output omitted>
```

```
      20 -rw-
      67998028
      Aug 7 2012 17:39:16 +00:00
      c1900-universalk9-mz.SPA.152-

      4.M3.bin
      22 -rw-
      2169
      Feb 4 2013 23:57:54 +00:00
      R1-running-config-backup

      24 -rw-
      5865
      Jul 10 2012 14:46:22 +00:00
      lpnat

      25 -rw-
      6458
      Jul 17 2012 00:12:40 +00:00
      lpIPSec
```

260153344 bytes total (64503808 bytes free)

c. Use the **more** command to view the running-config file in flash memory. Examine the file output and scroll to the Interface section. Notice the **no shutdown** command is not included with the GigabitEthernet0/1. The interface is shut down when this file is used to update the running configuration on the router.

```
R1# more flash:R1-running-config-backup
<output omitted>
interface GigabitEthernet0/1
ip address 192.168.1.1 255.255.255.0
duplex auto
speed auto
<output omitted>
```

# Step 3: Erase the startup configuration and reload the router.

# Step 4: Restore the running configuration from flash.

a. Verify the router has the default initial configuration.

b. Copy the saved running-config file from flash to update the running-config.

```
Router# copy flash:R1-running-config-backup running-config
```

c. Use the **show ip interface brief** command to view the status of the interfaces. The interface GigabitEthernet0/1 was not enabled when the running configuration was updated, because it is administratively down.

R1# show ip interface brief									
Interface	IP-Address	OK? Me	lethod	Status		Protocol			
Embedded-Service-Engine0/0	unassigned	YES u	nset	administratively	down	down			
GigabitEthernet0/0	unassigned	YES u	nset	administratively	down	down			
GigabitEthernet0/1	192.168.1.1	YES TI	FTP	administratively	down	down			
Serial0/0/0	unassigned	YES u	nset	administratively	down	down			
Serial0/0/1	unassigned	YES u	nset	administratively	down	down			

The interface can be enabled using the **no shutdown** command in the interface configuration mode on the router.

Another option is to add the **no shutdown** command for the GigabitEthernet0/1 interface to the saved file before updating the router running configuration file. This will be done in Part 6 using a saved file on a USB flash drive.

**Note**: Because the IP address was configured by using a file transfer, TFTP is listed under the Method heading in the **show ip interface brief** output.

# Part 6: (Optional) Use a USB Drive to Back Up and Restore the Running Configuration

A USB flash drive can be used to backup and restore files on a router with an available USB port. Two USB ports are available on the 1941 routers.

Note: USB ports are not available on all routers, but you should still become familiar with the commands.

**Note**: Because some ISR G1 routers (1841, 2801, or 2811) use File Allocation Table (FAT) file systems, there is a maximum size limit for the USB flash drives that can be used in this part of the lab. The recommended maximum size for an ISR G1 is 4 GB. If you receive the following message, the file system on the USB flash drive may be incompatible with the router or the capacity of the USB flash drive may have exceed maximum size of the FAT file system on the router.

\*Feb 8 13:51:34.831: %USBFLASH-4-FORMAT: usbflash0 contains unexpected values in partition table or boot sector. Device needs formatting before use!

#### Step 1: Insert a USB flash drive into a USB port on the router.

Notice the message on the terminal when inserting the USB flash drive.

R1#
\* \*Feb 5 20:38:04.678: %USBFLASH-5-CHANGE: usbflash0 has been inserted!

#### Step 2: Verify that the USB flash file system is available.

```
R1# show file systems
```

File Systems:

Size(b)	Free(b)	Туре	Flags	Prefixes
-	-	opaque	rw	archive:
-	-	opaque	rw	system:
-	-	opaque	rw	tmpsys:

	-	-	opaque	rw	null:	
	-	-	network	rw	tftp:	
*	260153344	64512000	disk	rw	flash0:	flash:#
	-	-	disk	rw	flash1:	
	262136	244676	nvram	rw	nvram:	
	-	-	opaque	WO	syslog:	
	-	-	opaque	rw	<pre>xmodem:</pre>	
	-	-	opaque	rw	ymodem:	
	-	-	network	rw	rcp:	
	-	-	network	rw	http:	
	-	-	network	rw	ftp:	
	-	-	network	rw	scp:	
	-	-	opaque	ro	tar:	
	-	-	network	rw	https:	
	-	-	opaque	ro	cns:	
	7728881664	7703973888	usbflash	rw	usbflash	.0 <b>:</b>

# Step 3: Copy the running configuration file to the USB flash drive.

Use the copy command to copy the running configuration file to the USB flash drive.

```
R1# copy running-config usbflash0:
```

```
Destination filename [running-config]? R1-running-config-backup.txt 2198 bytes copied in 0.708 secs (3105 bytes/sec)
```

#### Step 4: List the file on the USB flash drive.

Use the **dir** command (or **show** command) on the router to list the files on the USB flash drive. In this sample, a flash drive was inserted into USB port 0 on the router.

```
R1# dir usbflash0:
```

```
Directory of usbflash0:/
```

1	-rw-	16216	Nov 15 2006	09:34:04 +00:00	ConditionsFR.txt
2	-rw-	2462	May 26 2006	21:33:40 +00:00	Nlm.ico
3	-rw-	24810439	Apr 16 2010	10:28:00 +00:00	Twice.exe
4	-rw-	71	Jun 4 2010	11:23:06 +00:00	AUTORUN.INF
5	-rw-	65327	Mar 11 2008	10:54:26 +00:00	ConditionsEN.txt
6	-rw-	2198	Feb 5 2013	21:36:40 +00:00	R1-running-config-backup.txt

7728881664 bytes total (7703973888 bytes free)

### Step 5: Erase the startup-config and reload the router.

# Step 6: Modify the saved file.

a. Remove the USB drive from the router.

```
Router#
```

\*Feb 5 21:41:51.134: %USBFLASH-5-CHANGE: usbflash0 has been removed!

b. Insert the USB drive into the USB port of a PC.

c. Modify the file using a text editor. The **no shutdown** command is added to the GigabitEthernet0/1 interface. Save the file as a plain text file on to the USB flash drive.

```
!
interface GigabitEthernet0/1
ip address 192.168.1.1 255.255.255.0
no shutdown
duplex auto
speed auto
!
```

d. Remove the USB flash drive from the PC safely.

# Step 7: Restore the running configuration file to the router.

a. Insert the USB flash drive into a USB port on the router. Notice the port number where the USB drive has been inserted if there is more than one USB port available on the router.

```
*Feb 5 21:52:00.214: %USBFLASH-5-CHANGE: usbflash1 has been inserted!
```

b. List the files on the USB flash drive.

```
Router# dir usbflash1:
Directory of usbflash1:/
```

6	-rw-	2344	Feb 6 2013	3 14:42:30	+00:00	R1-running-config-backup.txt
5	-rw-	65327	Mar 11 200	3 10:54:26	+00:00	ConditionsEN.txt
4	-rw-	71	Jun 4 201	0 11:23:06	+00:00	AUTORUN.INF
3	-rw-	24810439	Apr 16 201	0 10:28:00	+00:00	Twice.exe
2	-rw-	2462	May 26 200	5 21 <b>:</b> 33:40	+00:00	Nlm.ico
1	-rw-	16216	Nov 15 200	5 09:34:04	+00:00	ConditionsFR.txt

7728881664 bytes total (7703965696 bytes free)

c. Copy the running configuration file to the router.

```
Router# copy usbflash1:R1-running-config-backup.txt running-config
Destination filename [running-config]?
2344 bytes copied in 0.184 secs (12739 bytes/sec)
R1#
```

d. Verify that the GigabitEthernet0/1 interface is enabled.

R1# show ip interface brief										
Interface	IP-Address	OK?	Method	Status		Protocol				
Embedded-Service-Engine0/0	unassigned	YES	unset	administratively	down	down				
GigabitEthernet0/0	unassigned	YES	unset	administratively	down	down				
GigabitEthernet0/1	192.168.1.1	YES	TFTP	up		up				
Serial0/0/0	unassigned	YES	unset	administratively	down	down				
Serial0/0/1	unassigned	YES	unset	administratively	down	down				

The G0/1 interface is enabled because the modified running configuration included the **no shutdown** command.

# Reflection

- 1. What command do you use to copy a file from the flash to a USB drive?
- 2. What command do you use to copy a file from the USB flash drive to a TFTP server?

# **Router Interface Summary Table**

Router Interface Summary								
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2				
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)				
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)				
<b>Note</b> : To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device								

The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be

used in Cisco IOS commands to represent the interface.

# 11.4.2.8 Lab – Researching Password Recovery Procedures

# **Objectives**

# Part 1: Research the Configuration Register

- Identify the purpose of the configuration register.
- Describe router behavior for different configuration register values.

# Part 2: Document the Password Recovery Procedure for a Specific Cisco Router

- Research and record the process for password recovery on a specific Cisco router.
- Answer questions based on the researched procedure.

# **Background / Scenario**

The purpose of this lab is to research the procedure for recovering or resetting the enable password on a specific Cisco router. The enable password protects access to privileged EXEC and configuration mode on Cisco devices. The enable password can be recovered, but the enable secret password is encrypted and would need to be replaced with a new password.

In order to bypass a password, a user must be familiar with the ROM monitor (ROMMON) mode, as well as the configuration register setting for Cisco routers. ROMMON is basic CLI software stored in ROM that can be used to troubleshoot boot errors and recover a router when an IOS is not found.

In this lab, you will begin by researching the purpose and settings of the configuration register for Cisco devices. You will then research and detail the exact procedure for password recovery for a specific Cisco router.

# **Required Resources**

• Device with Internet access

# Part 1: Research the Configuration Register

To recover or reset an enable password, a user will utilize the ROMMON interface to instruct the router to ignore the startup configuration when booting. When booted, the user will access privilege EXEC mode, overwrite the running configuration with the saved startup configuration, recover or reset the password, and restore the router's boot process to include the startup configuration.

The router's configuration register plays a vital role in the process of password recovery. In the first part of this lab, you will research the purpose of a router's configuration register and the meaning of certain configuration register values.

# Step 1: Describe the purpose of the configuration register.

What is the purpose of the configuration register?

What command changes the configuration register in configuration mode? \_\_\_\_\_

What command changes the configuration register in the ROMMON interface? \_\_\_\_\_

### Step 2: Determine configuration register values and their meanings.

Research and list the router behavior for the following configuration register values.

0x2102	
	-
0x2142	
	-
	-
What is the difference between these two configuration register values?	

# Part 2: Document the Password Recovery Procedure for a Specific Cisco Router

For Part 2, you will describe the exact procedure for recovering or resetting a password from a specific Cisco router and answer questions based on your research. Your instructor will provide you with the exact router model to research.

### Step 1: Detail the process to recover a password on a specific Cisco router.

Research and list the steps and commands that you need to recover or reset the enable or enable secret password from your Cisco router. Summarize the steps in your own words.

### Step 2: Answer questions about the password recovery procedure.

Using the process for password recovery, answer the following questions.

Describe how to find the current setting for your configuration register.

Describe the process for entering ROMMON.

What commands do you need to enter the ROMMON interface?

What message would you expect to see when the router boots?

Why is it important to load the startup configuration into the running configuration?

Why is it important to change the configuration register back to the original value after recovering password?

# Reflection

1. Why is it of critical importance that a router be physically secured to prevent unauthorized access?

# 11.6.1.1 Design and Build a Small Business Network (Capstone Project)

# Objectives

# Explain how a small network of directly connected segments is created, configured, and verified.

In this activity, you will demonstrate that you know how to design, configure, verify, and secure a very small network. Documentation and presentation are also vital parts of this Capstone Project.

# Background/Scenario

Note: This activity is best completed in groups of 2-3 students.

Design and build a network from scratch.

- Your design must include a minimum of one router, one switch, and one PC.
- Fully configure the network and use IPv4 or IPv6 (subnetting must be included as a part of your addressing scheme).
- Verify the network using at least five show commands.
- Secure the network using SSH, secure passwords, and console passwords (minimum).

Create a rubric to use for informal peer grading. Alternatively, your instructor may choose to use the rubric provided with this activity.

Present your Capstone Project to the class and be able to answer questions from your peers and Instructor.

# **Required Resources**

- Packet Tracer
- Student/group-created rubric for assessment of the assignment

# Reflection

- 1. What was the most difficult portion of this activity?
- 2. Why do you think network documentation is so important to this activity and in the real world?